

# JHY ROBOT

Control System User Manual

For other instructions, please refer to

- JHY Robot Body User Manual
- JHY Robot Control System Welding Instructions
- JHY Robot External Axis Control Instructions

Wuxi Jihoyen Industrial Automation Co., Ltd. www.jhyrobotic.com 2023.05



#### **Table of Contents**

1 Terms and Definitions	1
1.1 Teach Pendant	1
1.2 Key Indication	1
2 Security	1
2.1 Safety Regulations	1
2.2 Safety Precautions For Operators	2
2.3 Safety Precautions During Operation	3
2.3.1 General Principles	3
2.3.2 Emergency Treatment	4
2.3.3 Operating The Handheld Teach Pendant	4
2.3.4 Security Tools	5
2.3.5 Safety Considerations For Manual Mode	6
2.3.6 Safety Considerations For Automatic Mode	7
3 Install Wiring	7
3.1 Installation Site and Environment	7
3.1.1 Installation Environment Requirements	7
3.1.2 Installation Location Requirements	8
3.1.3 Precautions for Installation and Wiring	8
3.2 Controller Installation Instructions	9
3.2.1 Installation Mode of Main Control and I/O Unit	10
3.2.2 Main Control Unit Wiring Description	12
3.2.3 Teaching Pendant Installation Wiring	14
3.2.4 IO Module Wiring Definition	15
4 Hand-held Teach Pendant	16
4.1 Key Function of Teach Pendant	
4.2 Teach Pendant Interface	22
4.3 System Application Menu	24
4.3.1 Common Toolbar Customization	24
4.3.2 Description of Menu Options	25
4.4 Status Bar	26
4.4.1 Servo Display Status	26



4.4.2 Working Mode
4.4.3 Coordinate System27
4.4.4 Current Tool No. and Workpiece No27
4.4.5 Speed 27
4.4.6 Teaching File play Execution Mode28
4.4.7 Current Permissions and Network Status
4.5 Floating Menu28
4.6 Robot Status and Alarm History Viewing
4.6.1 Robot Status
4.6.2 Robot Alarm History and Action Log View
5 Get Started Quickly
5.1 Servo Power On
5.1.1 Switch on the Main Power Supply31
5.1.2 Switch on the Servo Power Supply
5.2 Servo Power Cut Off32
5.2.1 Cut Off the Servo Power Supply 32
5.2.2 Cut Off the Main Power Supply
5.3 Selection of Coordinate System
5.4 Manual Speed Adjustment
5.5 Axis Operation
5.6 Flush
5.7 Return to Zero position
6 Engineering Management Interface
6.1 Description of Robot Engineering Structure37
6.2 Engineering Operations
7 Program Editing Interface
7.1 Currently Open Programs
7.2 History Program
7.3 Program Page Turning43
7.4 Program Editing43
7.5 Extension Bar45
8 Variables
8.1 Global Variables



	9.1.1. Clobal Desition Variables	40
	8.1.1 Global Position Variables	48
	8.1.2 Global Incremental Location Points	51
	8.1.3 Global String Variable	51
	8.1.4 Global Numeric Variables	51
	8.2 Engineering Variables	52
	8.2.1 Engineering Positional Variable	53
	8.2.2 Engineering Incremental Positional Variable	53
	8.2.3 Engineering Numerical Variables	54
	8.2.4 Engineering String Variables	54
	8.3 Robot Posture	55
9 Co	oordinate System	55
	9.1 Introduction to Coordinate System	55
	9.1.1 Axis Coordinate System – ACS	56
	9.1.2 Kinematic Coordinate System – KCS	56
	9.1.3 Tool Coordinate System – TCS	56
	9.1.4 World Coordinate System – WCS	56
	9.1.5 Piece Coordinate System – PCS	57
	9.2 Coordinate System Management Interface	58
	9.3 Axis Coordinate System (ACS)	58
	9.4 Kinematic Coordinate System (KCS)	59
	9.5 Tool Coordinate System	59
	9.5.1 Tool Coordinate System Axis Action	60
	9.5.2 Calibration of Tool Coordinate System	61
	9.6 Piece Coordinate System (PCS)	68
	9.6.1 Piece Coordinate System Axis Action	68
	9.6.2 Calibration of Piece Coordinate System	69
	9.7 Workspace Monitoring	73
	9.7.1 Description of Working Space Monitoring	73
	9.7.2 Working Space Monitoring Setting	75
10 S	ystem Parameter Setting	84
	10.1 System Parameters	84
	10.2 Hardware Parameters	86
	10.3 Axis	87



10.4 External axis	
10.5 Descartes	90
10.6 Plan Parameters	
10.7 DH Parameters	97
10.8 Coupling	
11 General IO	
11.1 Input Signal	
11.1.1 Interface	
11.1.2 Function Description	
11.2 Output Signal	
11.2.1 Interface	
11.2.2 Function Description	
11.3 IO Wiring	
12 Remote IO	
12.1 Introduction to the Interface	
12.1.1 File Settings	
12.1.2 Remote IO Input	
12.1.3 Remote IO Output	
12.1.4 Setting	
12.2 Use in Single Mode	
12.2.1 Application	
12.2.2 Operation Steps	
12.3 Combined Mode Usage	113
12.3.1 Application	
12.3.2 Operation Steps	
12.4 Use of Additional Tasks	
12.4.1 Application Scenarios	116
12.4.2 Operation Steps	
13 Other Functions	
13.1 Zero Calibration	120
13.2 20-Point Method	
13.3 Exception Handling	
13.4 Authority Management	126



13.4.1 User Switching	
13.4.2 Hardware Testing	
13.4.3 Interface Style	
13.4.4 Upgrade and Backup	
14 Instruction System	130
14.1 List of Orders	
14.2 Directive Specification	
14.3 Motion Instructions	
14.3.1 Processing Mechanism of Motion Instruction	
14.3.3 Movs joint spline motion	
14.3.4 Movl Linear Motion	
14.3.5 Movc Circular Motion	136
14.3.6 MovjUntil Conditional Interrupt Movj	
14.3.7 MovlUntil Conditional Interrupt Movl	138
14.3.8 MovcUntil Conditional Interrupt Movc	140
14.3.9 MoveExt Outer Axis Set Articulation	
14.4 Motion Parameters	142
14.4.1 SetDyn Acceleration/Deceleration and Acceleration Time	
14.4.2 SetSpeed Global Speed Percentage	
14.4.3 SetCoord Coordinate System Switching	
14.4.4 ResetCoord Coordinate System Switching Reset	
14.4.5 SetTool Coordinate System Switching	
14.4.6 ResetTool Coordinate System Switching Reset	144
14.4.7 SetOriMode Posture planning mode setting	144
14.4.8 ResetOriMode posture Mode Reset	144
14.4.9 SetOffset Position Offset Setting	
14.4.10 ResetOffset Position Offset Cancellation	
14.5 Operation of IO	146
14.5.1 SetDo Output Digital Quantity	
14.5.2 SetDoAt Output IO in Motion	147
14.5.3 SetDoDeltaS Output Digital Quantity in Motion	147
14.5.4 SetDoDeltaT Output Digital Quantity in Motion	148
14.5.5 GetDo Digital Output Reading	



14.5.6 GetDi Digital Quantity Input Acquisition	149
14.5.7 SetAo Output Analog Quantity	150
14.5.8 SetAoAt Output Analog Quantity in Motion	150
14.5.9 GetAo Analog Output Acquisition	151
14.5.10 GetAi Analog Input Acquisition	151
14.5.11 Wait for the condition to complete	152
14.5.12 Pulse Output	152
14.6 Motion Management	153
14.6.1 Delay	153
14.6.2 WaitExecutor Stops Decoding	153
14.6.3 tod Get System Timing	153
14.6.4 SysDate Record system timing	154
14.6.5 Pause	154
14.6.6 GetPoint Save Current Position	154
14.7 Control Process	155
14.7.1 Call Subroutine	155
14.7.2 JUMP-LABEL Flag	155
14.7.3 IF Conditional Judgment	156
14.7.4 ELSELF Condition Judgment	156
14.7.5 WHILE Cycle Condition Judgement	157
14.7.6 FOR Loop Condition Judgment	158
14.8 Notes and Calculations	159
14.8.1 /**/ Multi-line Note	159
14.8.2 Comment/Uncomment Current Line	159
14.8.3 ASSIGN (=) Assignment	159
14.8.4 ADD (+) Addition	160
14.8.5 SUB (-) Subtraction	160
14.8.6 MUL(*) Multiplication	161
14.8.7 DIV(/) Division	161
14.8.8 Expr Advanced Expressions/Statements	162
14.9 Mathematical Functions	165
14.10 Character Functions	166
14.10.1 strlen (X) Finding the Length of a String	166



14.10.2 str2num(X) String to Real166
14.10.3 num2str(X) Real to String167
14.10.4 strcat (X, Y) String Splicing167
14.10.5 strleft (X, N) Takes N characters to the left of the string X
14.10.6 strright (X, N) Takes N characters from the right of a string X
14.10.7 strmid (X, M, N) Takes the M-th to N-th characters of the string X169
14.10.8 strsplit (X, Y, N) String Split169
14.11 Communications
14.11.1 TcpOpen opens tcp/ip communication170
14.11.2 TcpRecv Receiving Data171
14.11.3 TcpSend Sending Data171
14.11.4 TcpClose Closing a TCP/IP Connection172
14.11.5 SerialOpen Receiving Data172
14.11.6 SerialRecv Receiving Data173
14.11.7 SerialSend Sending Data174
14.11.8 SerialClose Closing a TCP/IP Connection
14.11.9 CanbusOpen Receiving Data174
14.11.10 CanbusRecv Receiving Data175
14.11.11 CanbusSend Sending Data176
14.11.12 CanbusClose Closing a TCP/IP Connection
15 Error Messages 177



# **1** Terms and Definitions

The following terms and definitions apply to this document.

#### **1.1 Teach Pendant**

A handheld unit that can be used to program or move a robot and connect to a control system.

#### **1.2 Key Indication**

1. The keys on the handheld teach pendant are represented by []: for example, the emergency stop key is represented by the [emergency stop] key.

2. The keys on the display are represented by []: for example, the clear key is represented by the [clear] key.

## 2 Security

# 2.1 Safety Regulations

The requirements of robots and other mechanical equipment are usually different, such as large range of motion in space, fast operation, rapid movement of arms, etc., which will cause safety hazards.

Read and understand the instruction manual and related documents, and follow various rules and procedures to avoid personal, injury or equipment accidents. It is the user's responsibility to ensure that the robot system is always in a safe operating environment and complies with and abides by national and local laws, regulations and related regulations on safety.

#### **Compliance with Regulations**



The teaching and maintenance of robots must comply with the following regulations

- 1. Laws on industrial safety and health
- 2. Mandatory orders concerning industrial safety and health laws
- 3. Corresponding regulations on industrial safety and health laws
- 4. Safe operation of industrial robots (ISO10218).

Teaching and repairing robots is listed as a "hazardous operation" under industrial safety and



health laws.

#### Safety Management



1. Personnel who teach and maintain the robot must be trained in advance.

2. Carry out safety management according to specific policies in compliance with relevant

regulations. Designate authorized operators and safety management personnel, and give further safety education.

## 2.2 Safety Precautions For Operators

The robot is potentially dangerous within the maximum range of motion.

All relevant personnel in the robotics industry (safety managers, installers, operators and maintenance personnel, etc.)

The idea of **Safety First** must be established at all times, and relevant operations must be carried out on the premise of ensuring the safety of all personnel.



1. Any dangerous operations are prohibited in the installation area of the robot.

2. Strictly abide by the following terms in the work area:

- Wear work clothes (do not wear loose clothes)
- Do not wear gloves when operating the robot.
- Underwear, shirts and ties should not be exposed from work clothes.
- Do not wear large jewelry such as earrings, rings or pendants.
- Wear appropriate safety equipment when necessary, such as hard hats, safety shoes (with non-slip soles), face shields, protective glasses and gloves.

3. Unauthorized personnel are not allowed to approach the robot and its peripheral auxiliary equipment.

4. During the operation of the equipment, the robot appears to have stopped, which may also be because the robot is waiting for the start signal to be in a state of imminent action. Even in such a state, the robot should be regarded as being in action. In order to ensure the safety of the operator, the display or sound of warning lights, etc. should be able to effectively inform (the operator) that the robot is in action.

5. Never force the shaft of the robot, otherwise it may cause personal injury or equipment



damage.

6. Never lean against the robot electrical control cabinet; do not press the operation button at will. Otherwise, the robot may cause unexpected actions, resulting in personal injury and equipment damage.

7. During operation, non-staff are never allowed to touch the robot electrical control cabinet. Otherwise, the robot may make unexpected movements, resulting in personal injury or equipment damage.

## 2.3 Safety Precautions During Operation

## 2.3.1 General Principles

Please follow the following principles for safe operation of the robotic system:

1. If there are staff in the protected space, please operate the robot system manually. When entering the protected space, be sure to carry a control device (teaching device) with you to control the robot at any time.

2. Pay attention to rotating or moving tools, such as cutting tools and saws. Make sure these tools stop moving before approaching the robot.

3. Pay attention to the high temperature surface of the work-piece and the robot system. The temperature of the robot motor is very high after long-term operation.

4. Pay attention to the fixture and make sure to clamp the work-piece. If the fixture is opened, the work-piece will fall off and cause personal injury or equipment damage. The fixture is very powerful and can also cause personal injury if not operated correctly.

5. Pay attention to hydraulic and pneumatic systems and live components. Even if the power is cut off, the residual power on these circuits is dangerous.



6. When installing a tool on the robot, be sure to CUT OFF the power supply on the electrical control cabinet and the installed tools, lock the power switch, and hang a warning sign. During installation and maintenance, for example, when the power is turned on, it may cause electric shock or cause the robot to move abnormally, resulting in injury.

7. Never exceed the allowable range of the robot (see the technical specifications section of the robot manual for the allowable range of the robot). Failure to do so may result in personal injury or equipment damage.

8. Whenever possible, the teaching work should be carried out outside the work area.



9. The following cautions shall be observed when performing teaching work within the robot

motion range:

10. Always observe from the front of the robot;

- Always follow pre-established operating procedures
- Always have an idea of dodging in case the robot makes an unexpected move, making sure you have a way out in an emergency.

## 2.3.2 Emergency Treatment



Press the emergency stop button immediately when:

1. When the robot is operated, there are obstacles in the operating space of the robot that may collide, or there are other workers in the operating space;

2. Robots hurt people or machines.

## 2.3.3 Operating The Handheld Teach Pendant

2.3.3.1 Operating the Handheld Teach Pendant

1. The handheld teaching pendant is a high-quality terminal equipped with high-sensitivity advanced electronic equipment. To avoid failure or damage caused by improper operation, please follow the following instructions when operating.

2. Use the handheld teach pendant only for the purposes specified in this manual. The handheld teach pendant is developed, manufactured and tested in accordance with applicable safety standards. If you follow the safety and use instructions in this manual, the product will not cause personal injury or damage to machines and equipment under normal conditions.

#### 2.3.3.2 Handling and Cleaning

1. Handle with care. Do not drop, throw or hit hard, as this may cause damage or malfunction.

2. In the event of an impact, it is important to verify that the safety functions (actuators and emergency stops) are working properly and are not damaged.

3. When the equipment is not in use, please place it on the vertical wall shelf to prevent accidental falling off.

4. Always use and store the handheld teach pendant in such a way that the cable does not trip



over the person.

5. Do not use sharp objects such as a screwdriver or nib to operate the touchscreen. This may damage the touch screen. Use your finger or stylus (depending on the model, some models do not have a stylus, usually on the back of the handheld pendant).

6. Clean the touch screen regularly. Dust and small particles may block the touch screen and cause malfunction.

7. Do not use solvents, detergents, or scrubbing sponges to clean the handheld teach pendant. Use a soft cloth with a small amount of water or a mild detergent.

8. Always cover the USB port when no USB device is connected. If the port is exposed to dust, it can break or malfunction.

2.3.3.3 Cables and Power Supplies

1. Before opening the cable entry area of the handheld tech pedant, please turn off the power. Otherwise, the component may be damaged or an unknown signal may appear.

2. Make sure that no one is caught by the cable so that the equipment does not fall to the ground.

3. Avoid extrusion of other objects to avoid damage to the cable.

4. Do not place the cable above the sharp edge, so as not to damage the outer skin of the cable.

#### 2.3.4 Security Tools

#### 2.3.4.1 Security Mechanism

Robot systems can be equipped with various safety protection devices, such as door interlock switches, safety light curtains and safety pads, etc. The most commonly used is the door interlock switch of the robot unit, which can be turned on to suspend the robot. When customers use it, they need to configure the corresponding switch signal in the robot control system, and correspond the I/O port connected by the hardware to the dedicated signal. Please refer to the I/O settings in this manual.

#### 2.3.4.2 Safety Monitoring

Emergency stops and safety guards are monitored so the controller can detect any failures and the robot stops until the problem is resolved.



#### 2.3.4.3 Built-in Safety Stop Function

The controller continuously monitors hardware and software functions. If any problems or errors are detected, the robot will stop, operating until the problem is resolved.

2.3.4.4 Limiting Robot Work Range

Robot operating range can be limited by mechanical stops, software functions, or a combination of both. Please refer to the documentation related to the functions of this manual for how to configure the robot system.

#### 2.3.5 Safety Considerations For Manual Mode

2.3.5.1 Introduction to Manual Mode

In manual mode, the movement of the manipulator is under manual control. The three-position actuator must be pressed to start the motor of the manipulator, that is, to allow movement. Manual mode is suitable for creating and verifying programs and debugging the manipulator system.

#### 2.3.5.2 Operating Speed

1. The movement of the manipulator in manual deceleration mode is limited to 250 mm/s (this can be set by setting whether the function is enabled or not).

2. When operating the manipulator in manual mode, the operator is very close to the manipulator. Manipulating industrial manipulators can be dangerous and should therefore be done in a controlled manner.

3. In manual mode, the manipulator moves at a preset speed, but must be under manual control. Manual mode should only be used when all personnel are outside the safe protected space, and operators must be specially trained to be aware of potential hazards.

#### 2.3.5.3 Three-Position Actuator

1. In manual mode, the robot's motor is activated by a three-position actuator on the handheld teaching pendant. In this way, the robot can only move by pressing the actuator.

2. This "stop-move" function is also applicable when stepping the debugging program in manual full speed mode.

3. The three-position actuator is uniquely designed, you must press the button halfway to start



the robot motor. If the button is not pressed or fully pressed, the robot will not move.

#### 2.3.6 Safety Considerations For Automatic Mode

2.3.6.1 Introduction to Automatic Mode

1. Automatic mode is used to run robot programs in production.

2. In automatic mode, the safety function of the three-position actuating device is disabled so that the manipulator can move without human intervention.

#### 2.3.6.2 Interference in Treatment Process

1. Process disturbances affect not only a specific manipulator unit, but the entire system chain, even if the problem is caused by a specific unit.

2. The chain of events may result in unknowable hazardous operations when operating a single manipulator unit, so special attention should be paid to this interference. Personnel performing all remedial actions must be familiar with the entire production line, not just the failed manipulator.

## **3 Install Wiring**

#### 3.1 Installation Site and Environment

#### **3.1.1 Installation Environment Requirements**

The installation site before installing the electrical control cabinet must meet the following conditions:

1. The ambient temperature during operation should be between 0° and 45° C (32° to 113° F).

- 2. The handling and maintenance period should be -10° to 60° C (14° to 140° F).
- 3. The humidity must be lower than the dew point (relative humidity below 10%).
- 4. Places with less dust, dust, oil fume and water.
- 5. No flammable products and corrosive liquids and gases are allowed in the operation area.

6. The vibration or shock energy of the electrical control cabinet is small (the vibration is below 0.5G).

7. There should be no large electrical noise sources nearby (such as Tungsten Inert Gas (TIG) Welding, etc.).

8. There is no potential hazard of collision with mobile equipment such as forklifts.



## **3.1.2 Installation Location Requirements**



1. The **electrical control cabinet** should be installed outside the robot's action range (outside the safety bar).

2. The **electrical control cabinet** should be installed in a position where the robot can be seen clearly.

3. The **electrical control cabinet** should be installed in a position that is convenient for opening the door for inspection.

4. Install the **electrical control cabinet** at least 500mm away from the wall to keep the maintenance channel open.

## 3.1.3 Precautions for Installation and Wiring



1. The system must be electrically grounded. If the equipment is not grounded, a fire alarm or electric shock will occur, resulting in personal injury.

2. Before the system is grounded, the power should be turned off and the main power switch should be locked. Otherwise, electric shock and personal injury may be caused.

3. Do not touch any substrate in the electrical control cabinet within 5 minutes after the power is cut off. Capacitors will store electrical energy after the power is cut off, so be careful whenever you operate the substrate. Failure to follow this warning may cause electric shock.

4. If the door is not closed, the power supply cannot be turned on, that is, the safety interlock device prevents the power supply from being turned on. Otherwise, a fire alarm or electric shock



may be caused.

5. During the wiring period, the electrical control cabinet is in emergency stop mode, and the user is responsible for anything that happens. Once the wiring is completed, an operation inspection is required. Otherwise, personal injury or mechanical failure may be caused.



6. Do not climb on top of the electrical control cabinet, otherwise it may cause personal injury or mechanical failure.

7. Wiring must be carried out by authorized staff. Incorrect wiring may cause fire or electric shock.

8. Please wire according to the rated capacity specified in the manual. Incorrect wiring may cause fire alarm or mechanical damage.

9. Confirm that the wiring of each circuit is safe and firm. If the circuit wiring is not firm, it will cause a fire alarm or electric shock.

10. Do not touch the substrate directly with your hands. Integrated circuit (IC) substrates may fail due to static electricity.

## **3.2 Controller Installation Instructions**





3.2.1 Installation Mode of Main Control and I/O Unit









# 3.2.2 Main Control Unit Wiring Description

3.2.2.1 Interface Description of Main Control Unit



Interface Name	Description		
+ 24V (must be connected)	Power supply to 24V		
GND	DC power ground		
PE	Connect reliability grounding and shielded terminals		
TP (to teach pendant) (must be connected)	The other end is connected to the handheld box network port, the default IP: 192.168.100.3		
Ecat (must be connected)	Connect with EtherCAT driver cable (standard, network cable interface)		
LAN 1 (optional)	Default IP : 192. 168.101.3		
LAN 2 (optional)	Default IP : 192. 168.102.3		
LAN 3 (optional)	Default IP : 192. 168.103.3		
RS 232/ CAN /485 combination port (optional)	For external communication		
USB 2.0 / USB3.0 (optional)	External USB keyboard, mouse or U disk		
HDMI (optional)	External HDMI interface display		



#### 3.2.2.2 RS-232/485/ CAN Interface Definition



1	VCCS_CAN	CAN power supply 24V	
2	RS232_RX	Serial port 232 communication receiving	
3	CAN_L	CAN low level (the new version of the controller cancels CAN and designs the CAN interface on the I/O module)	
4	RS485-	Serial port 485 communication low level	
5	GND	Ground	
6	CAN_GND	CAN grounding (the new version of the controller cancels CAN and designs the CAN interface on the I/O module)	
7	RS232_TX	Serial port 232 communication sending	
8	CAN_H	CAN high level (the new version of the controller cancels CAN, and the CAN interface is designed on the I/O module)	
9	RS485+	Serial port 485 communication high level	

#### 3.2.2.3 Controller Status Indicator Description

#### 3.2.2.3.1 Status Indicator HD:

Displays the read and write status of the hard disk. If the status indicator light is on, it indicates that the hard disk write operation is in progress. The status indicator light is controlled by the hardware system of the controller and is not operated by the upper-level program.

3.2.2.3.2 Status Indicator RUN:

The status indicator RUN remains normally on after power on (EtherCAT driver is not loaded.) When the EtherCAT driver starts, the driver will control the status indicator. The status indicator RUN under EtherCAT drive operation displays the status as follows:

1. The driver is in an idle state (waiting for the application to request the master:) on for 1s + off for 1s, alternately, that is, slow flash.

2. Bus communication is disconnected: on 300ms + off 200ms + on 300ms + off 1200ms,



alternately, that is, fast flash twice.

3. The application requests the master station to enter the OP mode (PDO interactive

communication:) on 100ms + off 100ms, alternately, that is, fast flash.

3.2.2.3.3 Status Indicator EC:

The status indicator EC remains normally on after being powered on. After the EtherCAT interface program is started, the status indicator will be automatically operated. In the automatic operation mode:

1. **System not registered**: on 200ms + off 200ms + on 800ms + off 800ms, alternately, that is, fast flash + slow flash.

2. **Network disconnection or abnormal network interface card status**: on 200ms + off 200ms + on 200ms + off 1400ms, alternately, that is, flash twice.

3. The master request is busy (the master is scanning the slave): on for 1s + off for 1s, alternately, that is, slow flash.

4. **Master Station Ready (PDO communication established)**: on 100ms + off 100ms, alternately, that is,fast flash.

5. Other states (during the configuration of the master station): on 200ms + off 200ms + on 200ms + off 200ms + on 200ms, alternately, that is, the application exits by flashing 3 times, after that, the status indicator ERR display is uncertain; it may be always on, or it may be often off.

#### 3.2.3 Teaching Pendant Installation Wiring



Figure 3 Teaching Pendant Aerial Insertion



1	Red	24V+	Connect 24V power supply +
2	White & Red	0V	Connect 24V power supply 0V
3	Black	PE	Grounding
4	Green	EMG1-1	Emergency stop terminal 1
5	Black & Green	EMG1-2	Emergency stop terminal 1
6	Blue	EMG2-1	Emergency stop terminal 2
7	Black & Blue	EMG2-2	Emergency stop terminal 2

Definition of External Cable of Teach Pendant:

(The specific line number shall prevail)

The hand-held box must be connected with 24 V power supply wiring, and the emergency stop terminal can be selected and used according to the needs. The emergency stop terminal provides two sets of wiring output, and connects the emergency stop signal of the hand-held teaching pendant. It is normally closed by default. Press the emergency stop button of the hand-held teaching teaching pendant to open it.

#### **3.2.4 IO Module Wiring Definition**



Ethercat dedicated to welded robots from the station I/O module				
IO type	Num. of channels	Signal type	Signal level	Remark



DI	16	compatible PNP/NPN	0V/24V,500mA	"1"signal level:15-24VDC;"0"signal level,0-5VDC
DO	16	NPN	0V,500mA	"1"signal level: 24VDC;"0"signal level,max 1.5VDC,10kΩ load
AI	2	voltage	0-10V	single grade,12BIT,two-wire system, input resistance 500kΩ
AO	2	voltage	0-10V	single grade,12BIT,two-wire system, min. load resistance 1kΩ,max. current 10mA
CAN	1	signal	5V	CAN-5V,CAN-L,CAN-H,CAN-GND

# 4 Hand-held Teach Pendant

This chapter describes the layout and key functions of the robot handheld teach pendant.







# 4.1 Key Function of Teach Pendant

No.	Name	Кеу	Function		
	Emergency Stop		Press this button and the servo power will be cut off.		
			After cutting off the servo power supply, the [servo		
			ready indicator] of the hand-held teach pedant is off,		
			and the emergency stop information is displayed on		
			the screen.		
			After the alarm is removed, the emergency stop		
1		ET TRA	button can be opened, and the servo power can be		
T		E	continued after the emergency stop button is opened. After this button is pressed, the servo power will not		
		1.1233			
		be turned on. Method of opening the [emerge rotate clockwise until the emerge up. With the sound of "click", it	be turned on.		
			Method of opening the [emergency stop button]:		
			rotate clockwise until the emergency stop button pops		
			up. With the sound of "click", it indicates that the		
			emergency stop button has been opened.		

17



			Press this button and the robot will stop running.
		0	This button can be used in any mode.
			In teach mode: When this button is pressed, the light
			will be on. At this time, the robot cannot perform axis
2	Dauca		operation.
2	rause		In play mode: Press this button one time to enter the
			pause mode. At this time, the pause indicator lights up
			and the robot is in the pause state. Press the [Start]
			button on the hand-held teach pedant to make the
			robot continue to work.
			Press this button and the robot starts play.
			This indicator lights up when play mode is running.
	Start		Start the robot by a special input start signal.
			This indicator lights up when play is running.
3			This indicator lights up when the robot starts a play
			run from a dedicated input start signal.
			The mode knob must be set to play mode before
			pressing this button; Make sure the[servo ready
			indicator]is on.
			Teach mode,Play mode, and remote mode
			TEACH: Teach mode
			Axis manipulation and editing can be done with a
			hand-held teach pedant (in this mode, working signals
л	Mode		from external devices are invalid).
4	WIDUE		PLAY: play mode
			You can run the program after teaching it.
			REMOTE: Remote mode
			The external TCP/IP protocol and IO can be used to
			start the teaching program.



			Pefere exercise the mode line house he set in Teach		
			Before operation, the mode knob must be set in leach		
			mode $\rightarrow$ click the [Servo Ready] key on the hand-held		
			teach pedant (the indicator light of [Servo Ready] is		
			blinking) $ ightarrow$ gently hold the three-stage switchand the		
5	Three-stage	12	servo power is switched on (the indicator light of		
	Switch		[Servo Ready] is steady on).		
		6. J.	At this time, if the grip, the servo power cut off. If you		
			do not press the "Servo Ready" button on the		
			hand-operated teach pedant, the servo power will not		
			be switched on even if you gently hold the "three-step		
			switch".		
	Hand Pulse Knob		Rotate the scroll up and down to switch the		
6			drop-down box contents, project/program and		
			program line. Press down to confirm the selection.		
			Press this key and the servo power will be switched		
			Press this key and the servo power will be switched on effectively.		
			Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency		
			Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch		
			Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power.		
			Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this		
7	Serve Ready	Servo ON	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power		
7	Serve Ready	Servo	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power will be switched on.		
7	Serve Ready	Servo	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power will be switched on. In teach mode, after pressing this key, the indicator		
7	Serve Ready	Servo	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power will be switched on. In teach mode, after pressing this key, the indicator light of [Servo Ready] flashes. At this time, press to the		
7	Serve Ready	Servo	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power will be switched on. In teach mode, after pressing this key, the indicator light of [Servo Ready] flashes. At this time, press to the 1 <sup>st</sup> stage of the [three-step switch] on the teach		
7	Serve Ready	Servo	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power will be switched on. In teach mode, after pressing this key, the indicator light of [Servo Ready] flashes. At this time, press to the 1 <sup>st</sup> stage of the [three-step switch] on the teach pedant. The indicator light of [Servo Ready] lights up		
7	Serve Ready	Servo	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power will be switched on. In teach mode, after pressing this key, the indicator light of [Servo Ready] flashes. At this time, press to the 1 <sup>st</sup> stage of the [three-step switch] on the teach pedant. The indicator light of [Servo Ready] lights up, indicating that the servo power is connected		
7	Serve Ready	Servo	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power will be switched on. In teach mode, after pressing this key, the indicator light of [Servo Ready] flashes. At this time, press to the 1 <sup>st</sup> stage of the [three-step switch] on the teach pedant. The indicator light of [Servo Ready] lights up, indicating that the servo power is connected.		
7	Serve Ready	Servo	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power will be switched on. In teach mode, after pressing this key, the indicator light of [Servo Ready] flashes. At this time, press to the 1 <sup>st</sup> stage of the [three-step switch] on the teach pedant. The indicator light of [Servo Ready] lights up, indicating that the servo power is connected.		
7	Serve Ready Upshift	Shift	Press this key and the servo power will be switched on effectively. When the servo power is cut off due to emergency stop or other reasons, use this key to effectively switch on the servo power. In play mode and remote mode, after pressing this key, the indicator light will be on and the servo power will be switched on. In teach mode, after pressing this key, the indicator light of [Servo Ready] flashes. At this time, press to the 1 <sup>st</sup> stage of the [three-step switch] on the teach pedant. The indicator light of [Servo Ready] lights up, indicating that the servo power is connected. <b>Can be used with other keys.</b>		



			Press this key to open the system application menu	
	Мори	Menu	Program: program management, file editing	
			Variables: global variable, global location, global	
0			increment, project variable, project location, project	
			increment	
5	Ivienu		Robot: coordinate system management, zero	
			calibration, exception processing	
			Settings: Permission management and system	
			parameters	
			Custom: Process	
10	Chain		Assist key, used in conjunction with other keys. This	
10	Chain	ain Ctrl	key must be used in teach mode.	
			Press this key to open the status display window.	
	Fn1	tus play	View the robot's current position, digital volume IO,	
11	Status		analog volume, multitasking, speed, variables,	
	Display		workspace and some process parameters.	
	Fn2 Floating Menu		Press this key to open the floating menu	
12		Fn2	The floating menu can switch coordinate system,	
12			switch play mode, switch robot/external axis, switch	
	Ivienu		speed and part of the process menu.	
			Key to operate each axis of the robot.	
			This key group must be used in Teach mode.	
			Multiple axes can be operated by holding down two or	
			more keys. The robot runs according to the selected	
13	Δχίς Κργ	2/5 (2)(7) as ( 2.5)	coordinate system and manual speed. Before	
15	AND RCy		operating the axis, please confirm whether the set	
			coordinate system and speed are appropriate. Before	
			operation, it is necessary to confirm that the [Servo	
			Ready Indicator] on the hand-held operation teach	
			pendant of the robot is on.	
14	Forward	BWD DWD	When the servo power is turned on, the robot will run	
14		FWD	step by step (in reverse direction) according to the	



	Backward		programming points trajectory once this key is
			pressed.
			This key must be used in Teach mode.
			The key to set the running speed of the robot in
			teaching mode.
	Creased Law		The low speed gears are 1%, 2%, 5%, and +/-5% each
15	Speed- OI	V- V+	time the key is pressed. The set speed is displayed in
	speed-		the status bar.
			[Upper] + [V+] / [V-] can adjust the speed under play
			mode.



## 4.2 Teach Pendant Interface



Figure 7 Teach Pendant Interface



## Menu, button and identification in the interface:

	Each menu and submenu will be
	displayed in the system
	application menu. Press the
	"Menu" key on the handheld
- IHY	teach pedant or click the LOGO
	button in the upper left corner of
	the interface to display the
	system application menu.
	Display current servo;
ServoOff	Operation mode;
	Coordinate system status.
	Display the number of the current
	tool coordinate system or the
	piece coordinate system;
T3P5 5 50	Display speed, the former is the
	speed of Teach mode, the latter is
	the speed of Play mode
	Display execution cycle mode
🚐 shangxia · main	(cycle, single, single step), current
	project name and program name
	Teach pedant connection state;
	Current permissions;
⇒ L° 定	Current coordinate system;
	Other process states
	You can use this key to view log
	and historical alarm information.
	Error and operation prompt or
	alarm, no alarm display
************Standby**********	"Standby", display movement
	speed
Clear	Key for clearing alarm



						Common application toolbar (can
Project	Program	C Variable	© G Position	R Variable	2 P Position	be customized)
Project	Program	G_Variable	G_Position	P_Variable	P_Position	be customized)

# 4.3 System Application Menu

Program					
Project	Program		•		
Variable					-
Xariable	C Position	C Increment	R Variable	P Position	P Incremen
abot Posit	G_POSICION	d_increment	F_Variable	P_POSICION	F_incremen
	<del>ا</del> ل		47	æ.	1
Coordinate	e HomePoi	nt Alarm	SafePoint	BackG Task	TCP
888	8	10			
Drives	EcatConfi	g Remote			
Setting					
8	0				
System	Setting	IOConfig			
e chnology					
?	\$	-21-0-	er,	TVV	-
Blank	Ext Axis	LaserWeld	Weld	WeldPro	Multipass

## 4.3.1 Common Toolbar Customization

The system menu bar has two operation modes. Click  $\bigcirc$  or  $\bigcirc$  to switch between them. In the drag mode, you can select common interface ICONS and drag them to the common toolbar for quick interface switching.

Icon Function Description
---------------------------



	Click Mode	In this mode, click other small ICONS on the menu bar to enter
		the corresponding interface
	Drag Mode	In this mode, you can drag a small menu bar icon to the toolbar
		of a common application
		Operation method:
		1. Switch to drag mode
		2. Hold down the icon and drag it to the toolbar of a common
		application to release the icon

# 4.3.2 Description of Menu Options

lcon	Name	Function
		1. Create the new project
		2. Project management: import, export, rename, save as, delete
		the selected project
	Project	3. New program: create a new program under the selected
Project	Management	project
		4. Program management: import, export, rename, save as, delete
		the selected program
		5. Open the program
ES.	Program	
Program	Editing	Edit the selected program under the current project.
x	Global	Global numeric variables and global strings can be used in
G_Variable	Variable	different projects for program editing.
0	Global	The position variable can be calibrated, and can be used in
G_Position	Position	different projects for program file editing.
0	Global	Can write positional increments, can be used in different projects
G Increment	Increment	for program file editing.
	Ducient	
Nacia bla	Project	Project value variables and project strings can only be edited and
P_variable	Variable	used in the currently opened project



2	Project	Position variables can be calibrated and can only be edited and
P_Position	Position	used in the currently opened project
Ø	Project	You can write positional increments, which can only be edited and
P_Increment	Increment	used in the currently open project
Coordinate	Coordinate System Management	Calibrate and modify the world coordinate system, tool coordinate system and piece Coordinate System. Set the current coordinate system, and the corresponding serial number is displayed in the status bar at the upper right corner of the interface
æ	Zero Point	Calibrate the zero point of the robot, manually modify it, and clear
HomePoint	Calibration	the absolute encoder
[] Alarm	Alarm	Axis Simulation Setting Limit switch of Axis motion
SafePoint	HOME Coordinate	Set home position coordinates (return to zero)
RackG Task	Backstage Task	Background task setting, reservation function
8 System	System Management	Set administrator permissions. Different permissions have different operation contents. Version Information
Setting	Setting	Settings: System Parameters, Hardware Parameters, Joint, External Axis, Cartesian, Planning Parameters, DH Parameters
7 Blank	Undefined	Process parameter setting

# 4.4 Status Bar

# 4.4.1 Servo Display Status

F	Servo off
4	Servo on



## 4.4.2 Working Mode

Display the working mode of the robot, and switch it by the mode knob on the teaching pendant.

ſ	Teach: The robot is in teach mode.
0→¢ ¢⊷0	Play: The robot is in play mode.
Ç,	Remote: The robot is in remote working mode.

## 4.4.3 Coordinate System

Displays the selected coordinate system, selected from {coordinate system} in the floating menu of the interface. The floating menu pops up using the [Fn2] key on the hand-held teach pedant.

Ì	Joint coordinate system
Ţ	Robot coordinate system
Ì.	piece Coordinate System
Ì.	World coordinate system
Ì¥,	Tool coordinate system

## 4.4.4 Current Tool No. and Workpiece No.

In order to facilitate the user to determine the serial number of the tool (workpiece) currently in use, a tool (workpiece) coordinate system data queue with 32 elements is used inside the program. The default number 1 is that no tool (workpiece) is used, and 2--32 coordinate system queues element is an editable queue element.

## 4.4.5 Speed

Display the current speed by pressing the [V+] or [V-] key on the hand-held teach pendant. The former is the speed of teach mode and the latter is the speed of play mode.



## 4.4.6 Teaching File play Execution Mode

9 <b>—</b>	Infinite cycle: the teaching program is executed in a non-stop cycle
ι <u>Ξ</u>	Single execution: only perform the teaching program once
۶	Single-line execution: only one line teaching program is executed at a time.

## 4.4.7 Current Permissions and Network Status

#### 4.4.7.1 Permission Level

Change in the System Application Menu - Permission Management



#### 4.4.7.2 Network Status



## 4.5 Floating Menu

The floating menu pops/closes by using the [Fn2] key on the hand-held teach pedant with quick switching function.

Level 1	Level 2	Function
E		<ol> <li>Switch to joint coordinate system</li> </ol>


	2. Switch to robot		
	coordinate system		
	3. Switch to piece		
	Coordinate System		
	4. Switch to world		
	coordinate system		
	5. Switch to tool coordinate		
	system		
	Infinite cycle		
	Single execution		
play program execution mode	Single-line execution		
<b>T</b> ¢	Switch to robot axis (hold		
	[J1] - [J8] represents robot		
	axis)		
jog axis switch	Switch to external axis (hold		
	[J1] - [J8] for external axis)		
Speed percentage switching	switch the speed percentage of the current mode		



# 4.6 Robot Status and Alarm History Viewing

#### 4.6.1 Robot Status

When there is an error message or alarm, the middle display area will turn yellow or red and display the error alarm information. Press the {clear} key on the right to clear the error.

## 4.6.2 Robot Alarm History and Action Log View

Status	Description						
Normal	When the robot is in normal operation state, it can operate the servo motion on the robot and execute the teaching program.						
Servo	*********************************         Clear						
Ready	The robot is in servo-powered state						
In	! ************************************						
execution	The robot is moving or performing an instruction program, and the following number						
	indicates the current linear velocity at the end of the robot						
	1 A "TCP socket error (Connection timed out) Clear						
Yellow	The robot is in the alarm state, which will not lead to servo down or emergency stop						
Alarm	of the robot. The operator needs to check according to the alarm content and rule						
	out the alarm cause						
	emergency stop     Clear						
Red Alarm	The robot is in the serious alarm state, which will cause the robot to stop abruptly						
	and get off the private server. Before the alarm is lifted, the robot cannot enter the						
	Servo Ready state						

You can view all alarm information records and interface log through the left button (as shown

below).

ltem	Description
------	-------------



	Record history interface action and alarm				
	Alarm History Interface Log				
	[2023-03-21 14:38:14] "Change to teach mode, and current file is 调试j7 at line 1"				
Interface Log	[2023-03-21 14:38:14] "Change work mode[Play->Te ach]"				
	[2023-03-21 14:38:13] "Change work mode[Play->Remote]"				
	[2023-03-21 14:38:13] "Change work mode[Play->Remote]"				
	Delete				
	Record system alarm history				
	Alarm History Interface Log				
Alarm	[2023-03-21 14:39:47.882][softplc] 4 50000 Emergency stop button is pressed				
History	[2023-03-21 14:39:47.878][softplc] 4 50000 Emergency stop button is pressed				
	[2023-03-21 14:34:13.316][softplc] 4 50050 TP is disconnected				
	[2023-03-21 14:33:32.195][softplc] 4 50050 TP is disconnected				

# **5 Get Started Quickly**

#### 5.1 Servo Power On



When opening the main power switch on the electrical control cabinet, make sure that there is no person within the robot action range. Ignoring this warning may result in personal injury due to accidental contact with the robot. If any problem occurs, immediately press the emergency stop button, which is located on the upper left of the front door of the electrical control cabinet.

#### 5.1.1 Switch on the Main Power Supply

Switch the main power knob on the electrical control cabinet to the ON position, the power indicator displays as green, now the main power is turned on.





Figure 8 electrical control cabinet Panel

#### 5.1.2 Switch on the Servo Power Supply

# The servo power-on procedure is different under the teach mode, the play mode, and the remote mode.

1. In teach mode:

Press the [Servo Ready] button on the hand-held teach pendant, and the [Servo Ready] indicator is flashing; press the 1<sup>st</sup> stage of the [Three- stage Switch] on the back of the hand-held teach pendant, and the [Servo Ready] indicator on the hand-held teach pendant is always on, indicating that the servo power is on.

2. In play and remote modes:

Release the [Servo Ready] button on the hand-held teach pendant, and the [Servo Ready] indicator light on the hand held teach pendant is always on, indicating that the servo power is on.

#### 5.2 Servo Power Cut Off

#### 5.2.1 Cut Off the Servo Power Supply

The servo power cutoff procedure is different under the teach mode, the play mode, and the remote mode.

1. In teach mode:

Release or press to the 2rd stage [Three-Stage Switch] on the back of the handheld teach pendant, and the [Servo Ready] indicator on the handheld teach pendant goes out, indicating that the servo power supply is cut off.

2. play and remote mode



Press the [Servo Ready] button on the handheld teach pendant again, and the [Servo Ready] indicator on the handheld teach pendant goes out, indicating that the servo power supply is cut off.

3. Press the emergency stop button on the panel of the electrical control cabinet

Once the servo power supply is cut off, the braking device is activated and the robot is braked and cannot perform any further operation. Emergency stop can be entered at any time in any mode (teach mode, play mode or remote mode).

#### 5.2.2 Cut Off the Main Power Supply

First cutting off the servo power then cut off the main power.

Switch the main power knob on the electrical control cabinet to the OFF position to cut off the main power supply, as shown in the figure below:



Figure 9 Rotary Switch

#### 5.3 Selection of Coordinate System

In teach mode, the robot motion coordinate system is selected from the floating menu.

#### 5.4 Manual Speed Adjustment

#### In Teach mode, modify the motion speed of the JOG robot:

Press the [V+] key or [V-] key on the hand-held teach pedant. Each time, the manual speed +/-5,will be confirmed by the speed display in the upper right corner of the status area. (The first value is the teaching speed)

# 5.5 Axis Operation

In teach mode, each axis of the robot can be moved to the desired position by pressing the **axis keys**, and the motion of each axis changes according to the selected coordinate system.





6r robot rotation direction (overall)

Each axis can only be moved when the **axis key** is pressed.



1. Before operating the robot, please confirm that the emergency stop button can work normally: Press the emergency stop button on the electrical control cabinet, the servo indicator light goes out and alarm appears on the teach pendant, indicating that the emergency stop key is normal. If the robot cannot be stopped in an emergency, it may cause mechanical damage.

2. The following cautions shall be observed when performing teaching work within the robot motion range:

- Always observe from the front of the robot
- Always operate according to the pre-established operating procedures
- Always have an idea of avoiding the robot in case of unexpected actions
- Make sure you have a fallback in case of an emergency

Improper and careless handling of the robot can cause injury.



3. Before performing the following operations, make sure that there are no people in the robot's range of motion and that you are in a safe position area.

- Switch on the power supply of the electrical control cabinet.
- When operating the robot with a hand-held teach pendant.
- On play motion
- When remote operation

If the robot collides with any person who enters the motion range, will result in personal injury.Perform the following inspection steps before teaching the robot, correct any problems found, and verify that all other necessary work has been completed.

- Check whether the motion of the robot is abnormal;
- Check if the insulation and covering of the external cables damage.

After the servo power is turned on (press the [Servo Ready] key, hold the [Three-Stage Switch], and the servo indicator light is always on), press the operation key of each axis on the handheld teach pendant to make each axis of the robot generate the required action. The above illustration shows how each axis behaves in the axis coordinate system.

Please pay attention to the joint movement speed status before operating the robot, and adjust it to the appropriate speed by pressing the high/low speed key.

#### 5.6 Flush

The flush function can only be used in teach mode.

The alignment function is to automatically align the rotation component of the rotation around a certain axis to an integer multiple of 90 degrees, such as  $-180^{\circ}$ ,  $-90^{\circ}$ ,  $0^{\circ}$ ,  $90^{\circ}$ ,  $180^{\circ}$ , etc. The constraint is that the Euler angles must be within 15 degrees.

When the angle is less than 15 degrees, press the [Ctrl] key + [A+] key, and the rotation component around the X axis of the selected coordinate system is aligned to an integer multiple of 90°; [Ctrl] key + [B +] key The rotation component of the selected coordinate system around the Y axis is equal to the integer multiple of 90°; the [Ctrl] key + [C+] key is used to align the rotation component of the selected coordinate system around the Z axis to an integer multiple of 90°.

Finally, select the robot motion coordinate system through the floating menu to confirm whether



it has reached the position that is an integer multiple of 90  $^\circ$ 

# 5.7 Return to Zero position

In teach mode, set the original position coordinates, after the servo on, press the [Ctrl] key+

[Forward] key can move to this point.

This point should be recorded as a position that the robot can safely reach from any position.

1 In "Touch Me	da" afthar Capin on		
Press +[	FWD1. the robot can m	ove to safety point	t?
2, User must co	onfirm current point po	siton can be reach	ned safety.
J1	0.0000	J5	0.0000
J2	0.0000	J6	0.0000
J3	0.0000	J7	0.0000
J4	0.0000	J8	0.0000

If the HOME point position is not set, it will default to the factory zero point position of the robot.

# **6 Engineering Management Interface**

Select **D** from the main menu or click "Project Management" on the common toolbar to enter the project management interface.





#### 6.1 Description of Robot Engineering Structure

The robot program is based on the project, each project can have multiple teaching files, and each project contains variables that can only be used by the teaching files within the project. Take the project named "test" as an example. The following figure shows the structure of the teaching file main and other teaching files can be executed.

The difference between the teaching file main and other teaching files: Other teaching files can be called in the teaching file main; other teaching files can call each other, but the teaching file main cannot be called.



	Teaching file main				
	Note: When creating a project, the project will automatically add a main				
	program named main, this program cannot be deleted, renamed.				
	Other teaching files				
Engineering	Note: Users need to create their own. Subprogram name specification:				
Teet	Contains only alphanumeric underscores and cannot begin with a digit				
TESL					
	Engineering variable, engineering positional variable, engineering				
	incremental positional variable				
	Note: When creating a project, each project will automatically create these				
	three types of variables. These variables can only be called by the teaching				
	file under the project				

# 6.2 Engineering Operations















# 7 Program Editing Interface

Click on the menu bar or click "File Editing" on the common toolbar to enter the program editing interface





Figure 11 Program Editing Interface

# 7.1 Currently Open Programs

The name of the currently opened program is displayed in the status bar. For example, *test01: main, test01* is the project name, and main is the name of the teaching file in the project.

#### 7.2 History Program

The interface will display the names of the five files that have been opened recently.





Item	Description		
1. Quickly switch	Click the corresponding row in the left column to quickly switch to the		
the history	corresponding program. The green one is the current open program.		
program			
2. Delete history	Click corresponding $X$ logo to the two columns on the right to delete the		
records	program history of the corresponding row		

# 7.3 Program Page Turning

Icons	Description
~	Get to the top
$\checkmark$	Page up
$\sim$	Page down
	End of program

# 7.4 Program Editing

Function	Description









#### 7.5 Extension Bar

Click corrected operation bar. The functions of each button in the extended bar are described as follows.

lcon

Description



Ξ	Program display font reduction							
+	Program display font enlargement							
Cut	Cut Selected Rows							
Сору	Copy Selected Rows							
Raste	Paste the program to the end of the selected line							
Muti	Batch modify, batch modify the speed and bl of motion instruction							
	1. Click the icon							
	L. CHICK THE ROTH							







	1 PROCEDURE 2 Movj P=#P1 V=20% BI=0%;//; 3 Movj P=#P2 V=20% BI=0%; 4 ENDPROCEDURE		II: mov Test cc Contr	i01: e e of ×			
	View and Modify the Variable						
	Variable No		#P2	•			
	Position	of Robot	Position of EXT Axis				
	Coordinate	0.0000	Ext1	B C D	Record the robot's current		
	J2	0.0000	Ext2	0.0000	nosition to the position-type		
	J3	0.0000	Ext3	0.0000			
	J4	0.0000	Ext4	0.0000	variable, and the coordinate		
	J5  6	0.0000	Ext6	0.0000	system is the current JOG		
	J7	0.0000	Ext7	0.0000	coordinate system		
	J8	0.0000	Ext8	0.000			
	Modify	Movel	ToPoint Record	Close			
Movi	Quick Insert MovI: 1. In the servo on state, click this button to add a position point at the end of the engineering position variable. The position of this point is the current position of the robot, and the coordinate system is the current jog coordinate system. 2. At the same time, a MovI instruction is inserted in the currently selected line of the teaching file. The target location of the instruction is the engineering location variable recorded in 1						
Movj	Quick insert Movj: The operation and steps are the same as above, and a Movj motion command will be inserted						
Mvc2	Quick insertion Mvc2: The operation and steps are the same as above, and a Movc2 motion command is inserted, that is the middle point of the arc						
Mvc3	Quick insertion Mvc3: The operation and steps are the same as above, and a Movc3 motion command will be inserted, that is the arc target point.						

# **8 Variables**

# 8.1 Global Variables

Global variables, including global position variables (#GP), global incremental positional variables (#GIncP), global numeric variables (#GVar), and global string variables (#GStr), are accessible to all teach files in the project.

# 8.1.1 Global Position Variables

The global position points are called in the teach file as #GPX (X indicates the sequence number

1-1000)



Item	Operating Instructions						
		#GP #GP1 Record the coordinate type to this point					
		Position	of Robot	/			
	2.Select coordinate system	Annotation	注释				
	type	Coordinace	ACS	-			
		Posture	0:LS+UP+UW	Tool No	1		
	If IIDs and the constituets true to this se	J1	0.0000	J5	90.0000		
	is selected the coordinate system of th	is J2	0.0000	J6	0.0000		
	point is the current JOG coordinate system of the	em.	0.0000	J7	0.0000		
1. Position points	If not selected, the unselected coordina	ite j4	0.0000	J8	0.0000		
record	system in the coordinate system option		of EXT Axis 3.Se	rvo on, clic	k 'Record'		
	the record.	EXT Axis Gro	оир 🔽 А 🗌 В 📃 С	D			
		Ext1	0.0000	Ext5	0.0000		
		Ext2	0.0000	Ext6	0.0000		
		Ext3	0.0000	Ext7	0.0000		
		Ext4	0.0000	Ext8	0.0000		
	1. Select the po number	osition poi	nt	/1000	Copy Paste Record		
		#GP #GP1	Record	I the coordinate typ	e to this point		
		Position o	of Robot				
		Annotation	注释				
		Coordinate	ACS				
	3. Manually edit values	Posture	0:LS+UE+UW	Tool No	1		
		J1	0.0000	J5	90.0000		
		J2	0.0000	J6	0.0000		
	4. Click the Confirm button	در ۱۹	0.0000	J/	0.0000		
2. Manually modify	to complete the		0.0000	J8	0.000		
a location point	modification	Position of EXT Axis 2. Click the Modify button					
	K	EXT Axis Gro	ир 🔽 А 🗌 В 📃 С				
		Ext1	0.0000	Ext5	0.0000		
		Ext2	0.0000	Ext6	0.0000		
	1. Select the sequence	Ext3	0.0000	Ext7	0.0000		
	number of the variable that	Ext4	0.0000	Ext8	0.0000		
	you want to modify			00	Copy Paste		
			1/	1000	Record		







#### 8.1.2 Global Incremental Location Points

The global increment position points are called in the teach file as #GIncPX (X indicates the sequence number 1-1000): Global incremental position points operate in the same way as global position points, except that they do not have the function of recording the current position and moving to a point.

#### 8.1.3 Global String Variable

The global string variable is called in the teach file as #GStrX (X indicates the sequence number 1-300):

No	Dat	ta	
#GStr 286			
#GStr 287			
#GStr 288			
#GStr 289			
#GStr 290			
#GStr 291			
#GStr 292			
#GStr 293			
#GStr 294			
#GStr 295			
#GStr 296			
#GStr 297			
#GStr 298			
#GStr 299			
#GStr 300			

Click 💾 to save the modification after modifying the variable value.

#### 8.1.4 Global Numeric Variables

The global numeric variables are called in the teach file as #GVarX (X indicates the sequence number 1-300):



No	Data	Note
#GVar 1	3.0000	
#GVar 2	100.0000	
#GVar 3	4.0000	
#GVar 4	1.0000	
#GVar 5	0.0000	
#GVar 6	0.0000	
#GVar 7	0.0000	
#GVar 8	4.0000	
#GVar 9	0.0000	
#GVar 10	1.0000	
#GVar 11	4.0000	
#GVar 12	1.0000	
#GVar 13	0.0000	
#GVar 14	7.0000	
#GVar 15	0.0000	

Click to complete the modification after modifying the variable value.

#### 8.2 Engineering Variables

Each project has a set of project variables that can only be accessed by the teach file under that project. Including engineering position variable (#P), engineering increment position variable (#IncP), engineering value variable (#Var), engineering string variable (#Str).

Before viewing project variables, first you must open a project. The currently opened project can

be obtained in the status bar.	test01 : main	For example, the currently
selected project is test01. In this case, the	e variables displayed in t	the project variable interface are
the variables under this project.		



## 8.2.1 Engineering Positional Variable

The project position point is called in the form of #PX (X indicates the serial number) in the teaching file.

ltem		Opera	ating I	nstructions	
	#P #P20	Reco	ord the	coordinate type	to this point
	Position o	of Robot			
	Annotation				
	Coordinate	ACS	•		
	Posture	AUTO	•	Tool No	1
	J1	0.0000		J5	0.0000
	J2	0.0000		J6	0.0000
	J3	0.0000		J7	0.0000
	J4	0.0000		J8	0.0000
	Position o	of EXT Axis		Click "+" b	utton,automatically
	EXT Axis Gro	up 🗌 A 📄 B 🗌	] c [	generates	s a new variable in the e serial No.
	Ext1	0.000	)	Ext5	0.0000
	Ext2	0.000	)	Ext6	0.0000
1. New variable	Ext3	0.000	)	Ext7	0.0000
	Ext4	0.000		Ext8	0.0000
			Þ	00	Copy Paste
	Clear	<	20/	/20	> Record
2. Other operations		Refer to gl	obal p	osition vari	able

#### 8.2.2 Engineering Incremental Positional Variable

The project location point is called in the form of #IncpPX (X represents the serial number) in the teaching file. The specific operation refers to the project location variable.



80.003282				
Annotation		_		
Coordinate	ACS	▼		
Posture	AUTO	v	Tool No	1
J1	0.0000	0.0000		0.0000
J2	0.0000		J6	0.0000
J3	0.0000		J7	0.0000
J4	0.0000		J8 -	0.0000
Position o	f EXT Axis			
X <mark>T</mark> Axis Gro	up 🗌 A 📃 B 📒	] c 🚺	D	
Ext1	0.0000	)	Ext5	0.0000
Ext2	0.0000	)	Ext6	0.000
Ext3	0.0000	)	Ext7	0.0000
	0.0000		Ext8	0.0000
Ext4				

#### 8.2.3 Engineering Numerical Variables

The engineering value variable is called in the teach file as #VarX (X is the sequence number).

Compared with global numerical variables, engineering numerical variables need to be added by

users themselves click "<sup>th</sup> key, and other operations are the same.

#### 8.2.4 Engineering String Variables

The engineering string variable is called in the teach file as #StrX (X for ordinal).

Compared with the global string variable, the project string variable needs to be added by the

user to click ", key, and other operations are the same.



# 8.3 Robot Posture

The robot pose can be used in position variables and incremental position variables. For the 6-axis robot pose model, the following definitions are used:



# 9 Coordinate System

This chapter describes the

- ACS Axis Coordinate System
- KCS Kinematic Coordinate System
- WCS World Coordinate System
- TCS Tool Coordinate System
- PCS piece Coordinate System

#### 9.1 Introduction to Coordinate System

The following coordinate systems can be used for axis manipulation of the

robot.(ACS,KCS,WCS,TCS,PCS)



#### 9.1.1 Axis Coordinate System – ACS

Axis Coordination System (ACS). The axis coordinate system is a pure rotation coordinate system which is established by taking the mechanical zero point of each axis as the origin. Each axis of the robot can rotate independently or together.

#### 9.1.2 Kinematic Coordinate System – KCS

Kinematic Coordination System (KCS). The kinematics coordinate system is a coordinate system used to perform forward and reverse kinematics modeling on the robot, and is a basic Cartesian coordinate system of the robot, which may also be referred to as a robot base coordinate system (BCS) or a kinematics coordinate system. In this coordinate system, the robot end TCP may perform movement along the X axis, Y axis, and Z axis of the coordinate system, and rotation around the X axis, Y axis, and Z axis of the coordinate system.

#### 9.1.3 Tool Coordinate System – TCS

#### Tool Coordination System (TCS)

Tool installation: the effective direction of the tool held by the robot wrist flange is taken as the Z axis of the tool coordinate system, and the origin of the tool coordinate system is defined at the tip point (or center point) TCP (TOOL CENTER POINT) of the tool.

Tool not installed: At this time, the tool coordinate system is established on the center point of the end face of the robot flange, and the Z axis direction is perpendicular to the end face of the flange and points to the front of the flange face.

When the robot moves, the tool coordinate system moves with the movement of the tool tip point TCP. The user can choose to perform the teach motion in the tool coordinate system TCS. The teaching motion in the TCS coordinate system includes a moving motion along the X, Y, and Z axes of the tool coordinate system and a rotating motion around the X, Y, and Z axes of the tool coordinate system. The robot system supports the user to save 32 user-defined tool coordinate systems.

#### 9.1.4 World Coordinate System – WCS

World Coordinate System (WCS). The world coordinate system is also a spatial Cartesian coordinate system. The world coordinate system is a reference coordinate system of other Cartesian coordinate systems (the kinematics coordinate system KCS and the piece coordinate system PCS), and the kinematics coordinate system KCS and the piece Coordinate System PCS are



established with reference to the world coordinate system WCS. In the case where the world coordinate system is not configured for teaching by default, there is no positional offset or posture transformation between the world coordinate system and the robot kinematic coordinate system, and therefore the world coordinate system WCS and the kinematic coordinate system KCS coincide at this time. Users can teach the world coordinate system WCS through the Coordinate System Management interface. The end of the robot tool can move along the X axis, Y axis and Z axis of the coordinate system and rotate around the X axis, Y axis and Z axis of the coordinate system. The robot system supports the user to save 32 user-defined world coordinate systems.

#### 9.1.5 Piece Coordinate System – PCS

Piece Coordination System (PCS). The piece coordinate system PCS is a Cartesian coordinate system based on the world coordinate system - WCS. The piece coordinate system is mainly used to facilitate the user to switch multiple identical workpieces under the world coordinate system WCS in one application. In addition, after teaching the piece coordinate system, the movement and rotation of the robot tool end TCP in the piece coordinate system can reduce the difficulty of teaching. The piece coordinate system supports the user to save 32 user-defined piece coordinate systems.



Figure 12 Schematic diagram of four coordinate systems



## 9.2 Coordinate System Management Interface



Figure 13 Coordinate System Interface

# 9.3 Axis Coordinate System (ACS)

In teach mode, when the coordinate system is set to the Axis coordinate system ACS, the J1, J2, J3,

J4, J5 and J6 axes of the robot move separately. Please refer to the following table for the

movement of each axis when the axis operation key is pressed:

Axis Na	ame	Axis Oper	ating Key	Action
	J1 axis	J1-/X-	J1+/X+	Body left and right rotation
Basic axis	J2 axis	J2-/Y-	J2+/Y+	Lower arm back and forth movement
	J3 axis	J3-/Z-	J3+/Z+	upper arm up and down movement



	J4 axis	J4-/A-	J4+/A+	upper arm forward and reverse rotation
Wrist axis	J5 axis	J5-/B-	J5+/B+	Wrist up and down movement
	J6 axis	J6-/C-	J6+/C+	Wrist forward and reverse rotation

# 9.4 Kinematic Coordinate System (KCS)

In the teach mode, when the coordinate system is set to the kinematic coordinate system KCS, the robot tool end TCP moves in parallel along the X, Y and Z axes of the KCS coordinate system and rotates around the X, Y and Z axes of the KCS coordinate system. When the axis operation key is pressed, refer to the following table for the movement of each axis:

Axis	Name	Axis Oper	rating Key	Action
	X axis	J1-/X-	J1+/X+	Translational movement along the X axis of the KCS coordinate system
Moving axis	Y axis	J2-/Y-	J2+/Y+	Translational movement along the Y axis of the KCS coordinate system
	Z axis	J3-/Z-	J3+/Z+	Translational movement along the Z axis of the KCS coordinate system
Axis of	About the	14-/A-	14+/4+	X-axis rotational movement around the
rotation	X axis	- ANIA		KCS coordinates
	Around Y	15-/B-	15+/B+	Y-axis rotational movement around KCS
	axis	3576	35.70.	coordinates
	Around Z	16-/C-	16+/C+	Z-axis rotational movement around KCS
	axis	3070-	JOT/CT	coordinates

# 9.5 Tool Coordinate System

The tool management interface is mainly used to manage the tools installed on the end flange of the robot.



#### 9.5.1 Tool Coordinate System Axis Action

In the tool coordinate system, the effective direction of the tool held by the robot wrist flange is defined as the Z axis, and the origin of the coordinate system is defined at the tool center point (TCP), so the pose of the tool coordinate system changes with the movement of the wrist. The default tool coordinate system is at the center of the robot flange until a tool is assigned, as

shown in the following illustration.



Figure 14 Default Tool Coordinate System

The movement along the tool coordinate system is based on the effective direction of the tool and is independent of the position and posture of the robot, so it is most suitable for parallel movement operation without changing the posture of the tool with respect to the workpiece. Refer to the following table for the action of each axis:

Axis I	Name	Axis Operati	ng Key	Action
	X axis	J1-/X-	J1+/X+)	Translational movement along the X axis of the TCS coordinate system
Moving axis	Y-axis	J2-/Y-	J2+/Y+)	Translational movement along the Y axis of the TCS coordinate system
	Z axis	J3-/Z-	J3+/Z+)	Translational movement along the Z axis of the TCS coordinate system



	About the X axis	J4-/A-	J4+/A+	X-axis rotational motion around TCS coordinates
Axis of rotation	Around Y axis	J5-/B-	J5+/B+	Y-axis rotational motion around TCS coordinates
	Around Z axis	J6-/C-	J6+/C+	Z-axis rotational motion around TCS coordinates

#### 9.5.2 Calibration of Tool Coordinate System

The user can enter the calibration management interface through the submenu {Coordinate System Management} under the system application menu. The main interface of tool coordinate system TCS management is the same as that of world coordinate system WCS management.

#### 9.5.2.1 Parameter Interpretation

#### Calibration plane:

XY: Calibration selects three points P1-P3 in the XY plane, and the direction of the Z axis is obtained by cross multiplication of the X axis and the Y axis according to the right-hand rule. YZ: Three points P1-P3 are selected to be located in the YZ plane for calibration, and the X-axis direction is obtained by the cross product of the X-axis and the Y-axis according to the right-hand rule.

ZX: Calibration selects three points P1-P3 to be located in the ZX plane, and the Y-axis direction is obtained by cross multiplication of the Z-axis and the X-axis according to the right-hand rule.

#### 9.5.2.2 Four-Point Method: Calibration Position Offset(现在的版本偏移是 6 点法示教?)

When using {4-point method} for calibration, use the tip (center) point (i.e. TCP point) of the tool to be tested to approach the same reference point from four different directions. The reference point can be selected arbitrarily, but it must be the same fixed reference point. The robot controller calculates the TCP from four different flange positions. The four flange positions from the robot TCP point movement to the reference point must be spread out by a sufficient distance to make the calculated TCP point as accurate as possible.

The {4-point method} diagram is shown below:





Figure 15 Diagram of four-point method

The steps of {4-Point Method} to teach and calculate the location of the tool center point TCP are as follows:

Step 1: Select the index number of the coordinate system to be refreshed and select the four-point teach mode.

	(Y, Z, X) 96 p3 Tcp p4	PS PS	(Y, Z, X) • P3	
2.Record	Offset+Pose	Offset Plane YZ	Pose	
P	1	P2	P	3
	M.	D5	P	c .

Four points are required to be recorded using the four-point method.

Step 2: Bring the tip point TCP of the tool under test closer to a fixed reference point from the first direction. Click the [Record P1] button with the servo power on to record the first position point. The background color of the [Record P1] button changes to green when the P1 point recording is completed.





Step 3: Bring the tip point TCP of the tool under test closer to the same fixed reference point from the second direction. Click the [Record P2] button with the servo power on to record the second position point. The background color of the [Record P2] button changes to green when the P2 point recording is completed.



Step 4: Bring the tip point TCP of the tool under test closer to the same fixed reference point from a third direction. With the servo power on, click the [Record P3] button to record the third position point. The background color of the [Record P3] button changes to green when the P3 point recording is completed.



Step 5: Bring the tip point TCP of the tool under test closer to the same fixed reference point from the fourth direction. With the servo power on, click the [Record P4] button to record the fourth



position point. The background color of the [Record P4] button changes to green when the P4 point recording is completed.



Step 6: Click the [Calculate] button after recording the four position points required by the {4-point method} to automatically calculate the TCP position point data and display the calculation result.

Note that if two or more identical location points are recorded in the four-point method, the calculation will not succeed, and the program will report an error.

Step 7: Click the [Save] button to save the recorded coordinates of teaching position points and calculated coordinate system data and return to the main interface of coordinate system management.

Step 8: Click the [Set Current] button to use the calculated TCP tool as the flange end tool. At this point, you have completed all the steps from the tool coordinate system calculation to switching the newly calculated tool to the currently used tool. The tool coordinate system is calculated and switched successfully, and various movements of the robot can now be performed under the new tool.

Note that the four-point method can only determine the position offset value of the tool tip (center) point TCP relative to the mounting surface of the robot end flange. When the user needs to teach to determine the tool posture component, the three-point method needs to be additionally used, or the six-point method is directly used.

9.5.2.3 Three-Point Method: Calibrated posture Offset

{3-point method} The steps to teach and calculate the pose components of the tool coordinate system TCS are as follows:


Step 1: Select the serial number of the tool coordinate system to be modified or refreshed, and select the three-point working mode.

In the three-point method working mode, it is necessary to record three position points, i.e., P1 point, P2 point and P3 point. In addition, you need to select the plane in which the teach point is located, as shown below, select the XY plane. That is, the taught points P1 and P2 are used to determine the direction of the X-axis of the tool coordinate system, and the point P3 is on the positive Y axis side of the XY plane of the tool coordinate system. Since the three-point method only determines the posture component of the tool coordinate system TCP, the XY plane to be taught is only required to be parallel to the XY plane of the actual tool coordinate system TCS, and is not necessarily required to be the XY plane of the TCS. Point P1 is a point on the X axis of the coordinate system of the selected XY teaching plane, and is not required to be the tool tip (center) point TCP(the origin of the tool coordinate system), and so are points P2 and P3.



Figure 16 Select the three-point method operation mode

Step 2: As shown in the following figure, first record the first point in the X-axis direction on the tool coordinate system, i.e. P1 point.





The figure 17 records the P1 point (the first point P1 in the positive direction of the X-axis)



Step 3: Record the second point in the X-axis direction on the tool coordinate system, point P2.

The figure 18 records the point P2 (the second point P2 in the positive direction of the X-axis)

Step 4: Record a point in the positive direction of the Y axis on the XY plane of the tool coordinate system, i.e., point P3.



The figure 19 records the P3 point (point in the positive direction of the Y axis on the XY plane)



Step 5: Click the {Calculate} button, and the program generates the tool coordinate system posture component data according to the recorded P1, P2 and P3 points, and click the [Save] button to update the posture component of the tool coordinate system TCS of the selected coordinate system serial number.

It should be noted that, when the three-point method (three position points to be recorded) is used to determine the tool posture, the three position points can only be taught by moving motion in Cartesian space (that is, only XYZ moving motion in KCS, WCS, PCS and TCS can be taught, but not XYZ rotating motion or single joint rotating motion in ACS), and cannot be taught by rotating motion with any posture, otherwise, the posture component of the tool coordinate system cannot be calculated, and an error warning is given.

9.5.2.4 Six-Point Method: Offset of Calibration Position and Posture

	c <	2/32	>						
Coordinate Ty	pe: TCS		•	TCS:32	PCS:29	WCS:1			
Calibratio	on Result								
X:	124.5992			2.8660					
Y:	-2	.0433	Pitch:		-33.5511				
Z:	<mark>4</mark> 13	3.0664	Yaw:	171.8405					
	P1 (7, 2, 10 (7, 2, 10 (7, 2, 10) (7,	CP P4	AS PI	(Y, Z, X) • P3 <u>P1</u> P2 (	1. 1. 2)				
2.Record	Offse	et+Pose	Offset Plane YZ	Pose	zx				
2.Record	C Offse	et+Pose	Offset Plane YZ P2	Pose Plane	ZX P3				
2.Record P P	C Offse	xy	Offset Plane YZ P2 P5	Pose Plane	2X P3 P6				



#### Figure 20 Tool Coordinate System Calibration Interface

There are three calibration methods for tool coordinate system: {6-point method}, {4-point method} and {3-point method}. {6-point method} can teach the position offset and pose vector of the end tool TCP (TOOL CENTER POINT) of the six-axis joint robot synthetically; {4-point method} can only calculate the TCP position offset value of the end of the six-axis robot tool, but can not calculate the pose vector of the tool; {3-point method} can only calculate the TCP pose vector of the tool end of the six-axis robot, but cannot calculate the position offset value of the position offset value of the TCP at the tool end. The {6-point method} is actually a comprehensive use of the {4-point method} and the {3-point method}. The first four position points recorded in the {6-point method} use the {4-point method} to calculate the position offset of the TCP at the end of the tool, and the last three position points use the {3-point method} to calculate the TCP pose vector of the TCP at the end of the tool, and the last three position points use the {3-point method} to calculate the TCP pose vector of the tool.

# 9.6 Piece Coordinate System (PCS)

## 9.6.1 Piece Coordinate System Axis Action

In the teach mode, when the coordinate system is set to the piece Coordinate System PCS, the robot tool end TCP moves in translation along the X, Y and Z axes of the PCS coordinate system and rotates around the X, Y and Z axes of the PCS coordinate system. When the axis operation key is pressed, the actions of each axis are shown in the following table:

Axis I	Name	Axis Operating Key	Action
	X axis	J1-/X- J1+/X+	Translational movement along the X axis of the PCS coordinate system
Moving axis	Y-axis	J2-/Y- J2+/Y+	Translational movement along the y-axis of the PCS coordinate system
	Z axis	J3-/Z- J3+/Z+	Translational movement along the Z axis of the PCS coordinate system
Rotation Axis	About the X axis	J4-/A- J4+/A+	X-axis rotational motion around PCS coordinates
,	Around Y axis	J5-/B- J5+/B+	Y-axis rotational motion around PCS coordinates



Around Z	15.10	16,15,
axis	J0-/C-	J0+/C+

# 9.6.2 Calibration of Piece Coordinate System

The user can enter the calibration management interface through the submenu {Coordinate System Management} under the system application menu.

9.6.2.1 Parameter Interpretation of Calibration Method

Calibration plane:

XY: Three points P1-P3 are selected to be located in the XY plane for calibration, and the direction of the Z axis is obtained by cross multiplication of the X axis and the Y axis according to the right-hand rule.

YZ: Three points P1-P3 are selected to be located in the YZ plane for calibration, and the X-axis direction is obtained by the cross product of the X-axis and the Y-axis according to the right-hand rule.

ZX: Three points P1-P3 are selected to be located in the ZX plane for calibration, and the Y-axis direction is obtained by cross multiplication of the Z-axis and the X-axis according to the right-hand rule.

## Mode:

Mode 1 of 3-points: Take the XY calibration plane as an example, P1 is the origin position, P2 is a point in the positive direction of the X axis, and P3 is a point on the XY plane. The origin of the coordinate system taught in this way is located at the point P1, the positive direction of the X axis is directed from the point P1 to the point P2, and the point P3 is located on one side of the positive direction of the Y axis. YZ plane and the ZX plane are the same.

Mode 2 of 3-points: Take the XY calibration plane as an example, one point P1 and another point P2 on the X axis, and teach the third point P3 on the Y axis. Make a vertical line perpendicular to the line P1-P2 through point P3, and the position of the vertical foot is the origin of the coordinate system. The coordinate system taught in this way has a positive X-axis direction from point P1 to point P2, and point P3 is on the positive semi-axis of the Y-axis.

Offset of home point: the coordinate system taught by the user using the above two methods is offset to the O0 position point in the teaching record.



Coordinate Type:	PCS	•	TCS:32	PCS:29	WCS:1		
Calibration	Result						
X:	771.5115	Roll:					
Y:	159.0738	Pitch:		-0.0003			
Z:	848.5609	Yaw:		97.5669			
A		1 P2 (X, Y, Z)	P1	P2 (X,Y,Z)			
Offser of Plane XY	Home Point	Mode 1 of 3-Po	bints	Mode 2 of 3	3-Points		
Offser of Plane XY 2.Record the Plane	Home Point	Mode 1 of 3-Po Plane YZ P2	pints	P2 (X, Y, Z) Mode 2 of 3 Plane ZX P3	3-Points		
Contraction of the second the sec	Home Point	Mode 1 of 3-Po Plane YZ P2	bints	P2 (X, Y, Z) Mode 2 of 3 Plane ZX P3	3-Points		

Figure 21 Calibration interface of piece coordinate system

### 9.6.2.2 How to Calibrate a Piece Coordinate System

Step 1: Select the coordinate system number and type

The default (1) coordinate system cannot be modified, please select the calibration starting from No. 2.

Step 2: Select Calibration Method

Select the calibration method [Mode 1 of 3-points], [Mode 2 of 3-points], refer to the above "Calibration Method Parameter Explanation" for details.



In addition, the user can also add and record a coordinate origin offset position point O0. This position point is optional. When the user uses this function, the coordinate system taught by the user using the above two methods can be offset to the O0 position point in the teaching record, while the pose of the coordinate system remains unchanged.

The user can select the taught coordinate system plane by pressing the {XY}, {YZ}, {ZX} keys on the interface.

Step 3: Location Point Recording

Move to the position point, click the corresponding button, and the color of the button changes to green (as shown in the figure below), indicating that the recording is successful. Note that the calibrated position points cannot be too close to each other.

Coordinate No:	<	2/32	>			
Coordinate Type:	wcs		•	TCS:2	PCS:2	WCS:2
Calibration	Result					
X:	0.0000	Roll:				
Y:	0.0000		Pitch:		0.0000	
Z:	0.0000		Yaw:		0.0000	
Offser of Plane XY	Home Point	P1 P2 0 Mode	x, y, z) 1 of 3-Po YZ		P2 (X, Y, Z) Mode 2 of Plane ZX	3-Points
2.Record the	e Points					
P1			2		P3	
0						
Previous	Check points			Calcula	te	Save

Figure 22 Piece Coordinate System Calibration Interface 2

### Step 4: Calculate and Save Results

Click [Calculate], and click [Save] if the result is displayed successfully; if it fails, an alarm will be displayed in the status bar, modify or re-calibrate according to the alarm prompt.

In addition, on the position point recording interface, the user clicks the [Check Points] button to enter the teaching point management interface. On this interface, the user can view the recorded position data and make the robot move to the specified recording point. First select the recorded



position point, then make the robot in the servo enable state, select points P1, P2, P3 and [MoveTo], press and hold [Forward], and the robot moves towards the specified position point in the linear motion mode. Click [Previous] to return to the calibration screen.

Select Poli					
P1		P2	P3		
0	<i>1</i> /				
Joints coor	rdinate of Point				
J1:	0.0000	J5:	0.0000		
J2:	0.0000	J6:	0.0000		
J3:	0.0000	J7:	0.0000	)	
J4:	0.0000	J8:	0.0000		

Figure 23 View interface of teaching points

### Step 5:Set as current

After calibrating a piece Coordinate System, return to the coordinate system management interface, and set the calibrated coordinate system as the currently used coordinate system.

Check whether " T2P2" on the status bar shows the set coordinate system serial number, T is the tool coordinate system, and P is the piece Coordinate System.

Step 6: Verify Coordinate System

The directional accuracy of the calibrated coordinate system is verified by the translational motion of the robot tool end TCP along the X, Y, Z axes of the PCS coordinate system and the rotational motion about the X, Y, Z axes of the PCS coordinate system of the point (tip).



# 9.7 Workspace Monitoring

In a practical application scenario, a workspace of a robot often needs to be relatively limited, for example, a range of the workspace is set, the robot is limited to move within a certain range, or a noverrun range of a working area is set, the robot is limited to move into a certain range, or a mutual interference range of work is set, for example, multiple devices need to share the same space area, and when the robot runs to the interference range, a signal can be output to a peripheral device working in the same interference range.so as to restrict each other and avoid collision.

The robot system develops the function of workspace monitoring for three types, including working area, obstacle area and monitoring area, and up to 32 workspace monitoring areas can be set.



# 9.7.1 Description of Working Space Monitoring

### 9.7.1.1 Work Area

Set a workspace of a geometric body (sphere, cube, cylinder), the current TCP point of the robot can only run in the set geometric body, once the scope of the workspace is exceeded, the robot will perform emergency braking and stop and trigger the alarm prompt of exceeding the workspace, or the workspace buffer boundary has been preset, when the current TCP point of the



robot enters the buffer boundary area, the robot will automatically decelerate to a safe speed to move within the buffer boundary.

If the current TCP point of the robot does not exceed all the activated work areas, it is still determined that the robot is operating normally in the work area, i.e., does not exceed the work area. if that current TCP end of the robot exceed the range of the activated work area, i. e., exceed the work area, the robot will perform emergency braking and stop, and trigger an alarm prompt of exceeding the work space, wherein the alarm contains a corresponding work space serial number.



### 9.7.1.2 Obstacle Area

An obstacle space of a geometric body (sphere, cube, cylinder) is set, the current TCP point of the robot can only operate outside the set geometric body, once entering the obstacle area range, the robot will perform emergency braking and stop and trigger an alarm prompt that the robot has entered the obstacle area, or the obstacle buffer boundary has been preset, and when the current TCP point of the robot enters the buffer boundary area, the robot will automatically decelerate to a safe speed to move in the buffer boundary.

If the current TCP point of the robot enters any activated obstacle area, it will be judged that the robot has entered the obstacle area, the robot will perform emergency braking and stop, and trigger an alarm prompt for entering the obstacle area, and the alarm contains the corresponding workspace serial number.





#### 9.7.1.3 Monitoring Area

Setting a monitoring space of a geometric body (sphere, cube, cylinder), when the current TCP point of the robot enters the set monitoring interval, the robot will perform input and output IO signal triggering according to user's setting, for example, setting the input as low/high level triggering, and outputting IO signals or values; at the same time, a warning prompt that the robot has entered the monitoring area will pop up, or the obstacle buffer boundary has been preset. When the current TCP point of the robot enters the buffer boundary area, the robot will automatically decelerate to a safe speed to move within the buffer boundary. If the current TCP point of the robot enters any activated monitoring area, it will be judged that the robot has entered the monitoring area, and a warning prompt of entering the obstacle area will be triggered; set the monitoring area in the teach mode, the robot will not stop the movement in an emergency; in the play mode, the robot will stop the movement in an emergency after entering the monitoring area, and the alarm contains the corresponding workspace serial number.

### 9.7.2 Working Space Monitoring Setting

The geometry model of the work monitoring space is set based on the currently bound piece Coordinate System, that is, the set piece Coordinate System origin is the origin of the set

75



geometry, and the origin offset can also be set functionally, that is, the offset is performed based on the geometry origin and the piece Coordinate System origin.

### 9.7.2.1 Geometry Origin Setting

In the [menu] , select and click [Coordinate] coordinate to enter the coordinate system calibration interface, and select the coordinate system serial number. Select [piece Coordinate System/PCS] as the coordinate system type, and then perform coordinate calibration. For the description of calibration operation steps, please skip to 9.6.2 calibration of piece Coordinate System.





### 9.7.2.2 Global Monitoring Settings

After calibration of piece Coordi nate System, select and click {Workspace} in the bottom

column WorkSpace to enter the system as shown in the figure.

Note: When using workspace monitoring for the first time, you need to click to enter {Global Configuration} to enable settings.



coordinate N		1		2132		/					
Coordinate Type: PC		PCS	S			•	TCS:3	2	PCS:29	WCS:1	
1.Type Co	onfig	urat	tion								
Space Type	nonus	nonuse 🔍 🔻		▼	0	bservatio	n	tool			
Work Mode	Play 🔻			•	Sa	fety Edg	e9(mm)		0.00		
2.Shape(	nm)										
Space shape	Sphere			▼	R		0.00				
nonuse	1		0.0	0		nonus	se	0.00			
3.Origin	Offse	t(m	m)								
X:	0.00				y: 0	y: 0.00			z: 0.00		
Roll	0.00				Pitch:	0.00			Yaw: 0.00	D	
4.IO Con	fig										
Output IO M	odule		n	onuse	Outp		put IO Point		1		
Output Activ	e Leve	A	ctive	Low	▼	Outp	ut GVar I	ID nonuse		ise	
Input IO Mo Input Active Interlock pro	Input IO Module nor Input Active Level Active Lo Interlock processing Output in		Low	<b>v</b>	I	nput IO I	Point	t	1		
Coordinate	1			1		-	Global	Cont	fig	Save	

Go to "GlobalConfig" for the

first time



oordinate Type	: PCS		w l	TCS:32	PCS:29	WCS:1	
	a la secono de la se Internet de la secono		1				
Global Swite	h OFF	•					
1.Global W	ork OFF		1.Clic	c <mark>k "ON</mark> '	"		
IO Module	ON		IO Pa	int	1		
Effective level	Active Low	GVar	ID	nonuse			
2.Global Bl	ock Space						
IO Module	nonuse		IO Po	int	1	1	
Effective level	Active Low	•	GVar	ID	nonuse		
3.Global M	onitor Space						
IO Module	nonuse		IO Po	int	1		
Effective level	Active Low	•	GVar	ID	nonuse		

N	lame	Definition
Global monitoring switch		Enable/disable switch for workspace monitoring
		When the current TCP point of the robot exceeds all active
Global	IO Module	working areas, the corresponding IO signal is output. If not,
workspace		enter -1 in the input box
nontopuee	Output Gvar	When the current TCP point of the robot exceeds all active
	Sequence	working areas, the corresponding Gvar sequence number is



	Number	assigned 1. If not, enter -1 in the input box
		When the current TCP point of the robot enters any activated
	IO Module	obstacle area, the corresponding IO signal is output. If not, enter
Global		-1 in the input box
obstacle area	Output Gvar	When the current TCP point of the robot enters any activated
	Sequence	obstacle area, the corresponding Gvar sequence number is
	Number	assigned 1. If not, enter -1 in the input box
		When the current TCP point of the robot enters any activated
Global	IO Module	interference area, the corresponding IO signal is output. If not,
interference		enter -1 in the input box
region	Output Gvar	When the current TCP point of the robot enters any activated
region	Sequence	interference area, the corresponding Gvar sequence number is
	Number	assigned 1. If not, enter -1 in the input box

### 9.7.2.3 Global Monitoring Settings

Note: 1. The coordinate system serial number can be selected from 1 to 32; During workspace configuration, please pay attention to the selected coordinate system serial number.

2. Click Save, and the data will take effect.



	Coordinate N	lo:	<	2/32	2	>					
	Coordinate T	ype: P	:s			•	TCS:	32	PCS:29	w	CS:1
	1.Type C	onfigu	ration								
	Space Type	Type nonuse		-	O	bservatio	on	too	ol	1	•
	Work Mode	Play			Sa	fety Edg	ge9(mm)		0.00	8	
	2.Shape	(mm)									
	Space shap	e Spher	e		V	R			0.00		
	nonuse		0.0	0		nonu	se		0.00		
	3.Origin	Offset	(mm)								
	×	0.00			y: 0	.00			z: 0.00		
	Ro	l: 0.00	0.00		Pitch:	0.00			Yaw: 0.00		
	4.10 Co	nfig									
	Output IO	Module nonu		nonuse		Output IO Po		oint 1			
	Output Acti	ve Level	e Level Active Low			Output 0			GVar ID nonuse		
	Coordinate						Globa	ICon	nfig	Sa	ve
Nar	ne						Defir	niti	on		
	Area Type	There	are fou	ur op	tions	: 1. No	ot effec	ctiv	e; 2. wo	ork	area;
						4. S	urveilla	anc	e areas;	;	
	Mode of			1 ^		nree i	modes	are offo	e availat	ole:	v me
	operation			1. P 2. te	ach r	mode:	effecti	ive	only in	pia tea	ch m
Туре			3. Tea	ach +	Auto	o mode	e: effec	ctiv	ve in plav	y ai	nd te
Configuration	Monitoring								· ·	- -	
		Τ	mon	itorin	$\sigma n n$	ints ar	e inclu	der	d·1 Too	ים וו	0.pu

	point	Two monitoring points are included;1. Tool end;2. Flange center
	Security boundary (mm)	That is, the buffer boundary, when the robot runs to the safety boundary, the running speed will drop to the safe speed.
Shape	Sphere	The origin of the current corresponding piece Coordinate System is



configuration		taken as the center of the sphere, and the radius is automatically set to		
(mm)		limit a space area.		
		The origin	of the current corresponding piece Coordinate System is	
	Cube	taken as the	e vertex of the bottom surface of the cube, and the length,	
		width a	and height are set by themselves to limit a space area.	
		The origin of the current corresponding piece Coordinate System is		
	Cylinder	taken as the	e center of the bottom circle of the cylinder, and the radius	
		and t	he height are automatically set to limit a space area.	
		Based on	the origin of the current corresponding piece Coordinate	
Area origin c	offset (mm)	System, the	origin of the geometric body is offset in the directions of X,	
			Y, Z, around X, around Y and around Z.	
		Working	When the current TCP point of the robot exceeds the	
		area	activated work area, the corresponding IO signal is output.	
		arca	If not, enter -1 in the input box	
	Output IO module		When the current TCP point of the robot enters the	
		Obstacle	activated obstacle area, the corresponding IO signal is	
		area	output.	
			If not enter -1 in the input hox	
			in not, enter in the input box	
			When the current TCP point of the robot enters the	
		Interference	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is	
10		Interference region	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output.	
IO		Interference region	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output. If not, enter -1 in the input box	
IO Configuration		Interference region	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output. If not, enter -1 in the input box When the current TCP point of the robot exceeds the	
IO Configuration		Interference region Working	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output. If not, enter -1 in the input box When the current TCP point of the robot exceeds the active working area, the corresponding Gvar sequence	
IO Configuration		Interference region Working area	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output. If not, enter -1 in the input box When the current TCP point of the robot exceeds the active working area, the corresponding Gvar sequence number is assigned 1.	
IO Configuration	Output	Interference region Working area	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output. If not, enter -1 in the input box When the current TCP point of the robot exceeds the active working area, the corresponding Gvar sequence number is assigned 1. If not, enter -1 in the input box	
IO Configuration	Output Gvar	Interference region Working area	When the current TCP point of the robot enters the         activated interference area, the corresponding IO signal is         output.         If not, enter -1 in the input box         When the current TCP point of the robot exceeds the         active working area, the corresponding Gvar sequence         number is assigned 1.         If not, enter -1 in the input box	
IO Configuration	Output Gvar Sequence	Interference region Working area Obstacle	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output.If not, enter -1 in the input boxWhen the current TCP point of the robot exceeds the active working area, the corresponding Gvar sequence number is assigned 1.If not, enter -1 in the input boxWhen the current TCP point of the robot exceeds the active working area, the corresponding Gvar sequence number is assigned 1.Use the current TCP point of the robot enters the activated obstacle area, the corresponding Gvar sequence	
IO Configuration	Output Gvar Sequence Number	Interference region Working area Obstacle area	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output. If not, enter -1 in the input box When the current TCP point of the robot exceeds the active working area, the corresponding Gvar sequence number is assigned 1. If not, enter -1 in the input box When the current TCP point of the robot enters the activated obstacle area, the corresponding Gvar sequence number is assigned 1. If not, enter -1 in the input box	
IO Configuration	Output Gvar Sequence Number	Interference region Working area Obstacle area	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output. If not, enter -1 in the input box When the current TCP point of the robot exceeds the active working area, the corresponding Gvar sequence number is assigned 1. If not, enter -1 in the input box When the current TCP point of the robot enters the activated obstacle area, the corresponding Gvar sequence number is assigned 1. If not, enter -1 in the input box	
IO Configuration	Output Gvar Sequence Number	Interference region Working area Obstacle area Interference	When the current TCP point of the robot enters the activated interference area, the corresponding IO signal is output.If not, enter -1 in the input boxWhen the current TCP point of the robot exceeds the active working area, the corresponding Gvar sequence number is assigned 1.If not, enter -1 in the input boxWhen the current TCP point of the robot enters the active working area, the corresponding Gvar sequence number is assigned 1.Uter of the robot enters the activated obstacle area, the corresponding Gvar sequence number is assigned 1. If not, enter -1 in the input boxWhen the current TCP point of the robot enters the activated obstacle area, the corresponding Gvar sequence number is assigned 1. If not, enter -1 in the input boxWhen the current TCP point of the robot enters the activated interference area, the corresponding Gvar	



		box
Input IO		
module (only valid in interference		When the corresponding input IO signal is triggered, the current TCP point of the robot enters the activated interference area, and the robot stops moving urgently
	Interference	There are two options:
Interlock	region	1. Continuous output: when the current TCP point of the
processing		robot enters the activated interference area, the
(only valid		corresponding output IO signal continues to be output;
in		2. Ignore output: If the input signal has been triggered, the
interference	2	current TCP point of the robot enters the activated
area)		interference area, and the corresponding output IO signal
		is not output.

## 9.7.2.4 Work Space Monitoring

Manually press the viewing interface Fn1 of the handheld box and select {Workspace Interface} to view the activated and triggered workspace monitoring.

Current Content: Workspace				
Global Block Space	Global Working Space	Global Monito	or Space	
1	2	3	4	
5	6	7	8	
9	10	11	12	
13	14	15	16	
17	18	19	20	
21	22	23	24	
25	26	27	28	
29	30	31	32	



# **10 System Parameter Setting**

Click the Logo in the upper left corner to open [System Application], and select [System Parameters] to set parameters. After the parameter setting is completed, click [Save] below to save the parameters.

Select the setting parameter, and you can use the [Copy][Paste] button for shortcut operation.

## **10.1 System Parameters**

0	System Parm		
System Parm	1. Remote protocol	IO Mode	
6	2. Teach pendant inspection	Disconnection and Alarm	
Device Parm	3. Auto Annotation for CMD	Open	3

Figure 24 System Parameter Interface

No.	Parameter Name		Parameter Description
1 R6		Modebus TCP	Remote external IO to control the robot
		lo Mode	The upper computer communicates with the robot through Modbus TCP
	Remote Protocol	TCP Remote	The upper computer communicates with the robot through Tcp/ip
		Modbus RTU	
Teach penda 2 Inspectior	Teach nendant	Disconnection And Ignore	There is no prompt after the handheld box is disconnected or has been disconnected
	Inspection	Inspection Disconnection and Alarm	After the hand-held box is offline, it will prompt the alarm of "Hand-held box is offline or has been offline"
	Auto Annotation for 3 CMD	Close	Indicates that the function of automatically adding comments to commands is not enabled;
3 A		Open	Indicates that the command is enabled to automatically add comments; when writing a program, it will automatically add comments after setting the command line



Movc2 teach check	linearMotion	When teaching and running the circle command program, it is set to run to the midpoint of the circle in a straight line
	CircularMotion	When teaching and running the circle command program, it is set to run to the midpoint of the circle in the form of an arc
		Indicates that the brake release function is not
	Close	used;
	oreak off Open	Indicates that the brake release function is
		used; in an emergency, if the robot cannot be
Auto break off		operated through the teaching pendant, this
		function can be turned on at this time to
		perform brake release operations on the 4, 5,
		and 6 axes of the robot (note: safety protection
		must be done)
Satac chack	Close	
Selpt thetk	Open	
Main craft		
	Movc2 teach check Auto break off Setpc check Main craft	Horeal and the method of the m



# **10.2 Hardware Parameters**

0	Device Parm					
System Parm	Axis No:	1	•	Сору	Paste	
0	1. Encode	r plan res	olution	838	8608	
Device Parm	2. Encoder feedback resolution			838	8388608	
R	3. Absolut	te en <mark>cod</mark> e	r port	со	COM2	
Joint Parm	4. Encoder type			Gth	GthdEcat	
0	5. Cycle of encoder reading			98		
EXT Axis Parm	6. Max speed of motor (rpm)			350	3500	
	7. Max current of motor (A)			39.	0000	
Descartes Parm	8. Torque constant of motor (Nm/A)			m/A) 0.7	0.7300	
	9. Ratio of joint side			1.0	000	
	10. Ratio	of motor	side	121	.0000	

Figure 25 Hardware Parameter Interface

## Parameter list:

No.	Parameter Name	Parameter Description
1	Encoder plan resolution	Example of encoder lines: The resolution of a 17-bit encoder
2	Encoder feedback resolution	is 131072
3	Absolute Encoder Port	Bus-based control value This parameter is invalid
4	Encoder Type	Default GthdEcat
	Cyclo of oncoder reading	The absolute encoder data is read regularly to refresh the
5		current absolute position of the robot
	May croad of motor (rom)	The maximum speed of the motor, it is not allowed to exceed
6	Max speed of motor (rpm)	this speed during actual operation
	Max current of motor $(\Lambda)$	The maximum current of the motor, it is not allowed to be
7	Max current of motor (A)	exceeded this value during actual operation.
0	Torque constant of motor	Torque produced by unit current
ŏ	(Nm/A)	Torque produced by unit current
9	Ratio of joint side	The ratio of the rotation angle of the motor end to the
10	Ratio of motor side	rotation angle of the execution end (the allowable value is



positive or negative to change the dire	ection	ot	joint
---	--------	----	-------

## movement)

# 10.3 Axis

0	Joint Parameter				
System Parm	Axis No: 1	•	Сору	Paste	
0	1. Joint type	Rotary Joint (deg)			
Device Parm	2. Positive limit (deg)		165.00		
8	3. Negative limit (deg)		-165.00		
Joint Parm	4. Offset of Home point (deg) Bias of the actual Home point relative to the standard model		0.00		
0	5. Axis reverse		Null		
EXT Axis Parm	6. JOG max speed (deg	30.00			
	7. JOG max acc (deg/s^	2)	150.00		
Descartes Parm	8. JOG max dec (deg/s/	2)	150.00		
	9. MovJ max speed (deg/s)		200.00		
Plan Parm	10. MOVJ max acc (deg	/s^2)	200.00		
~	11. MOVJ max dec (deg	/s^2)	200.00		
UH Parm	12. Axis address		1		
Coupling					
			Reset	Save	

#### Figure 26 Axis Parameter Interface

## Parameter list:

No.	Parameter Name	Parameter Description
		Null;
1	Joint Type	Rotary joint (deg);
_		Translational Joint (mm);
2	Positive limit(deg)	Maximum joint range of motion
3	Negative limit(deg)	Minimum joint range of motion
4	Offset of home point(deg)	The deviation between the user-defined joint zero



	(Bias of the actual home	point and the system internal robot model zero point
	point relative to the	
	standard model)	
		Whether the rotation direction of the user-defined
5	Axis Reverse	joint is opposite to the direction of the robot model
		inside the system
6	IOG May Speed(X/s)	The maximum value of the movement speed of the
	JOG Max Speed(X/S)	jog axis operation keys in the joint coordinate system
		The maximum value of the movement acceleration of
7	JOG Max Acc(X/s^2)	the jog axis operation keys in the joint coordinate
		system
		The maximum value of the movement deceleration of
8	JOG Max Dec(X/s^2)	the jog axis operation keys in the joint coordinate
		system
9	Movj max speed(X/s)	MOVJ command joint movement speed maximum
10		MOVJ command joint movement acceleration
10		maximum value
11		MOVJ command joint motion deceleration maximum
11		value
12	Avis addross	The station number used in the bus communication
	Axis audiess	must match the setting of the host computer

# **10.4 External axis**

External axis parameters refer to the [Axis] parameter setting, and external axis that are not used have parameter 1 [Axis Type] selected as "Null".



0	EXT Axis Parameter						
System Parm	Axis <mark>No</mark> :	Ex1	T	Сору	Paste		
0	1. Joint ty	pe		Null		1	
Device Parm	2. Positive limit (X)			360.00	360.00		
0	3. Negative limit (X)			-360.00	-360.00 0.00		
Joint Parm	4. Offset Bias of th relative to	4. Offset of Home point (X) Bias of the actual Home point relative to the standard model					
	5. Axis re	verse		Null			
EXT Axis Parm	EXT Axis Parm 6. JOG max speed (X/s)			10.00			
	7. JOG max acc (X/s^2) 8. JOG max dec(X/s^2)			90.00			
Descartes Parm				90.00			
	9. MovJ max speed (X/s)			30.00	30.00		
Plan Parm	10. MOVJ	max acc ()	(/s^2)	100.00			
	11. MOVJ	max dec (	K/s^2)	100.00			
DH Parm	12. Axis a	ddress		7			
Coupling						i	
				Reset	Save		

Figure 27 Auxiliary Shaft Parameter Interface



## **10.5 Descartes**

# **Descartes Parameter** 1. Axis X: Positive limit (mm) Negative limit (mm) JOG max speed (mm/s) JOG max acc (mm/s^2) JOG max dec (mm/s^2) 2. Axis Y: Positive limit (mm) Negative limit (mm) JOG max speed (mm/s) JOG max acc (mm/s^2) JOG max dec (mm/s^2) 3. Axis Z: Positive limit (mm) Negative limit (mm) JOG max speed (mm/s)

9999.00	
-99999.00	
150.00	
1000.00	
1000.00	
9999.00	
-9999.00	
150.00	1
100 <mark>0.00</mark>	-
1000.00	
	~
9999.00	



JOG max dec (mm/s^2)	1000.00	
4. Axis RX:		
Positive limit (deg)	9999.00	
Negative limit (deg)	-9999.00	
JOG max speed (deg/s)	20.00	
JOG max acc (deg/s^2)	120.00	
JOG max dec (deg/s^2)	120.00	
5. Axis RY:		
Positive limit (deg)	9999.00	
Negative limit (deg)	-9999.00	$\sim$
JOG max speed (deg/s)	20.00	~
JOG max acc (deg/s^2)	120.00	A
JOG max dec (deg/s^2)	120.00	$\sim$
NEW 10 10 10		
6. Axis RZ:		~
6. Axis RZ: Positive limit (deg)	9999.00	*
6. Axis RZ: Positive limit (deg) Negative limit (deg)	9999.00 -9999.00	>
6. Axis RZ: Positive limit (deg) Negative limit (deg) JOG max speed (deg/s)	9999.00 -9999.00 20.00	>
<ul> <li>6. Axis RZ:</li> <li>Positive limit (deg)</li> <li>Negative limit (deg)</li> <li>JOG max speed (deg/s)</li> <li>JOG max acc (deg/s^2)</li> </ul>	9999.00 -9999.00 20.00 120.00	>
<ul> <li>6. Axis RZ:</li> <li>Positive limit (deg)</li> <li>Negative limit (deg)</li> <li>JOG max speed (deg/s)</li> <li>JOG max acc (deg/s^2)</li> <li>JOG max dec (deg/s^2)</li> </ul>	9999.00 -9999.00 20.00 120.00 120.00	»       «
<ul> <li>6. Axis RZ:</li> <li>Positive limit (deg)</li> <li>Negative limit (deg)</li> <li>JOG max speed (deg/s)</li> <li>JOG max acc (deg/s^2)</li> <li>JOG max dec (deg/s^2)</li> <li>7. Max Speed of Terminal:</li> </ul>	9999.00 -9999.00 20.00 120.00 120.00	
<ul> <li>6. Axis RZ:</li> <li>Positive limit (deg)</li> <li>Negative limit (deg)</li> <li>JOG max speed (deg/s)</li> <li>JOG max acc (deg/s^2)</li> <li>JOG max dec (deg/s^2)</li> <li>7. Max Speed of Terminal:</li> <li>Line speed (mm/s)</li> </ul>	9999.00 -9999.00 20.00 120.00 120.00 2000.00	
<ul> <li>6. Axis RZ:</li> <li>Positive limit (deg)</li> <li>Negative limit (deg)</li> <li>JOG max speed (deg/s)</li> <li>JOG max acc (deg/s^2)</li> <li>JOG max dec (deg/s^2)</li> <li>7. Max Speed of Terminal:</li> <li>Line speed (mm/s)</li> <li>Line acc (mm/s^2)</li> </ul>	9999.00 -9999.00 20.00 120.00 120.00 2000.00 20000.00	
<ul> <li>6. Axis RZ:</li> <li>Positive limit (deg)</li> <li>Negative limit (deg)</li> <li>JOG max speed (deg/s)</li> <li>JOG max acc (deg/s^2)</li> <li>JOG max dec (deg/s^2)</li> <li>7. Max Speed of Terminal:</li> <li>Line speed (mm/s)</li> <li>Line acc (mm/s^2)</li> <li>Line dec (mm/s^2)</li> </ul>	9999.00 -9999.00 20.00 120.00 120.00 2000.00 20000.00 20000.00	
<ul> <li>6. Axis RZ:</li> <li>Positive limit (deg)</li> <li>Negative limit (deg)</li> <li>JOG max speed (deg/s)</li> <li>JOG max acc (deg/s^2)</li> <li>JOG max dec (deg/s^2)</li> <li>7. Max Speed of Terminal:</li> <li>Line speed (mm/s)</li> <li>Line acc (mm/s^2)</li> <li>Line dec (mm/s^2)</li> <li>Angular speed (deg/s)</li> </ul>	9999.00 -9999.00 20.00 120.00 120.00 2000.00 20000.00 20000.00 300.00	
6. Axis RZ: Positive limit (deg) Negative limit (deg) JOG max speed (deg/s) JOG max acc (deg/s^2) JOG max dec (deg/s^2) C. Max Speed of Terminal: Line speed (mm/s) Line acc (mm/s^2) Line dec (mm/s^2) Angular speed (deg/s) Angular acc (deg/s^2)	9999.00 -9999.00 20.00 120.00 120.00 2000.00 20000.00 20000.00 300.00 300.00	

#### Figure 28 Descartes Parameter Interface

### Parameter list:

No.	Parameter Name	Parameter Description	
1	Positive limit(mm)	Maximum motion range in Cartesian coordinates	
2	Negative limit(mm)	Minimum motion range in Cartesian coordinates	
3	JOG Max	Maximum speed of jog axis operation key in Cartesian	



	Speed(mm/s)	coordinate system
Л		The maximum value of the movement acceleration of the jog
4		axis operation key in the Cartesian coordinate system
5	$IOC \max doc(X/cA2)$	The maximum value of the movement deceleration of the jog
		axis operation key in the Cartesian coordinate system
6	Line speed(mm/s)	The maximum value of the synthetic linear velocity at the end of
		the point in the Cartesian coordinate system
7	Lino Max Acc(X/sA2)	The maximum value of the synthetic linear acceleration at the
		end of the point in the Cartesian coordinate system
0	Line Max dec(X/cA2)	The maximum value of the synthetic linear deceleration at the
0		end of the point in the Cartesian coordinate system
0	Angular speed(deg/s)	Maximum resultant angular velocity at the end of a point in
9	Angular speed(deg/s)	Cartesian coordinates
10	Angular acc(dog/cA2)	The maximum value of the synthetic angular acceleration at the
10	Angular acc(deg/s <sup>-2</sup> )	end of the point in the Cartesian coordinate system
11	Angular dec(deg/sA2)	The maximum value of the synthetic angular deceleration at the
		end of the point in the Cartesian coordinate system



# **10.6 Plan Parameters**

Plan Parm		
1. Planner type	Cos	•
2. Joint smooth window	0	
3. Blend type	Spline	•
4. Follow error (round)	10	
5. Jerktime at "Teach" mode (ms)	128	
6. Default Jerktime at "Play" mode (ms)	200	
7. Default Speed at "Play" mode (%)	50	
8. Default Acc % at "Play" mode	100	
9. Default Dec % at "Play" mode	90	
10.Max joint speed in teach mode(%)	10	
11.Max decare speed in teach mode(mm/s)	100	

#### Figure 29 Planning Parameter Interface

### Parameter list:

No.	Parameter Name	Parameter Description
		Cos: Jerk is the trajectory planning of the Cos function
		Quintic: Jerk is a trajectory planner for degree 5 curves
		Door: Jerk is a trajectory planner for square waves
1	Planner Type	SawTooth: Jerk is a zigzag trajectory planner
		Exp: Jerk is a trajectory planner for exponential curves
		Bell: Jerk is a quadratic trajectory planner
		Refer to the figure below for the planning curve
	Joint Smooth	Output Averaging Filter Length
2	Window	Output Averaging Filter Length
		Fusion: The path is mixed and transitioned, the speed and
		acceleration do not change suddenly, the trajectory is controllable,
2	Diared Turne	but the speed cannot be constant, the default option
3	Biend Type	Arc: Circular transition ensures that the speed of the transition
		section is constant and the trajectory is controllable, but it will
		cause a sudden change in acceleration speed. Not suitable for joint



		trajectory and pose planning.				
		Spline: Spline transition ensures that the speed of the transition				
		section is constant and the trajectory is controllable, but it will				
		cause a sudden change in acceleration speed, which is smaller				
		han the Arc transition. Not suitable for joint trajectory and pose				
		planning				
		VelBlend: Speed transition, that is, two motion commands are				
		planned at the same time, and the speed is superimposed,				
		get the new location. The trajectory shape is related to the speed				
		when entering the Blend segment				
		15 P'				
		$P_{b2}$ $P'_{out}$				
		0 P2 Pb1				
		$P_{bx}$ $P_{in}$				
		-15 Pout				
		P <sub>3</sub>				
		Figure: End position path blending				
	Follow Error	The difference between the position command and the actual				
4	(round)	position in the time period from the start of the movement to the				
	(round)	actual position				
5	Jerktime at "teach"	The acceleration time used in manual jog, if the jog value is				
5	mode(ms)	increased, it will easily cause shake				
6	Default Jerktime at	When playing back, if the program does not call SetDyn, the				
0	"play" mode(ms)	default jerk time is this value, which is the jerk time in SetDyn				
7	Default speed at	Default running speed of play mode when startup				
,	"play" mode(%)	Derault running speed of play mode when startup				
Q	Default acc% at	Default acceleration speed of play mode when startup				
0	"play" mode	Default acceleration speed of play mode when startup				
۵	Default Dcc% at	Default deceleration speed of play mode when startup				
3	"play" mode	Derault deceleration speed of play mode when stallup				
10	Max joint speed in	Limit the maximum joint movement speed in teach mode				
10	teach mode(%)	Limit the maximum joint movement speed in teach mode				





Figure 6: bell-shaped jerk







Figure 2: saw-tooth-shaped jerk



Figure 3: exp-shaped jerk



# 10.7 DH Parameters

2		1P5	4
	P4	2	P3 + 0 -
P1	446 500	P10	0.000
P2	165.000	P11	0.000
P3	0.000	P12	0.000
94	580.000	P13	0.000
25	200.000	P14	0.000
P6	691.000	P15	0.000
77	102.000	P16	0.000
P8	0.000	P17	0.000
	0.000	D10	0.000

Figure 30 DH Parameter Interface

No.	Parameter Name	Parameter Description
1	P1~P7	Please fill in the parameter information according to the diagram
2	P8/P9	Coupling ratio between axis 4 and axis 5
3	P10/P11	Coupling ratio between axis 6 and axis 4
4	P12/P13	Coupling ratio between axis 6 and axis 5
5	P14~P18	Reserved



# 10.8 Coupling

Vo	Driving	Driven	Coupling
1	0	0	0.00000
2	0	0	0.00000
3	0	0	0.00000
4	0	0	0.00000
5	0	0	0.00000
6	0	0	0.00000
7	0	0	0.00000
8	0	0	0.00000
9	0	0	0.00000
10	0	0	0.00000

Figure 31 Coupling Ratio Setting Interface

# **11 General IO**

General IO is mainly used to configure general signals such as anti-collision, pause, restart, alarm reset and safety door.



# 11.1 Input Signal

# 11.1.1 Interface

ID	Function	Group	Index	Level	Status
1	AntiCollision	1	0	0	
2	ForbitMove	1	0	1	
3	StationPause	1	0	1	
4	SafeGate	1	0	1	
5	StationEstop	1	0	1	
6	HighTemperater	1	0	1	
7	BatteryError	1	0	1	

#### Figure 32 IO Input Interface

Group: indicates the address ID of IO module. The value of the extended IO slave address ID starts from 1.

Index: indicates the number of digits of the IO module to be used, 0 indicates not to be used, and the value of point starts from 1.

Level: Valid value, normally 1 is valid and can be negated.

Status: Points input status indicator, shows as green light when signal is triggered, shows as gray when no signal is displayed.

	No.	Input/output	Parameter	Description
		type	Name	
	1	Digital input	Anti-collision	After detecting that the anti-collision signal is
				triggered, the system stops the movement in
				an emergency and prompts the anti-collision
				signal to trigger the alarm.
	2	Digital input	ForbitMove	After the system detects that the external
				robot prohibition signal is triggered, the yellow
				warning prompts that the robot is prohibited

# **11.1.2 Function Description**



			from moving.
	Digital input	SationPause	When the system detects that the pause signal
3			is triggered, the system pauses the execution of
			the teach file.
	Digital input	Safe gate	After the system detects that the emergency
1			door signal is triggered, it will stop the
4			movement in an emergency and prompt the
			emergency door to give an alarm.
	Digital input	StationEstop	After the system detects that the emergency
			stop signal is triggered, the system stops the
5			movement in an emergency and prompts the
			emergency stop alarm.
			After the system detects that the high
	Digital input	High temperature	temperature alarm signal is triggered, it stops
6			moving and prompts the high temperature
			alarm.
	Digital input	BatteryError	After the system detects that the battery alarm
7			signal is triggered, it stops moving and prompts
			the battery alarm.


## 11.2 Output Signal

## 11.2.1 Interface

ID	Function	Group	Index	Level	Statu
1	Servo	1	0	1	
2	Idle	1	0	1	
3	Error	1	0	1	
4	Pause	1	0	1	
5	Working	1	0	1	
6	Warn	1	0	1	
7	Moving	1	0	1	
8	TeachMode	1	0	1	
9	PlayMode	1	0	1	
10	RemoteMode	1	0	1	
11	TPPause	1	0	1	
12	TPEstop	1	0	1	
13	TPStart	1	0	1	
14	TPThreeSwitch	1	0	1	
15	StationEstop	1	0	1	
16	StationPause	1	0	1	

#### Figure 33 IO Output Interface

Group: indicates the address ID of IO module. The value of the extended IO slave address ID starts from 1.

Index: indicates the number of digits of the IO module to be used, 0 indicates not to be used, and the value of point starts from 1.

Level:valid value,normally 1 is valid and can be negated.

Status: Point input status indicator, shows as green light when signal is triggered, shows as gray when no signal is displayed.



## **11.2.2** Function Description

No	Input/output type	Parameter	Description
NO.		Name	Description
1	Digital output	Servo	Output signal after robot is enabled
2	Digital output	Idle	Enable in standby state
3	Digital output	Error	The robot is in a red alarm abnormal state
4	Digital output	Pause	The robot is in a paused state
5	Digital output	Working	The robot is in the state of executing the
5	Digital output	VV OI KIIIg	teach file.
6	Digital output	Warn	The robot is in a warning prompt state
7	Digital output	Moving	The robot is in moving state
0	Digital output	TaachMada	Output signal when handheld teach pendant
0	Digital output	reactivioue	is in teach mode
0	Digital output		Output signal when handheld teach pendant
9	Digital output	Playivioue	is in play mode
10	Digital output	gital output RemoteMode	Output signal when handheld teach pendant
10	Digital output		is in remote mode
11	Digital output	TPppuso	Output signal when emergency stop signal of
11	Digital Output	Trpause	hand-held box is triggered.
12	Digital output	TDEston	Output signal when handheld box pause
12		TI EStop	signal is triggered.
12	Digital output	TDSTART	Output signal when hand-held box start
15	Digital Output	IFJIANI	signal is triggered.
1.4	Digital output	TPthrooSwitch	Output signal when trigger enable button
14	Digital Output	Truneeswitch	signal of three-stage switch of hand-held box.
			The workstation emergency stop input signal
15	Digital output	StationEstop	is received and the system is in the
			workstation emergency stop state.
			A workstation pause input signal is received
16	Digital output	StationPause	and the system is in the workstation pause
			state



## 11.3 IO Wiring

Take R51C1-EA/pro as an example, refer to the instruction manual for specific IO wiring.

#### R51C1-EA/pro wiring diagram



Ecat: Network cable connection

Power supply: 24V power supply, as shown in the lower right corner

Output: L3/L4(QL0/QL1) to 24V, M3/M4(QM0/QM1) to 0V, output is 24V

Input: If M1/M2(IM0/IM1) is connected to 0V, then input shall be 24V;

If M1/M2(IM0/IM1) is connected to 24V, then input shall be 0V;



## 12 Remote IO

Remote IO is mainly used in remote mode, such as remote operation of external startup file, reservation file, external startup confirmation and other signals related to remote operation.

## 12.1 Introduction to the Interface

#### 12.1.1 File Settings

No	Project Name	rogram Name	Priority	Repeat	addition
1	•	•	0	0	
2	•	•	0	0	
3	•	•	0	0	
4	•	•	0	0	
5	•	•	0	0	
6	•	•	0	0	
7	•	•	0	0	

**No.**: The file number obtained by combining the remote input file bits. In binary mode, only file numbers 1~8 are valid, and in combination mode, files 1~255 are valid.

**Project name and program name:** the project name and program name corresponding to the file number. If the file is started, the program of the project name and program name corresponding to the file number will be executed.

**Priority:** display the order of file execution. Priority is 1, which is the program being executed. In single mode, priority 2~8 are the programs being reserved; Only programs with priority 1 are in combined mode.

**Repeat:** The number of execution times of the reserved file program is mainly used for piece counting statistics and can be manually modified.

Additional: When the number of completions of the corresponding file number reaches an integral multiple of the set number of executions, it will automatically trigger an additional task to be executed.



## 12.1.2 Remote IO Input

Remote	System_In System_	Out Setting			2
No	Function	Group	Pin	Value	Status
1	Servo ON	1	0	1	
2	File1	1	2	1	
3	File2	1	3	1	
4	File3	1	0	1	
5	File4	1	0	1	
6	File5	1	0	1	
7	File6	1	0	1	
8	File7	1	0	1	
9	File8	1	0	1	
10	Start Confirm	1	0	1	
11	Cancel Reservation	1	0	1	
12	Reset Alarm	1	0	1	Ó
13	Remote Pause	1	4	1	
14	Remote Estop	1	0	1	

**Group:** Indicates the address ID of the IO module, and the value of the address ID of the extended IO slave station starts from 1.

**Pin:** Indicates the number of the module used, 0 means not used, and the value of the dot starts from 1.

**Value:** valid value, normally 1 is valid, can be negated.

**Status:** Point input status indicator, the light will be green when the signal is triggered, and it will be black when there is no signal.

Function Description:

No.	Input/output type	Parameter Name	Description
1	Remote IO Input	Servo On	In the remote IO control mode, the system will enable the robot when it receives this signal.
2	Remote IO Input	File bit 1	File number input bit 1, it represents the file bit 1 if it is a single mode; it represents the first bit of 8421 encoding if it is a combination mode.



			File number input bit 2, it represents the file bit 2 if it is a
3	Remote IO Input	File Bit 2	single mode; it represents the second bit of 8421
			encoding if it is a combination mode.
			File number input bit 3, it represents the file bit 3 if it is a
4	Remote IO Input	File bit 3	single mode; it represents the third bit of 8421 encoding if
			it is a combination mode.
			File number input bit 4, it represents the file bit 4 if it is a
5	Remote IO Input	File bit 4	single mode; it represents the 4th bit of 8421 encoding if
			it is a combination mode.
			File number input bit 5, it represents the file bit 5 if it is a
6	Remote IO Input	File Bit 5	single mode; it represents the 5th bit of 8421 encoding if
			it is a combination mode.
			File number input bit 6, it represents the file bit 6 if it is a
7	Remote IO Input	File bit 6	single mode; it represents the 6th bit of 8421 encoding if
			it is a combination mode.
			File number input bit 7, it represents the file bit 7 if it is a
8	Remote IO Input	File bit 7	single mode; it represents the 7th bit of 8421 encoding if
			it is a combination mode.
			File number input bit 8, it represents the file bit 8 if it is a
9	Remote IO Input	File bit 8	single mode; it represents the 8th bit of 8421 encoding if
			it is a combination mode.
10	Remote IO Input	Startup	File start signal in combination mode. This signal is invalid
10		Confirmation	in single mode.
11	Remote IO Input	Cancel an	Cancel all appointments (including additional tasks
		appointment	corresponding to execution or appointment files)
12	Remote IO Input	Alarm Reset	Clear alarm signal
12	Remote IO Input	Remote	Pause robot motion
		Pause	
11	Remote IO Input	remote	Emergency stop signal
¥		scram	Lincigency stop signal



## 12.1.3 Remote IO Output

No	Function	Group	Pin	Value	Status
1	Servo ON	1	0	1	
2	Idle	1	0	1	
3	Working	1	0	1	
4	Pause	1	0	1	
5	Alarm	1	0	1	
6	Warning	1	0	1	
7	Running	1	0	1	
8	File1	1	1	1	
9	File2	1	2	1	
10	File3	1	0	1	
11	File4	1	0	1	
12	File5	1	0	1	
13	File6	1	0	1	
14	File7	1	0	1	
15	File8	1	0	1	
16	Start Confirm	1	0	1	

**Group:** Indicates the address ID of the IO module, and the value of the address ID of the extended IO slave station starts from 1.

**Pin:** Indicates the number of the module used, 0 means not used, and the value of the dot starts from 1.

Value: valid value, normally 1 is valid, can be negated.

**Status:** Point input status indicator, the light will be green when the signal is triggered, and it will be black when there is no signal.

Description:

No.	Input/output type	Parameter Name	Description
1	Remote IO Output	Servo On	Output signal after robot is enabled
2	Remote IO Output	Idle	Enable in standby state
3	Remote IO Output	Working	The robot is in the state of executing the



			teach file.
4	Remote IO Output	Pause	The robot is in a paused state
5	Remote IO Output	Alarm	The robot is in a red alarm abnormal state
6	Remote IO Output	Warning	The robot is in a warning prompt state
7	Remote IO Output	Running	the state in which that robot is in motion
8	Remote IO Output	File bit 1	File bit 1 is in reservation
9	Remote IO Output	File Bit 2	File bit 2 is in reservation
10	Remote IO Output	File bit 3	File bit 3 is in reservation
11	Remote IO Output	File bit 4	File bit 4 is in reservation
12	Remote IO Output	File Bit 5	File bit 5 is in reservation
13	Remote IO Output	File bit 6	File bit 6 is in reservation
14	Remote IO Output	File bit 7	File bit 7 is in reservation
15	Remote IO Output	File bit 8	File bit 8 is in reservation
16	Remote IO Output	Start Confirm	Remote input enable confirm is pressed

### 12.1.4 Setting

Remote	System_In	System_Out	Setting	
Single				

Confirm File No. when start in compose mode

**Reset reservation when the model changed** and **Confirm File No. When start in compose mode** are backup functions.

If **Reset reservation when the model changed** is checked, all reservations will be cleared when the mode of the handheld box is switched; the new reservation is required when switching back to the remote mode.

If the function of **Confirm File No. When start in compose mode** is checked, the file position signal must be detected when the combination mode is started (that is, the corresponding file signal (combination) is continuously input), the confirmation signal is activated, and the file position input signal can only be canceled after the station file starts to execute.



There are two working modes of remote IO: 1. No used 2. Single 3. Compose (combination mode).

Remote	System_In	System_Out	Setting	
Single				•
NoUse				
Single				
Compos	se			

## 12.2 Use in Single Mode

## 12.2.1 Application



The three stations shown in the above figure are used to process different workpieces

respectively, and the following preparations shall be made in advance:

On the station 1, execute program 1 of workpiece 1.

On the station2, execute the program 2 of the workpiece 2.

On the station 3, execute the program 3 of the workpiece 3.

During reproduction, switch to "REMOTE" mode, after preparing workpiece 1, press the start button on station 1, and the robot executes program 1. When executing Procedure 1, prepare Workpiece 2 and Workpiece 3, and then press the start buttons on station 2 and station 3 in turn. At this time, even if the program 1 is still running, since the start buttons have been pressed, the program 2 and the program 3 have been reserved in sequence, and the programs will be executed in sequence according to the reserved order.

The system can realize the reservation of 8 stations at most.



## 12.2.2 Operation Steps

12.2.2.1 Setting Remote Work Mode

Enter [Remote] - [Setting] - set it to [single] mode in [Remote IO Mode].

12.2.2.2 Setting Remote File Names

Step 1 Create a workstation program.

enter [menu] - [project]-create a demo project, and create a new station program with program names of a1, b2and c3.

Step 2 Set up remote files.

Enter the [Remote] interface. The settings are as follows:

No	Project	Name	rogran	n Name	Priority	Repeat	addition
1	demo	•	a1	•	0	0	
2	demo		b2	•	0	0	
3	demo		63		0	0	

#### 12.2.2.3 Setting Remote IO Input

Connect to ethercat IO and use input points 1.1~1.15 for configuration.

Remotely operate the robot to perform 3 stations' work, enable signal must be set for file 1, file2, and file 3. Cancel reservation, alarm reset, remote pause and remote emergency stop can be set as required.



No	Function	Group	Pin	Value	Status
1	Servo ON	1	0	1	
2	File1	1	1	1	
3	File2	1	2	1	
4	File3	1	3	1	
5	File4	1	0	1	
6	File5	1	0	1	
7	File6	1	0	1	
8	File7	1	0	1	
9	File8	1	0	1	
10	Start Confirm	1	0	1	
11	Cancel Reservation	1	0	1	
12	Reset Alarm	1	0	1	
13	Remote Pause	1	4	1	
14	Remote Estop	1	0	1	

### 12.2.2.4 Setting Remote IO Output

Connect ethercat IO, and use output points 1.1~1.16 for configuration.

The remote IO output signal is set according to the external status.



No	Function	Group	Pin	Value	Status
1	Servo ON	1	0	1	•
2	Idle	1	0	1	
3	Working	1	0	1	
4	Pause	1	0	1	
5	Alarm	1	0	1	
6	Warning	1	0	1	
7	Running	1	0	1	
8	File1	1	1	1	
9	File2	1	2	1	
10	File3	1	0	1	
11	File4	1	0	1	
12	File5	1	0	1	
13	File6	1	0	1	
14	File7	1	0	1	
15	File8	1	0	1	
16	Start Confirm	1	0	1	

#### 12.2.2.5 Start Reservation

For example, the procedures of station 1, station 2 and station 3 are executed in sequence, and the workflow is as follows:

After completing the setting of step 1-4, switch to remote mode—input signal 1.4 to enable wait for normal enabling of robot—input signal 1.1 to station 1—station 1 is working, wait for execution—input signal 1.2 to station 2—station 2 is reserved, wait for execution—input signal 1.3 to station 3—station 3 is reserved, wait for execution.



## 12.3 Combined Mode Usage

## 12.3.1 Application



The three stations shown in the above figure are used to process different workpieces

respectively, and the following preparations shall be made in advance:

On the tool 1, execute the program 1 of the workpiece 1.

On the tool 2, execute the program 2 of the workpiece 2.

On the tool 3, execute the program 3 of the workpiece 3.

Only two file bits are available.

The combined mode system enables up to 255 process files.

## 12.3.2 Operation Steps

12.3.2.1 Setting Remote Work Mode

Enter [Remote] - [Setting] - [Remote IO] Mode to set to [Compose] mode.

12.3.2.2 Set Remote File Names

Step 1 Create a workstation program

enter [menu] - [project] - create a demo project, and create a new station program with program names of a1, b2and c3.

Step 2 Set up remote files.

Enter the [Remote] interface and select the [Remote] property page. The settings are as follows:



No	Project I	lame	rogran	n Name	Priority	Repeat	addition
1	demo	•	a1	•	0	0	
2	demo	•	b2	•	0	0	
3	demo		63		0	0	

#### 12.3.2.3 Set remote IO Input

Operating the robot to work remotely at 3 stations . File 1, File 2, File 3 and Servo ON signal must be set. Cancel reservation, Reset alarm, Remote Pause and Remote Estop can be set as required.

No	Function	Group	Pin	Value	Status
1	Servo ON	1	4	1	
2	File1	1	1	1	
3	File2	1	2	1	
4	File3	1	3	1	
5	File4	1	0	1	
6	File5	1	0	1	
7	File6	1	0	1	
8	File7	1	0	1	
9	File8	1	0	1	Ó
10	Start Confirm	1	5	1	
11	Cancel Reservation	1	6	1	
12	Reset Alarm	1	7	1	۲
13	Remote Pause	1	8	1	
14	Remote Estop	1	9	1	

#### 12.3.2.4 Setting remote IO Output

Connect ethercat IO, and use output points 1.1~1.16 for configuration. The remote IO output signal is set according to the external status.



No	Function	Group	Pin	Value	Status
1	Servo ON	1	1	1	
2	Idle	1	2	1	
3	Working	1	3	1	
4	Pause	<b>1</b>	4	1	
5	Alarm	1	5	1	
6	Warning	1	6	1	
7	Running	1	7	1	
8	File1	1	8	1	
9	File2	1	9	1	
10	File3	1	10	1	
11	File4	1	11	1	
12	File5	ा	12	1	
13	File6	1	13	1	
14	File7	1	14	1	
15	File8	1	15	1	
16	Start Confirm	1	16	1	

#### 12.3.2.5 Start an appointment

For example, the procedures of station 1, station 2 and station 3 are executed in sequence, and the workflow is as follows:

Start the work flow of station 1: after completing the setting of steps 1-4, switch to remote mode--give the enable input signal 1.4--wait for the robot to be enabled normally--set the file 1 signal 1.1--the reservation of station 1 is completed--give the start confirmation signal 1.5--the robot starts to work in station 1(demo.a1), waiting for execution--the work is completed. Start the work flow of station 2: after completing the setting of steps 1-4, switch to remote mode--input enable signal 1.4--wait for normal enable of robot--input signal 1.2 to file 2--reservation of station 2 is completed--start confirmation signal 1.5--robot starts working at station 2 (demo.b2), waiting for execution--work is completed.

Start the work flow of station 3: after completing the setting of steps 1-4, switch to remote mode--input enable signal 1.4--wait for normal enabling of robot--input signal 1.1 to file 1, input signal 1.2 to file 2 (file 1 and file 2 are combined to form station 3 file)--reservation of station 3 is



completed--send start confirmation signal 1.5--robot starts working at station 3(demo.c3), wait for execution--work is completed.

## 12.4 Use of Additional Tasks

## 12.4.1 Application Scenarios



The two stations shown in the above figure are used to process different workpieces respectively, and the following preparations shall be made in advance:

On tool 1, execute program 1 of workpiece 1

On the tool 2, execute the program 2 of the workpiece 2

Additional tasks can be performed based on individual mode and combination mode, and the system can add up to 256 additional tasks.

## 12.4.2 Operation Steps

### 12.4.2.1 Set Remote Work Mode

Enter [Remote] - [Setting] - [Remote IO Mode], which can be set to [Single] or [Compose]mode as required.

12.4.2.2 Set Remote File Names

Step 1 Create a workstation program Enter [menu]-[project] -create a demo project, and create a new station program with program names of a1,b2and c3.

Step 2 Set up remote files



Enter the [Remote] interface and select the [remote] Settings property page. The settings are as follows:

Remo	te Syst	em_In	Syster	n_Out	Setting		
No	Project	Name	rogram	Name	Priority	Repeat	addition
1	demo	•	a1	V	0	0	

Step 3 Set up additional tasks

Click the [Additional] button in the line corresponding to the document number to enter the setting page, and the settings are as follows:

No. Project Name (rogram Name Priority									1
	No	Project	Name	rogram	Name	Priority	Repeat	addition	
	1	demo	•	a1		0	0		
Ac	dition	n task se	tting					?	1
				•	Addition	n task settir	g		
Inde	x:					1			
Proje	ectNam	ne: den	no						
Prog	ramNa	me: a1							
Prog	ramNa	me: a1							
Prog	ramNa	me: a1							
Prog	ramNa Enable	me: a1	task						
Prog	ramNa Enable tion Ta	me: a1 addition	task			b2			
Prog Addi Exec	Enable tion Ta	me: a1 e addition sk mes of Pr	task	once addi	ition tasl	b2 < 2			
Prog Addi Exec	ramNa Enable tion Ta cuted ti	me: a1 e addition sk mes of Pr	task	once addi	ition tasl	b2 ¢ 2			
Prog Addi Exec	Enable tion Ta	me: a1	task ogram	once addi	ition tasl	b2 < 2			
Prog Addi Exec	Enable tion Ta	me: a1	task ogram	once addi	ition tasl	b2 < 2			
Prog Addi Exec	Enable tion Ta	me: a1	task	once addi	ition tasl	b2 ¢ 2			



To enable the additional task function, you need to check before [enable additional task] option, select the [Addition task] to be added, input the [executed times of program once addition task], and click [Modify] to complete the configuration.

No	Project	Name	Irogran	n Nami	Priority	Peneat	addition
NU	riojett	Name	TUgran	I Name	ritority	кереас	aduition
1	demo		a1		0	0	b2
2				-	0	0	

#### 12.4.2.3 Set Remote IO Input

Connect to ethercat IO and use input points 1.1~1.15 for configuration.

Operating the robot to work remotely at 3 stations . File 1, File 2, File 3 and Servo ON signal must

be set. Cancel reservation, Reset alarm, Remote Pause and Remote Estop can be set as required.

Remote	System_In System_	Out Setting			er 12
No	Function	Group	Pin	Value	Status
1	Servo ON	1	1	1	
2	File1	1	2	1	
3	File2	1	3	1	
4	File3	1	4	1	
5	File4	1	5	1	
6	File5	1	6	1	
7	File6	1	7	1	
8	File7	1	8	1	
9	File8	1	9	1	
10	Start Confirm	1	10	1	
11	Cancel Reservation	1	11	1	
12	Reset Alarm	1	12	1	Ó
13	Remote Pause	1	13	1	0
14	Remote Estop	1	14	1	

Previous	1/1	> Next	Save
----------	-----	--------	------



#### 12.4.2.4 Set Remote IO Output

Connect ethercat IO, and use output points 1.1~1.16 for configuration.

The remote IO output signal is set according to the external status.

No	Function	Group	Pin	Value	Status
1	Servo ON	1	1	1	
2	Idle	1	2	1	
3	Working	1	3	1	
4	Pause	1	4	1	
5	Alarm	1	5	1	
6	Warning	1	6	1	
7	Running	1	7	1	
8	File1	1	8	1	
9	File2	1	9	1	
10	File3	1	10	1	
11	File4	1	11	1	
12	File5	1	12	1	
13	File6	1	13	1	
14	File7	1	14	1	
15	File8	1	15	1	
16	Start Confirm	1	16	1	

#### 12.4.2.5 Start Additional Task Operation

Example: workflow of additional task (file number b2):

In the individual mode/continuous mode, the station 1(file number a1) is started twice, and the system automatically starts the additional task station 2(file number b2) after the completion of the accumulated two jobs.

Note: The additional task is automatically started each time the number of times the corresponding file number is executed is an integer multiple.



## **13 Other Functions**

## 13.1 Zero Calibration



1. Without the calibration of the origin position, the teaching and playback operations cannot be performed. In a system using multiple robots, each robot must perform home position calibration.

2. When there is a coupling relationship between the joint axes, for example, there is a coupling relationship between the fifth axis and the sixth axis of common robots. When the fifth axis must be at the zero position, the zero point data recorded by the sixth axis will be valid; otherwise, the zero point data recorded by the six-axis is invalid. Therefore, the zero position data of the sixth axis must be recorded when the fifth axis is at zero position. If there is no coupling relationship, each axis can calibrate the zero position independently, and the respective zero positions will not affect the zero positions of other joints.

3. When all the used axes (main body axis and auxiliary extension axis) have completed the zero calibration, the "all" indicator light on the zero calibration interface turns green, indicating that the robot has completed the zero data calibration, and the robot can Carry out motion in Cartesian space.

After clearing the encoder zero drift alarm, the mechanical zero position calibration and software record calibration must be required for each axis of the robot immediately.

**Mechanical zero calibration**: perform calibration according to the following method, i.e., make each axis run to mechanical reference zero point through single-axis movement.

**Software record calibration**: When all 6 axes have returned to the mechanical reference zero point through single-axis movement, it is necessary to enter the factory setting of the software and re-record the zero-point position. Ensure that the zero positions of the software and hardware correspond. After that, each time the robot returns to zero, it will return to that position.



1:	0	2:	0	3:	0	4:	0		
5:	0	6:	0	7:	0	8:	0		
x1:	0	Ex2:	0	Ex3:	0	Ex4:	0		
x5:	0	Ex6:	0	Ex7:	0	Ex8:	0		
.Curr	Green i ent zer	ndicates t o status a	hat the a nd refe	axis zero poi rence posito	nt is v on	alid			
		0		Ex1		0			
		0		Ex2		0			
3 0				Ex3		11			
4 0				Ex4	12				
		0		Ex5		13			
		0		Ex6		14			
7		0		Ex7		15			
3		0		Ex8		16			
1					M	odify	Refresh		
Gr Axis	ay indic selectio	ates that	the axis	zero point is	s inval	id and ne	eds to be recal		
1		2	3	4		5	6		
7		8	E1	E2		E3	E4		
E5		E6	E7	E8					
	Clear	robot defa	ault valu	e of encoder	Re	cord	Clear		









## 13.2 20-Point Method

The 20-point method is used to compensate for the zero point and the tool coordinate system. step 1: Step 1: Change the different poses of the robot and use the end of the tool to align the tip and record the position points. The joint angle of each position point changes as much as possible.



	Step 1: Rec	ord Points(V	3.3)	
1 Record	1. Status of the Green-Recor Gray-Unreco	e points: rded success ord appe of joints :	at adiacent po	ints
	shall be as la	rge as possible		las -
2		2		4 5
Calculate	6	0		9 (10
		12		14 (15)
3		-	-	
Compensate		•		
	Points No:	<	1	>
	J1:	-0.2538	J2:	-16.8904
	J3:	7. <mark>75</mark> 03	J4:	-0.0010
	15.	-9.1561	J6:	-0.2521
	J.,	0.000	-5-01-5	



#### Step 2: Click [Calculate]

	Step 2: Ca	lculate		
Record	Input the co to obtain the	upling ratio, the e result	n click [Calculat	e]
	Axis 5,6	0.00000	Axis 4,5	0.00000
2	Axis 4,6	0.00000	Axis 2,3	0.00000
Calculate	1. Offset of	Home Position		
R	J1:	0.0000	J2:	0.0884
Compensate	J3:	-0.7335	J <mark>4</mark> :	0.3857
	J5:	0.0503	J6:	0.0000
	2. TCP (mm)			
	X:	78.6696	Y:	-5.0135
	Z:	369.1848		
	3. Calibratio	n Error		
	Avg Err(mm)	: 0.6422	Max Err(mn	n): 1.2177
		c	alculate	

Step 3: Click [Compensate]





# 13.3 Exception Handling

1.Simul	ation St	atus of /	Axis				
1	2	3	4	5	6	7	8
Ex1	Ex2	Ex3	Ex4	Ex5	Ex6	Ex7	Ex8
2.Alarm	and Lin	nitation					
Limitation	of axis		A	larm of Ar	nti-collisio		)

Green light means active, gray means normal.

## **13.4 Authority Management**

## 13.4.1 User Switching

Å	Q	Q
Factory	Manager	Operator
Password:		
		Login
New password : Facto	ager	1
New password : Facto	ager Confirm	Clear
New password : Factor New password : Man Boot Options	ager Confirm	Clear
New password : Factors	ager Confirm Boot Manager	Clear Boot Operat

Figure 34 User Switching Interface



# 13.4.2 Hardware Testing

A	Syste	m Funct	ion			
User Level	Messa	age:				
<i>i</i> Device Test						
0 UI Style						
(Opgrade	1. Ping	test			ping 192.16	8.100.3
	2.Moni (Restar	itor calib rt to effe	oration ect)		Calibration	
	3. Back	dight te	st			•
	Auto S	creensa	ver		Close	•
	4.Devi	ce test			Open	
	5. Mod	lify the I	P of con	troller	lan1	•
	0.	0.	0.	0	Modify	
					DHCP	
	6.View controller ip				View	

Figure 35 System Version Interface

#### Parameter list:

No.	Parameter Name	Parameter Description
1	Ping Test	Check whether the communication between the teach
		pendant and the controller is normal
	Monitor	Calibrate the handheld touch screen, and the handheld will
2	calibration(restart to	automatically restart after the calibration procedure is
	effect)	completed.
3	Backlight Test	Adjust the backlight brightness of hand-held lcd
Ū	Auto Screensaver	Automatic screensaver (on/off)
4	Device test	[Open hand-held Hardware Test]
5	Modify the IP of	Modify LAN1, LAN2(LAN3) network port IP



	controller	
6	View controller IP	View controller IP

## 13.4.3 Interface Style

UI Sytle			
Default st	yle 1	style 2	
1.Font size:	11		
2.Language (Restart to effect):	En		▼
	Confirm	Cance	el

Figure 36 Interface Style Setting Interface

Set the interface font, font size and display language.



# 13.4.4 Upgrade and Backup

	BackUp and recover	Update teach pendant	
Ulsar	1.Ui Version	1.7.25 - 2.0.5	the upgrade package
User	2.Update System	Control box update	format is UI
i Hardware test	Task v2.3.2 simulated_controller_v1.0.0 libmotion_r_v2.5.9 CmdExecutor v2.4.3 softPlc v0.2.23 ext_axis1.3.4.20211020 imf_communication1.0.6 Welding1.3.10.20211020	Controller update	Update the controller
ckUp ang recov	3.BackUp		
ckop ang reco	👻 🗹 Other Par		
	🔀 Robot system conf	ig	
	🔽 Coordinate		
	GVar		
	🔀 Ecaat		
	<ul> <li>Project of teachfiles</li> </ul>		
	Fluzh01	Packup the colorted files	
	🧭 @GlobalTask	- backup the selected files	
	Update Ba	ackup Slected Backup all	Backup all files



## **14 Instruction System**

## 14.1 List of Orders







## **14.2 Directive Specification**

Representation rules:

•[]: indicates that the content in brackets appears 0 or 1 times, indicating optional

 $\cdot$  | : means "or", either of the two

·=: indicates the input assignment

·=>: Indicates output assignment

#represents a numeric value, Var represents a variable, and Str represents a string
 The light blue italic font indicates the values or variables that need to be filled in or selected
 during parameter setting

## **14.3 Motion Instructions**

### 14.3.1 Processing Mechanism of Motion Instruction

#### 14.3.1.1 Motion Command Preprocessing

The robot does not move a position by executing a line of motion instructions. In order to improve the smoothness of the movement, the teaching program analysis module of the control system will compile all the instructions in advance and perform preprocessing, and then send several movement instructions to the robot's motion stack according to the logic of the program itself. At this time none of the positions were reached. It is important to understand that the execution of the application program is independent of the movement of the robot. At the same time, the system provides a pause analysis command to facilitate the user to interrupt the ahead-of-time compilation mode of the program according to the actual situation.

#### 14.3.1.2 Motion Command Trajectory Transition

At the junction of two movement commands, because the speed change of the two movement commands before and after is not smooth, that is, the speed of the previous trajectory must be reduced to 0 before continuing to the next trajectory. This increases cycle time unnecessarily. By setting the transition section, the exercise time can be greatly reduced. When this Blend value is set to "Not used", the robot strictly arrives at every point of the trajectory. However when the Blend value is set to #Var or %, the trajectory will blend around each point and the robot does not strictly reach these points.

131



14.3.2 Movj Axis Motion

Movj trajectories and examples:

Movj commands are used to program point-to-point motions (axis motions). To optimize the speed of movement, the center of the tool follows a system-defined curve between the start and end points. Positions between points are interpolated by axis.



Figure 38 Movj trajectory and command

Movj	(Joint	movem	ent)
1.Target	#P	•	1
2.Speed	96	•	20.00
3.Blend	96	•	0
4.EXT Axis Group	<b>A</b>		В
	c		D

Figure 39 Movj Parameter Settings

Instruction format	MovjP=Poi	MovjP=PointV=Sped%[Bl=Blend%][Ext=[A-D]]			
Examples	MovjP=#P	1V=20%Bl=20%Ext=A;			
	target	Point: can be axis space or cartesian space point			
Parameter Description	speed	Speed:Synthetic speed at the end of joint space, speed = % * maximum synthetic speed at the end of joint space. The value is from 1 to 100, and the default value is 20			
	Blend	Blend: axis space blend radius, blend radius =%* total length of axis space trajectory.			
	EXT Axis	Ext: External axis group number of synchronous motion			



	Group	required, multiple selection is allowed. For Movj, there is
		only the synchronous motion planning of the robot and the
		external axis, and there is no strict position following
		planning. The speed of the external axis is the smaller of
		both the robot movement speed and the maximum speed
		allowed for the external axis, and there is no need to set the
		speed of the external axis itself separately.
Precautions		

### 14.3.3 Movs joint spline motion

Movs trajectory and example:

The Movs command performs b-spline motion in joint space.



#### Figure 40 Movs trajectory and instructions

Movs				Movement	X
1.Target	#P	•	1	Movj	
2.Speed	96	•	20.00	Movs	
3.Weight	1.0			Movi	
4.Type	Nouse			Movc	
5.Blend	Nouse			Movc2	
				Movc3	
				Movp	

## 14.3.4 Movl Linear Motion

Movl Motion Trajectories and Examples

Rectilinear motion in Cartesian space, including pose following and planning.









Figure 42 Movl Parameter Settings

Instruction	MovIP= <i>Point</i> (V= <i>Speed</i> mm/s[BI= <i>Blend</i> mm]) (OriV= <i>OriSped</i> %[OriBI=% <i>OriBlend</i> ]					
format	)[Ext=[A-D]]					
Examples	MovIP=#P1V=20mm/sBI=10mmExt=A; MovIP=#P1OriV=20%OriBI=10%Ext=A;					
	Point	<i>Point</i> : Can be an axis space or Cartesian space point.				
Parameter Description	Speed	Speed: Cartesian-space end path resultant speed, in:mm/sOriSped: Cartesian Space Posture End Resultant Velocity Percentage, Velocity =%* Posture End Resultant Maximum Velocity.				
	Blend	<i>Blend</i> : Cartesian space blend radius, units:mm; <i>OriBlend</i> : Cartesian space end pose blend percentage, blend angle =%* pose space trajectory total angle.				
	EXT axis	The number of the external axis group that needs to move				



	group	synchronously can be selected multiple times. Whether the			
		synchronous motion is position following depends on whether			
		the corresponding PCS recorded by the position point moves			
		with the corresponding external axis.			
	OriMode	Standard, PathFrame, JointSpace			
	OirDir	Posture planning, default Min, Max as required			
	1. After setting Speed and Blend, the path is planned and the posture is				
Dragoutiens	followed.				
Precautions	2. After OriSpeed and OriBlend are set, the pose is planned and the path is				
	followed.				



#### 14.3.5 Movc Circular Motion

Movc trajectory and examples

Arc motion in Cartesian space, including posture following. In a circular motion, the tool center point moves along an arc defined by 3 points, with circular interpolation between the start point, middle point and end point.



Figure 43 Movc trajectory and command

The arc command needs 2 position points, which represent the middle point and the end point of the arc respectively, and the current position of the robot or the end position of the previous action is the starting point of the arc. A complete circle requires 4 position points, realized by 2 Movc instructions.

MovC	(Cir <mark>cula</mark> r r	nove	ment)	
1.Target	#P	¥	1	
Middle Point	#P	•	1 20.00	
2.Speed	mm/s			
3.Blend	Null			
4.Angle	Auto	▼		
5.EXT Axis Group	A [	в	_ c 🗌 d	,
6.Mode,Dir	Standard	w	Min	,
7.ViaMid	Blend	•		

Figure 44 Movc Parameter Settings

```
Instruction Movc P=EndPoint Mid=MidPoint V=Speed mm/s[Bl=Blend mm]
```


format	[Deg=Degree	![Ext=[A-D]]		
Examples	MovcP=#P1Mid=#P2V=20mm/sBl=10mmDeg=108Ext=A;			
	Target	<i>EndPoint:</i> The end point of the arc, can be joint space or Cartesian space point;		
	Middle point	<i>MidPoint:</i> The middle point of the arc,can be joint space or Cartesian space point.		
	Speed	Speed: Cartesian-space end path resultant speed, in:mm/s。		
	Blend	Blend: Cartesian space blend radius, units:mm。		
	Angle	Degree: the arc angle of the actual motion, for example, a full circle, by default it is an arc angle formed by three points, supports negative numbers, optional.		
	EXT axis group	Ext: external axis group number to be synchronized, multiple choices are allowed, same as MovL.		
	Mode,Dir	Standard, PathFrame, JointSpace		
	Viamid	Posture planning, default Min, Max as required 应为blend 和ignore		
Precautions	Arc trajector not supporte	y, pose planning, path following situation is unreasonable, d.		



### 14.3.6 MovjUntil Conditional Interrupt Movj

Joint movement, if the custom Boolean expression becomes True during the movement, stop the current instruction or directly execute the next instruction; Otherwise the movement is in place. This type of command does not support the setting of transition parameters and does not support synchronous motion.



Figure 45 11.3.5 MovjUntil Parameter Settings

Instruction format	MovjUntil F	P=Point V=Speed% Cond=Condition? =>ReachEnd
Examples	MovjUntil F	P=#P1V=20%Cond=(#Var1<<5)=>#Var10;
	Target	<i>Point</i> : Target point, which can be joint space or Cartesian space point.
	Speed	Speed: Joint space end resultant velocity, unit:degree/s。
Parameter	Condition	<i>Condition?</i> : Custom Boolean expression. For example, #Var1<<5.
Description	Output	ReachEnd: If Condition is False, the target point is reached, ReachEnd=True; If Condition is True before reaching the target point, it means to leave or stop halfway, the target point is not reached, and ReachEnd=False . ReachEnd is a BoolVar.
	Trigger	
Precautions		

### 14.3.7 MovlUntil Conditional Interrupt Movl

MovlUntil Cartesian space linear motion, if the Boolean expression becomes True during the motion, stop the current instruction or directly execute the next instruction; Otherwise the



movement is in place. This type of command does not support the setting of transition

parameters and does not support synchronous motion.

MovIUntil	(Movl wit	h condi	tional interrupt
1.Target	#P	•	1
2.Speed	O Linear	v	Angular V
	mm/s	•	20.00
3.Condition	0		
4.Output	#Var	•	Null
5.Trigger	#P	•	Null

Figure 46 MovlUntil Parameter Settings

Instruction	MovlUntil P=	= <i>Point</i> (V <i>=Speed</i> mm/s) (Ori= <i>OriSpeed</i> %)		
format	Cond= <i>Condition?</i> =>ReachEnd			
Examples	MovlUntil P=#P1V=20mm/sCond=(#Var1<<5)=>#Var10;			
	MovlUntil P=#P1OriV=20%Cond=(#Var1<<5)=>#Var10;			
	Target	<i>Point</i> : Target point, which can be joint space or Cartesian		
		space point.		
		Speed: Cartesian-space end path resultant speed,		
		unit:mm/s;		
	Speed	<i>OriSpeed</i> : Cartesian space end pose resultant velocity		
		percentage, velocity =%* pose end resultant maximum		
Parameter		velocity.		
Description	Condition	<i>Condition</i> ?: Custom Boolean expression. For example,		
	Condition	#Var1<<5.		
		ReachEnd: If Condition is False, the target point is reached,		
		ReachEnd=True: If Condition is True before reaching the		
	Output	target point,it means leaving or stopping halfway and not		
		reaching the target point,ReachEnd=False. ReachEnd is a		
		BoolVar.		
	Trigger			
	Select one b	etween Speed and OriSpeed. The former represents path		
Precautions	planning and	d posture following;The latter is pose planning and path		
	following.			



### 14.3.8 MovcUntil Conditional Interrupt Movc

MovcUntil Cartesian space arc motion, if the Boolean expression becomes True during the motion, stop the current instruction or directly execute the next instruction; Otherwise the movement is in place. This type of command does not support the setting of transition parameters and does not support synchronous motion.

1.Target	#P	•	1
Middle Point	#P	•	1
2.Speed	mm/s	•	20.00
3.Angle	Auto	•	
4.Condition	0		
5.Output	#Var	•	Null
6.Trigger	#P	w	Null
7.ViaMid	Blend	v	

Figure 47 MovcUntil Parameter Settings

Instruction	MovcUntil	P=EndPoint Mid=MidPoint V=Speed mm/s[Deg=		
format	Degree] Cond=Condition? =>ReachEnd			
Examples	MovcUntil	MovcUntil P=#P1Mid=#P2V=20mm/sDeg=108		
Examples	Cond=(#Va	/ar1<<5)=>#Var10;		
	Target	<i>EndPoint:</i> the end point of the arc, which can be a joint space		
	laiget	point or a Cartesian space point;		
	Middle	<i>MidPoint</i> : The middle point of the arc, either in joint space or		
	point	Cartesian space.		
Parameter	Speed	Speed : Cartesian-space end path resultant speed, unit:mm/s。		
Description		<i>Degree</i> : the arc angle of the actual motion, such as a full circle.		
	Angle	The default is the arc angle formed by three points. Negative		
		value is supported and optional.		
	Condition	<i>Condition?</i> : Custom Boolean expression. For example, #Var1<<5.		
	Output	ReachEnd: If Condition is False, the target point is reached,		



		ReachEnd=True: If Condition is True before reaching the target
		eachEnd=False if the target point is not reached. ReachEnd is a
		BoolVar.
	Trigger	
	ViaMid	
Precautions		

### 14.3.9 MoveExt Outer Axis Set Articulation

The MoveExt external axis group joint movement, and the robot chooses whether to follow the motion or not according to the set parameters.

1.Target	#P		1
2.Speed	96	•	20.00
3.Blend	%		0

Figure 48 MoveExt Parameter Settings

Instruction format	MoveExt P	P=Point V=Speed%[BI=Blend%][Ext=[A-D]]
Examples	MoveExt P	P=#P1V=20%Ext=A
	Target	<i>Point</i> : Target point, using only the relevant part of the external axis.
	Speed	Speed: Joint space end resultant velocity percentage, velocity =%* Joint space end resultant maximum velocity.
Parameter	Blend	Blend: Percentage of joint space blend radius, blend radius =%* total axis space trajectory length.
Description		Ext: the external axis group number which requiring synchronous motion, with values of A,B,C and D. If Ext is not
	EXT Axis	selected, all external axes move together. Whether the
	Group	synchronous motion of the robot is position following the
		external axis depends on whether the PCS recorded by the
		position point moves together with the external axis.
Precautions		



### **14.4 Motion Parameters**

### 14.4.1 SetDyn Acceleration/Deceleration and Acceleration Time

Acceleration/deceleration magnification setting and jerk time setting.

SetDyn (	Set the acc,	dec and jerk)
1.Acceleration	100%	
2.Deceleration	90%	
3.Jerk time	200ms	

Figure 49 SetDyn Setting Interface

Instruction format	SetDyn Acc=	#%Dec=#% JerkTime=#
Examples	SetDyn Acc=	1%Dec=1% JerkTime=128ms;
	Acceleration	Acc: Global acceleration percentage, all instructions apply next.
Parameter Description	Deceleration	Dec: Global deceleration percentage, all subsequent commands apply.
	jerk time	JerkTime: jerk time, unit:ms, ranging from 32 to 512 milliseconds, and the default value is 128.
Precautions		·

### 14.4.2 SetSpeed Global Speed Percentage

Adjust the speed percentage of the motion command following this statement.

SetSpeed	(Set th	ne globa	l speed)
1.Global speed, %	96	•	20.00

#### Figure 50 SetSpeed Parameter Setting

Instruction	SatSpaad Val-#%		
format			
Examples	SetSpeed Vel=20%;		
Parameter	global speed Global speed percentage		
Description			
Precautions	If you do not call the SetSpeed command, the program defaults is 20%.		



### 14.4.3 SetCoord Coordinate System Switching

Coordinate system switching is applicable to all subsequent motion commands, and coordinate points in Cartesian space are recorded until the next SetCoord command is encountered, or the switching is canceled when ResetCoord is encountered.



Figure 51 SetCoord Settings

Instruction	SotCoord Tur	no- Tupeldy-#			
format	Setcoord TypeTux-#				
Examples	SetCoord Type=PCSIdx=1;				
Parameter	coordinato	<i>Type</i> : Coordinate system type, optional KCS,PCS,WCS;			
Description	coordinate	Idx: Coordinate system serial number.			
Procentions	This instruction takes effect for the location points between SetCoord				
Precautions	and ResetCoord.				

### 14.4.4 ResetCoord Coordinate System Switching Reset

The coordinate system stops switching and returns to the coordinate system recorded in the command itself. Refer to SetCoord command.

### 14.4.5 SetTool Coordinate System Switching

The tool coordinate system switch is applicable to all subsequent motion commands until the next SetTool or ResetTool is encountered to cancel the switching.



1.Tool coordinate No 1

#### Chart 52 SetTool Settings

Instruction	CotTool Indo	<u>.</u>				
format	Set roor mue.	et i ooi index=#				
Examples	SetTool Inde	SetTool Index=1				
Parameter	Tool	Index: Tool coordinate system serial number				
Description	coordinate					



	No.	
Precautions	This comman	d is valid for the position points between SetTool and
	ResetTool.	

### 14.4.6 ResetTool Coordinate System Switching Reset

The tool stops switching and returns to the tool number recorded in the command itself, refer to SetTool command.

### 14.4.7 SetOriMode Posture planning mode setting

Set the posture planning mode, and all the following Cartesian space motion instructions will take

effect until the next SetOriMode or ResetOriMode is encountered.

2	econmode (	Set TODOL ON I	noue
Mode	Standard	T	
	Standard		
	Unchange		
	Rotate		
	Normal		

Figure 53 SetOriMode Settings

Instruction format	SetOriMode Mode=Standard Unchange Rotate Normal			
Examples	SetOriMode Mode=Standard;			
Parameter Description	Mode	Mode: Standard, Unchange, Rotate, Normal.		
Precautions	This instruction is valid for the position points between SetOriMode and ResetOriMode.			

### 14.4.8 ResetOriMode posture Mode Reset

Resumes the posture standard follow mode Standard.

### 14.4.9 SetOffset Position Offset Setting

Set axis space position point, Cartesian position point and external axis position point offset.



	SetOffset	(Start	to offset)	
1.Type	Joint	•	NULL	
2.Value	J1: 0.00		J2: 0.00	
	J3: 0.00		J4: 0.00	
	J5: 0.00		J6: 0.00	
	J7: 0.00		J8: 0.00	

Figure 54 SetOffset Parameter Setting

Instruction	SetOffset	Type="A	kis"   " <i>Pose</i> " (J1=#	tJ2=#J3=#J4=#J5=	#J6=#J7=#J8=#)	(X= <b>#</b> Y= <b>#</b> Z= <b>#</b> [Roll
format	=#Pitch=	=#Pitch=#Yaw=#])				
	SetOffset	Type=Ax	isJ1=5.00J2=10.0	00J3=0.00J4=0.00	J5=0.00J6=0.00J7	/=0.00J8=0.00;
Examples	SetOffset	t Type=Po	seX=5.00Y=10.0	0Z=0.00Roll=0.00	Pitch=0.00Yaw=0	0.00;
	SetOffset	Type=Po	seX=0Y=0Z=0Ro	ll=10Pitch=10Yaw	/=10	
		Type: off	set type, robot j	oint offset, Cartes	sian position poin	t offset 1. J1, J2,
		J3, J4, J5,	J6, J7, J8 axis po	osition offset or e	xternal axis offset	;
Parameter	Туре	2.X, Y, Z:	position offset;			
Description		3.Roll, F	Pitch, Yaw: Po	sture offset.		
	offset			offcot valu	10	
	value			Unset Valu	ie	
	Joint	zero N	offset+joi	nt directio	on I A	١Ą
Precautions	Direction: St Zero point: horizontal th Joint direct Encoder v tion Display jo The input cal joint a The curre This ins	andard+1 eoretical position ction and zerc value → theor int angle → th of forward kin ngle nt angle is als truction is	Direction: Standard+1 Zero point: - 90 degrees offset relative to stand etical joint angle $\rightarrow$ dis neoretical joint angle= $\alpha$ nematics is the theoret so the theoretical joint a s valid for the point	Direction: Standard+1 Zero point:+90 degrees dard case splayed joint angle= (theo tisplay joint angle * joint ical joint angle, and the angle calculated from the position points betw	Direction: Reverse - 1 Zero: - 90 degrees oretical joint angle - zero direction+zero point offs output of inverse kinema e data obtained by the en ween SetOffset an	Direction: reverse+1. Zero point:+90 degrees offset) * joint direc- set tics is the theoreti- ncoder nd ResetOffset.



### 14.4.10 ResetOffset Position Offset Cancellation

Joint Position Point Offset no longer works and is often paired with SetOffset.

## 14.5 Operation of IO

## 14.5.1 SetDo Output Digital Quantity

	SetDo	(Dig	ital output)
1.Module	0		
2.Pin	Idx=	▼	1
3.Output	Int (0,1)	-	0

Figure 55 SetDo Settings

Instruction format	SetDo Val= <i>Value</i> Grp= <i>Group</i> Idx=#  <i>ALL</i>				
Examples	SetDo Val=1Gr	p=0ldx=1;			
	SetDo Val=0b1	111Grp=1ldx=All;			
	Module	Group:Group: Indicates w controller software consid	which group of digital outputs, the ders 16 IOs as a group.		
Parameter Description	Pin	Idx.: Indicates the IO sequ selected, it indicates that	x.: Indicates the IO sequence number in the group. If <i>ALL</i> is elected, it indicates that the group is output together.		
	Output	<i>Value</i> : Indicates that the oselected, <i>Value</i> is the bina	digital output is 0 or 1. If <i>ALL</i> is ary number 0b01100110.		
	× 15	Delete 🔇 💙 Co	If ALL is selected, Val is		
	<b>1</b> 2	✓ 3 ✓ 4 Set all to 1	interpreted as binary. When		
Precautions	5 6	7 8 Set all to 0	you modify the output value, a		
	9 10	11 12 Generate	but is displayed as a 0b binary		
	13 14	15 16	number. The same below		



### 14.5.2 SetDoAt Output IO in Motion



#### Figure 56 SetDoAt

Instruction		CatDa AtDia Diatagan Val Valua Cara Canava Idu, #1 AU [Tal Dalawara]					
format	Selbo Alb	Serbo Arbis-Distance val-value Grp=Group lax=#[ALL [1d=Delay lins]					
Evamples	SetDo AtD	SetDo AtDis=7mm Val=1 Grp=1 Idx=1 Td=5ms;					
Examples	SetDo AtD	SetDo AtDis=7mm Val=0b1111 Grp=1 Idx=All Td=5ms;					
	distanco	<i>Distance</i> : indicates the distance from the target point,					
	uistance	unit:mm.					
D	Modulo	<i>Group</i> : indicates which group of digital outputs, and the					
	wiodule	controller software considers 16 IOs as a group.					
Description	Din	Idx: Indicates the IO sequence number in the group. If ALL					
Description	PIN	is selected, the group is output together.					
	Output	Value : Indicates that the digital output is 0 or 1. If ALL is					
	Output	selected, value is the binary number 0b01100110.					
	Delay	<i>Delay</i> : indicates the delay time, unit ms.					
Precautions	This instru	This instruction is valid only for the previous instruction.					

### 14.5.3 SetDoDeltaS Output Digital Quantity in Motion



Figure 57 SetDoDeltaS Settings

Instruction SetDoD	eltaS Dis= <i>DeltaS</i> Val= <i>Value</i> Grp= <i>Group</i> Idx=#  <i>ALL</i> Width=#ms
--------------------	--



format					
<b>F</b>	SetDoDelta	SetDoDeltaS Dis=50mm Val=1 Grp=1 ldx=1 Width=2ms;			
Examples	SetDoDelta	S Dis=50mm Val=0b1111 Grp=1 Idx=All Width=2ms;			
	Interval	DaltaSt indicator the congration distance in mm			
	distance	Deltas. Indicates the separation distance, in film			
	Madula	Group: indicates the group of digital outputs, and the			
	wodule	controller software considers 16 IO as a group.			
Parameter	Din	Idx: Indicates the IO sequence number in the group. If ALL is			
Description	PIN	selected, the group is output together.			
	Output	<i>Value:</i> Indicates that the digital output is 0 or 1. If <i>ALL</i> is			
	Output	selected, value is the binary number <i>0b01100110</i> .			
	Delay	Width: Indicates the signal duration in ms.			
Precautions	This instrue	ction is valid only for the previous instruction.			

# 14.5.4 SetDoDeltaT Output Digital Quantity in Motion

SetDoDeltaS (Equitime DO on the path)				
1.Interval time	Oms			
2.Module	0			
3.Pin	Idx=	•	1	
4.Output	Int (0,1)	▼	0	
5.Duration	1ms			

Figure 58 SetDoDeltaT Settings

Instruction format	SetDoDeltaT Time= <i>DeltaT</i> Val= <i>Value</i> Group=# Idx=#  <i>ALL</i> Width=#ms				
Examples	SetDoDeltaT Time=5ms Val=1 Group=1 Idx=1 Width=1ms;				
	SetDoDeltaT Time=5ms Val=0b1111 Group=1 ldx=All Width=1ms;				
	Interval time DeltaT: represents the time interval in ms.				
	Module	<i>Group:</i> indicates which group of digital outputs, and the			
Parameter		controller software considers 16 IOs as a group.			
Description	Pin	Idx: Indicates the IO sequence number in the group. If ALL is			
		selected, the group is output together.			
	Output	<i>Value:</i> Indicates that the digital output is 0 or 1. If <i>ALL</i> is			
		selected, <i>value</i> is the binary number <i>0b01100110</i> .			



	Delay	Width: Indicates the signal duration in ms.
Precautions	This instruction is valid only for the previous instruction.	

## 14.5.5 GetDo Digital Output Reading

GetDo	(Get DC	) then sa	ave to variable)
1.Module	0		
2.Pin	Idx=	•	1
3.Output	#Var	•	0

#### Figure 59 GetDo Parameters

Instruction format	GetDo Grp= <i>Group</i> Idx=#/ALL=>#Var#			
Examples	GetDo Grp=1 Idx=1=>#Var2; GetDo Grp=1 Idx=All=>#Var2;			
Parameter Description	Module	<i>Group</i> : indicates which group of the digital outputs, and the controller software considers 16 IOs as a group.		
	Pin	Idx: Indicates the IO sequence number in the group. If <i>ALL</i> is selected, the group is output together.		
	Output	The digital output value is stored in a numeric variable.		
Precautions				

# 14.5.6 GetDi Digital Quantity Input Acquisition

GetD	i (Get DI	then sa	ve to variable)
1.Module	0		
2.Pin	Idx=	•	1
3.Output	#Var	•	0

#### Chart 60 GetDi Parameters

Instruction	GotDi Gra-Group Idv-#->#War#			
format				
Evennles	GetDi Grp=1 Idx=1=>#Var2;			
Examples	GetDi Grp=1 Idx=All=>#Var2;			
Parameter	Module	<i>Group</i> : indicates the group of digital inputs, and the		
Description		controller software considers 16 IO as a group.		



Output	Digital input values are stored in numeric variables.
Pin	Idx: Indicates the IO sequence number in the group. If <i>ALL</i> is selected, the group is imported together.

## 14.5.7 SetAo Output Analog Quantity

	SetAo	(Analog	output
1.Output	Value	•	0.00
2.Pin	0		

Figure 61	SetAo	Parameter	Setting
-----------	-------	-----------	---------

Instruction		alue Idv-#			
format	SetAO Val=Value lax=#				
Examples	SetAo Val=7.	00 Idx=1;			
Parameter	output	<i>Value</i> : Indicates the analog output value.			
Description	Pin	Idx: Indicates the IO sequence number in the group.			
Precautions					

# 14.5.8 SetAoAt Output Analog Quantity in Motion

SetAoAt	(AO befo	re reac	hing the target)
1.Distance	0mm		
2.Output	Value	•	0.00
3.Pin	0		
4.Delay	None		

Figure 62 SetAoAt Parameter Setting

Instruction format	SetAoAt Dis= <i>Distance</i> Val= <i>Value</i> Idx=# [Td= <i>Delay</i> ms]			
Examples	SetAoAtDis=10mmVal=8.00Idx=25ms;			
Parameter	Distance	<i>Distance:</i> Indicates the distance from the target point, unit mm.		
Description	Output	Value: Represents the analog value.		
	Pin	Idx: Indicates the IO sequence number in the group.		
	Delay	<i>Delay</i> : indicates the delay time,unit:ms.		



Precautions

This instruction is valid only for the previous instruction.

### 14.5.9 GetAo Analog Output Acquisition

GetA	D (Get A	) then sa	ave to variable)
1.Pin	0		
2.Output	#Var	•	1

Figure 63 GetAo Parameter Setting

Instruction	GetAo Idx =	#=>#Var#
format		
Examples	GetAo Idx=1	L =>#Var2;
Parameter	Pin	Idx: Indicates the IO sequence number in the group.
Description	Output	Analog input values are stored in variables.
Precautions		

## 14.5.10 GetAi Analog Input Acquisition

GetA	i (Get Al	then sa	ve to variable)
1.Pin	0		
2.Output	#Var	-	1

Figure 64 GetAi Parameter Setting

Instruction	CotAildy - #	>#\/ar#	
format	$\operatorname{GetAT}\operatorname{Iux} = \# = 2 \# \operatorname{Vur} \#$		
Examples	GetAi Idx=1 =	=>#Var2;	
Parameter	Pin	Idx: Indicates the IO sequence number in the group.	
Description	Output	Analog input values are stored in variables.	
Precautions			



# 14.5.11 Wait for the condition to complete

Wa	ait (Wait	t until)	
1.Condition	0		
2.Time (ms) 0-Keep waiting	Keep Wa	iting	
3.Timeout output 0-No output	#Var	•	Null
4.Wait in advance (mm) 0-Invalid	Invalid		

Figure 65 Wait Parameter Settings

#### Wait for a Boolean expression

Instruction	Wait Cond=Con	dition? [Time = #ms => #Var#]	
format			
Examples	Wait Cond=(#Var1>>5) Time=5ms =>#Var2;		
	condition	<i>Condition?</i> : Custom Boolean expression.	
Parameter	Time(ms)	Time: indicates the upper limit of the waiting time. If not	
Description	0-Keep waiting	set, it means to wait all the time (in s).	
	timeout output	#Var# is True if timeout occurs. False otherwise	
	0-No output		
	Wait in		
	advance(mm)		
	0-invalid		
Precautions			

### 14.5.12 Pulse Output

The digital output is set to 1 and held for a period of time, then set to zero

	Pulse (Pu	lse output)
1.Module	0	
2.Pin	0	
3.duration	0ms	

Chart 66 Pulse Parameter Settings

Instruction	Pulse Grp=Group Idx = #Width = #ms
format	



Examples	Pulse Grp=1	ldx=1 Width=5ms;
	Madula	<i>Group</i> : indicates which group of the digital inputs, and the
Parameter	wodule	controller software considers 16 IOs as a group.
Description	Pin	Idx: Indicates the IO sequence number in the group.
	Duration	Width indicates the setting time in ms.
Precautions		

## 14.6 Motion Management

### 14.6.1 Delay

	Delay (Delay)	
1. Delay time	1ms	

#### Figure 67 Delay Parameter Setting

Instruction	Delay Time-	ttms			
format	Delay Time-	π113,			
Examples	Delay Time=	Delay Time=2000ms;			
Parameter	Delay time	Timing time in ms			
Description					
Precautions		·			

### 14.6.2 WaitExecutor Stops Decoding

Stop teaching instruction decoding in advance, wait for the robot to actually execute the current

instruction line and then automatically start decoding.

Examples	WaitExecutor;

### 14.6.3 tod Get System Timing

		T	od (Get t	he curre	ent timin	g)		
		1.Result:	#GVar	•	1			
		= tod()						
		F	igure 68 to	od param	eter setti	ng		
Instruction	#\/ar#= too	4/).						
format	# <i>vur#</i> - tot	J(),						
Examples	#Var1= too	d();					 	



	#Var2=tod();		
	#Var3=#Var2-#Var1;		
	Record a time at time T1 and put it into variable #Var1;Record a time at		
	T2 and put it in variable #Var2;The time difference between T1 and T2 is		
	equal to the value of #Var2 minus the value of #Var1.		
Parameter	Rosult	The recorded time is stored in #War#	
Description	Nesur		

### 14.6.4 SysDate Record system timing

	SysDa	ate 记录系	系统时间	
变量	#Var	*	1	
	#Var			
	#GVar			

#### Figure 69 SysDate parameter setting

Instruction	SysDate =>#Var#				
format					
Examples	SysDate =>#Var1;				
Parameter	Variable	Date:	The system time is recorded in a string variable		
Description		Dute.			

### 14.6.5 Pause

Stop execution and wait for external signal to restart

Examples Pause;

### 14.6.6 GetPoint Save Current Position

Get Tool End Position

GetPoint	(Get pos	ition th	en save to Var)
1.Coordinate	KCS	•	
2.Output to	#P	•	1

#### Figure 70 GetPoint Parameter Settings

Instruction	GetPoint <b>Type</b> => P= <b>Point</b>



format		
Examples	GetPoint KC	S=>#P1;
Parameter	coordinate	Type Coordinate system model, KCS,WCS,PCS,ACS.
Description	Output to	Point stores the location point.
Precautions		

## **14.7 Control Process**

### 14.7.1 Call Subroutine

			When the robot end moves to point P1,	
			start to execute the third line of program:	
			Call the subroutine named "call", after the	
	1	PROCEDURE	execution of the subroutine "call", return to	
	2	Movj P=#P1 V=20%;	the original program to continue execution	
Examples	3	CALL call;	of the fourth line of the program to move	
	4 Movl P=#P2 V=20mm/s; 5 ENDPROCEDURE	MovI P=#P2 V=20mm/s;	to point P4.	
		Note: The calling and called programs must		
			be in the same project. Subprogram name:	
			can only contain alphanumeric underscores	
			and cannot start with a number.	

# 14.7.2 JUMP-LABEL Flag

Examples	2	Movj P=#P1 V=20%;	After the end of the robot moves to point			
	3	JUMP 1;	P1, it jumps to the fifth line labeled			
	4	Movj P=#P2 V=20%;	with"1"and moves down to the sixth line t			
	5 6	LABEL 1; Movj P=#P3 V=20%;	point P3			



## 14.7.3 IF Conditional Judgment





### 14.7.4 ELSELF Condition Judgment

Refer to IF flow chart.



		After the robot end moves to the point
		P1, judging the condition 1(whether the
	2 Movj P=#P1 V=20%;	value of #Var1 is equal to 5), if the value is
	3 IF (#Var1=5) THEN; 4 Movel P=#P2 V=20mm/s:	equal to 5, run the fourth row, move to
Fyerenlee	5 ELSEIF (#Var1 = 8) THEN;	the point P2, and the judgment end;
Examples	6 Movl P=#P3 V=20mm/s;	judging condition 2(whether the value of
	7 ELSE; 8 Movi P=#P4 V=20mm/s;	#Var1 is equal to 8), if the value is equal
	9 ENDIF;	to 8, run the sixth line, move to point P3,
		and the judgment end; otherwise move
		to point P4.

### 14.7.5 WHILE Cycle Condition Judgement

WHILE loop: conditional loop, first judge and then execute, if the condition is not established, exit the loop.



Figure 72 WHILE Flow Chart



		The robot end runs to P1 (transition point), sets the value of #Var1 to 1,
Examples	<pre>2 Movj P=#P1 V=20%; 3 #Var1 = 1; 4 WHILE (#Var1&gt;=10) DO; 5 Movj P=#P2 V=20%; 6 Movj P=#P3 V=20%; 7 #Var1 = #Var1 + 1; 8 ENDWHILE;</pre>	determines that the value of condition 1 is False (condition 1 is not satisfied), and executes the program to move to points P2, P3, and #Var1+1 in a loop until condition 1 is satisfied when #Var1=10, and exits the loop. The end of the robot makes a total of 9 round trips between P2
		and P3.

# 14.7.6 FOR Loop Condition Judgment

FOR	#Var	V	1
	FROM: 1		TO: 1
	STEP: 1		

#### Figure 73 For Loop

		By default, the value of #Var#is set to
Instruction format	FOR#Var#FROM#1TO#2STEP#3DO; Procedure 1; ENDFOR;	#1, and when the value of #Var#is in the
		interval [#1, #2], the program 1 is
		executed in a loop, and the number of
		loop steps is #3, that is,#Var#is added by
		#3 once in each loop (#Var#=#Var#+#3).
	<ul> <li>2 Movj P=#P1 V=20%;</li> <li>3 FOR #Var1 FROM 1 TO 10 STEP 1 DO;</li> <li>4 Movi P=#P2 V=20mm/s;</li> <li>5 Movi P=#P3 V=20mm/s;</li> <li>6 ENDFOR;</li> </ul>	The end of the robot first runs to
		P1(transition point), and then runs 10
		times between points P2 and P3 before
Example 1		exiting the FOR loop. (The value of
		#Var1 is set to 1 at the first cycle, +1
		each time, until #Var1=11>10 after 10
		cycles, exit the cycle)



		The end of the robot first runs to
	9 Movj P=#P1 V=20%;	P1(transition point), and then loops
	10 #Var1 = 1;	between points P2 and P3 for 5 times
Example 2	11 FOR #Var1 FROM 1 TO 10 STEP 2 DO; 12 Movi P=#P2 V=20mm/s;	before exiting the FOR loop. (The value
	13         Movl P=#P3 V=20mm/s;           14         Movc P=#P1 Mid=#P1 V=20mm/s;	of #Var1 is set to 1 in the first cycle, +2
	15 ENDFOR;	each time, until #Var1=11>10 after 5
		cycles, exit the cycle)

### **14.8 Notes and Calculations**

### 14.8.1 /\*\*/ Multi-line Note

	4	/*FOR #Var1 FROM 1 TO 10 STEP 1 DO;	Insert {/* multiline comment} at the start
	5	Movi P=#P2 V=20mm/s;	
Examples	6	Movi P=#P3 V=20mm/s;	line and {*/multiline comment} at the end
	7	Move P=#P1 Mid=#P1 V=20mm/s;	
	8	ENDFOR;*/	line. Uncomment and repeat.

### 14.8.2 Comment/Uncomment Current Line

Examples	//Movi P=#P1 V=20%.	Click {// Comment / Uncomment Current	
Examples	//////////////////////////////////////	Line }tocomment or uncomment	

### 14.8.3 ASSIGN (=) Assignment

ASSIGN (=) Assignment



#### Figure 74 Assignment

Instruction	A=B
	#GVar1=#Var1;
Examples	#Var1=1.58;
	#GStr1=#Str5;
	#Str1="jjkkll";
	#GP1=#GP5;



	#GIncP1=#IncP2;
Parameter	assigning the value of B to A;
Description	Numeric variables , string variables , positional variables, and positional
Description	increment variables are supported.

# 14.8.4 ADD (+) Addition



Figure 75 Addition

Instruction	C=A+B	
format		
	#GVar1=#GVar1+1;	
Examples	#GVar1=#Var1+#Var2;	
	#GVar1=1+2;	
Parameter	adding the value of A and the value of B to C:Support for numeric variables	
Description		

# 14.8.5 SUB (-) Subtraction

	3	SUB (-)	
1.Result:	#GVar	•	1
=			
	#GVar	•	1

### Figure 76 Subtraction

Instruction	C-A-B
format	
	GVar1=#GVar1-1;
Examples	#GVar1=#Var2-#Var1;



	#Var1=5-1;
Parameter	subtracting the value of A from the value of B and assigning the value to
Description	C;Support for numeric variables

# 14.8.6 MUL(\*) Multiplication



Figure 77 Multiplication

Instruction	C-A*B
format	
	#GVar1=#GVar1*#Var2;
Examples	#GVar1=#GVar1*2;
	#GVar1=2*3;
Parameter	multiplying the value of A by the value of B and assigning the result to C;Support
Description	for numeric variables

# 14.8.7 DIV(/) Division

DIV (/)				
1.Result:	#GVar	▼	1	
=				
=	#GVar	•	1	

#### Figure 78 Addition

I	nstruction	C-A/B
f	format	
		#GVar1=#GVar1/#Var2;
E	Examples	#GVar1=#GVar1/2;
		#GVar1=2/3;



Parameterdividing the value of A by the value of B and assigning the value to C;Support forDescriptionnumeric variables

### 14.8.8 Expr Advanced Expressions/Statements

Expr advanced expression support:

- 1. Four arithmetic operations
- 2. Bit operation
- 3. Boolean operation
- 4. Mathematical function
- 5. String Handling

6		Delete	<	>	Co	nfirm
#Var	#GP	#P	#GStr	=	+	
#GIncP	#IncP	DO	DI	*	1	0
AI	Varia	ble IO		7	8	9
Math fun	Logic	String fun	Other		-	-
++		&	I	4	2	D
~~	>>		Symbol	1	2	3
	Symbols a	nd numbers a	re	0	10	Tab
	#Var #GIncP AI Math fun ++ <<	#Var     #GP       #GIncP     #IncP       AI     Varia       Math fun     Logic       ++        <<	Delete       #Var     #GP       #GIncP     #IncP       Math fun     Variabur       Math fun     Logic       *++        <	Delete       Constant         #Var       #GP       #P       #GStr         #GIncP       DO       DI         #GIncP       DO       DI         AI       Variabe IO       DI         Math fun       Logic       String fun       Other         ++        &       I         <<	DeleteDelete#Var#GP#P#GStr=#GIncP#IncPDODI*AIVariable IO7*7Math funLogicString funOther4++& 1<	DeleteDeleteImage: constraint of the state of the

Figure 79 Advanced Expression Interface

**Extended Description:** 

Operation

modulo
(remainder
operation)
self-increment
Auto-decrement
bitwise AND
bitwise OR
bitwise XOR



<<	left shift
>>	Right shift
~	negation

#### Mathematical function

ceil()	Rounded up
trunc(,)	variable rounding
exp()	e exponential function
log(,)	10 Logarithmic function
mod( <i>,</i> )	remainder function
sqrt(,)	square root
pow(,)	exponential function
sin()	sine
cos()	cosine
tan()	tangent
acos()	Arc cosine
asin()	Arc sine
atan()	Arc tangent
atan2()	arctangent (2 variables)
abs()	absolute value

Logic

&&	logical AND
	logical OR
!	logical not
>=	Greater than or equal to
<=	less than or equal to
>	greater than
<	less than
==	equal to
!=	Not equal to

Character function

strtovar()	Converts a string to a numeric type
vartostr()	Converts a numeric type to a string



strcat(,)	String concatenation
strlen()	Calculate string length
strcmp(,)	String comparison
strtok()	Separates a string into fragments based on the
50100(,)	delimiter

Other

tod()	Timing instruction

Chinese and upper and lower case switching

Click [Switch] in the lower right corner, and the left side will switch different input keys.

×	, a	1					Delete		:	>	C	onfirm
9	8		7	6	5		4	3	2		1	0
1	@	#	\$	96	^	8,	*	(	)		+	
q	w	e	r	t	у	u	I	0	p	-	1	1
а	s	d	f	g	h	j	k	I	:	-	?	=
z	x	c	v	b	n	m		x	spa	ace		Low

×	; ,	4					Delete	<	:	>	C	onfirm
9	8	5	7	6	5		4	3	2	Î	13	0
1	@	#	\$	96	٨	&	*	(	)	•	+	
Q	w	E	R	т	Y	U	I	0	Ρ	-	1	1
A	s	D	F	G	н	J	к	L	:	*	?	=
z	x	с	v	В	N	М		X	spa	ice	c	ар

Examples:





Figure 80 Example of an Advanced Expression

As in line 3: assign a value to the variable #Var

Line 6: IF statement (custom Boolean expression)

Can be entered through advanced expressions.

### **14.9 Mathematical Functions**

abs(X)	take absolute value
sqrt(X)	root sign
exp(X)	natural index
In(X)	natural logarithm
sin(X)	sine
cos(X)	cosine
tan(X)	tangent
asin(X)	arcsine
acos(X)	arccosine
floor(X)	Rounding down



ceil(X)	Rounding up
round(X)	Rounding off
trunc(X)	rounding
pow(X,Y)	X to the power of Y
mod(X,Y)	remainder of X to Y
atan2(X,Y)	arctangent

## 14.10 Character Functions

# 14.10.1 strlen (X) Finding the Length of a String

I.Result:	#GVar	•	1
= strlen(			
		i unai	log V

Parameter	Calculates the length of a string and stores it in a numeric variable
Description	calculates the length of a string and stores it in a numeric variable
Examples of	#Str1=asfsdfasg
instructions	#Var1=strlen(#Str1)
operation	#\/ar1=9·
result	

# 14.10.2 str2num(X) String to Real

		Str2num (S	String t	o number)		
	1.Result:	#GVar	•	<b>1</b>		
	= str2nu	ım(				
	Parm1:	#GStr	▼	1		
		)				
Parameter		Constanto	-			
Description		converts a	string	to a real V	ariable	



Examples of	#\/2r1=str2num(#Str1)
instructions	#var1=str21utit(#str1)
Parameter	It is generally used to convert a numeric string sent and received into a real
Description	number for calculation or assignment

# 14.10.3 num2str(X) Real to String

1.Result:	#GStr	•	1
= num2s	tr(		

Parameter	Converts a real variable to a string
Description	
Examples of	#Str1-num2str/#\/ar1)
instructions	
Parameter	It is generally used to transfer the x,y,z and other values of the location
Description	point out of the string and send it

# 14.10.4 strcat (X, Y) String Splicing

1.Result:	#GStr	•	1
= strcat(			
Parm1:	#GStr	•	1
Parm2:	#GStr	w	1

Parameter Description	Concatenate 2 strings into 1 string
Examples of	#Str2=asd
instructions	#Str3=fgh



	#Str1=strcat(#Str2,#Str3)
operation	#Str1-acdfab
result	#Sti 1-asuigii

### 14.10.5 strleft (X, N) Takes N characters to the left of the string X

1.Result:	#GStr	•	1
= strieft	(		
	-	12.21	4
Parm1:	#GStr	•	1

Parameter	Take Nicharasters from the left of string V
Description	
Examples of	#Str2=asdfgh
instructions	#Str1=strleft(#Str2,2)
operation	#Str1-ct
result	

## 14.10.6 strright (X, N) Takes N characters from the right of a string X

1.Result:	#GStr	•	1
= strright	c(		
Parm1:	#GStr	•	1
Parm2:			0

Parameter Description	Take N characters to the right of string X
Examples of instructions	#Str2=asdfgh #Str1=strright(#Str2,2)
operation	#Str1=gh



result	•
--------	---

### 14.10.7 strmid (X, M, N) Takes the M-th to N-th characters of the string X

1.Result:	#GStr	•	1
= strmid	(		
Parm1:	#GStr	•	1
Parm2:			0
Parm3:			0

Parameter Description	Take the M-th to N-th characters of the string X
Examples of instructions	#Str2=asdfgh #Str1=strmid(#Str2,3,4)
operation result	#Str1=df

# 14.10.8 strsplit (X, Y, N) String Split

1.Result:	#GStr	•	1
= strsplit	(		
Parm1:	#GStr	•	1
Parm2:			Split symbol
Parm3:			0

Parameter	Colit the string V according to the constator V and take the Nth sharastor
Description	Split the string x according to the separator f, and take the Nth character
Examples of	#Str2=a,s,d,f,g,h
instructions	#Str1=strsplit(#Str2,",",3);



operation	#C+r1_d
result	#Str1=0

### 14.11 Communications

# 14.11.1 TcpOpen opens tcp/ip communication

ТсрО	pen (Op	en TCI	P/IP)
1.Connect Name			
2.Connect Type	server	▼	
3.BlockTime	Oms		
4.ip:port	192.168.100.4		:1
5.Output	#Var	v	1

Examples of	TcpOpen name="imf" type=""server"" block=1					
instructions	addr="192.168.100.33:22" =>#Var1;					
	Connect	an identifier of the link, with which subsequent receive and				
	Name	send operations are associated;				
	Connect	link type,				
	tuno	server: Create a server;				
	lype	client: Create a client and link to the server;				
		if that instruction is bloc,				
Parameter	block time	1: Blocking time (ms); waiting time for instruction execution				
Description		0: non-blocking;				
	ip:port	IP address of the link: port; the server can listen to the				
		whole network port, so no ip is needed to create the server				
	output	output values,				
		>=0: Number of links maintained by the socket;				
		-1: The server is starting, and the client is linking;				
		-2: Failure;				



# 14.11.2 TcpRecv Receiving Data

TcpRecv (	Receive	data b	y TCP/IP)
1.Connect Name			
2.Save date to	#Str	•	1
3.BlockTime	Oms		
4.Output	#Var	•	1

Examples of instructions	TcpRecv name="imf" dest=#Str1 block=0 =>#Var1;			
	Connect Name	receiving a data link identifier, created by TcpOpen;		
	Save data to	a character string variable for storing the received data;		
Parameter Description	Block time	if that instruction is bloc, 1: Blocking time (ms); waiting time for instruction execution 0: non-blocking;		
	output	output values, >=0: Number of bytes received; -2: no corresponding identifier;		

# 14.11.3 TcpSend Sending Data

TcpSend	(Send d	ata by	TCP/IP)
1.Connect Name			
2.Send data from	#Str	▼	1
3.BlockTime	Oms		
4.Output	#Var	•	1

Examples of instructions	TcpSend name="imf" src=#Str1 block=0 =>#Var1;			
	Connect Name	Link identifier of the sending data, created by TcpOpen;		
<u> </u>				
Parameter	Send data	String variable for storing the sent data:		
Description from				
		if that instruction is bloc,		
	block time	1: Blocking time (ms); waiting time for instruction execution		



	0: non-blocking;
	output values,
output	>=0: Number of bytes sent;
	-3: no corresponding identifier;

# 14.11.4 TcpClose Closing a TCP/IP Connection

TroClose	Close	TCP/IP)
reperose	(CIOSE	icr/ir)

1.Connect Name

Examples of				
instructions	icpclose name="imf";			
Parameter	Connect	Class link identifier greated by TanOnan.		
Description	Name	close link identifier, created by TcpOpen;		

# 14.11.5 SerialOpen Receiving Data

SerialOpen (Open the serial port)			
1.Connect Name			
2.Address	0		0:rs232 4:rs485
3.Baud (k)	1200	T	8
4.Check	n I	•	n:none o:odd e:even
5.Stop bit	1		
6. <mark>Bloc</mark> kTime	Oms		
7.Output	#Var	•	1

Examples of	SerialOpen name="imf" addr=4 par="1200,8,n,1" block=0				
instructions	=>#Var1;	=>#Var1;			
	Connect	Open the serial port identifier, and the subsequent received			
Deremeter	Name	and sent data is related to this identifier;			
		Open the serial port address to 0, 1, 2 To mark;			
Description	Address	0: rs232;			
Description		4: rs485;			
	Baud(k)	The number of symbols transmitted per second			
	check	Select error detection mode, n: no check detection, o odd			


	check, e even check
	Indicates the end of a transfer and gives the computer an
	opportunity to correct clock synchronization. The more bits
stop bit	available for stop bits, the greater the tolerance for
	different clock synchronizations, but the slower the data
	transfer rate.
	if that instruction is bloc,
Block time	1: Blocking time (ms); waiting time for instruction execution
	0: non-blocking;
outout	0: The serial port is opened normally;
υπιραι	-1: failure;

### 14.11.6 SerialRecv Receiving Data

SerialRecv (F	Receive	data by	y serial port)
1.Connect Name			
2.Save data to	#Str	•	1
3.BlockTime	Oms		
4.Output	#Var	•	1

Examples	SerialRecv na	me="imf" dest=#Str1 block=0 =>#Var1;
	Connect	Serial port identifier for receiving data, created by
	Name	SerialOpen;
	Save data to	a character string variable for storing the received data;
Parameter		if that instruction is bloc,
Description	Block time	1: Blocking time (ms); waiting time for instruction execution
		0: non-blocking;
		output values,
	output	>=0: Number of bytes received;
		-1: Serial port is not open;



# 14.11.7 SerialSend Sending Data

SerialSend (	Send da	ta by s	serial port)
1.Connect Name			
2.Send data from	#Str	•	1
3.BlockTime	Oms		
4.Output	#Var	•	1

Examples of	SorialSond n	$a_{a} = a_{a}$
instructions	Senaisenu n	
	Connect	Serial port identifier for sending data, created by
	Name	SerialOpen;
	Send data	String variable for storing the contractor
	from	
Parameter		if that instruction is bloc,
Description	Block time	1: Blocking time (ms); waiting time for instruction execution
		0: non-blocking;
		output values,
	output	>=0: Number of bytes sent;
		-1 : Serial port is not open;

#### 14.11.8 SerialClose Closing a TCP/IP Connection

		SerialClose (Close the serial port)
	1	1.Connect Name
Examples of	Sorial Classo pr	amo-"imf".
instructions	Senaiciose na	ame= imi ;
Parameter	Connect	Class social part identifier, greated by SocialOpen.
Description	Name	close serial port identifier, created by serialOpen;

### 14.11.9 CanbusOpen Receiving Data



Canbus	Open (C	Open C	anbus)
1.Connect Name			
2.Address	0		
3.Bau <mark>d (</mark> k)	125	•	
4.Blocktime	Oms		
5.Output	#Var	v	1

Examples of instructions	CanbusOper	n name="imf" addr=1 par=125 block=0 =>#Var1;
	Connect	Open the canbus identifier, and the subsequent received
	Name	and sent data is related to this identifier;
	Address	Canbus address, marked with 0, 1, 2, currently there is only one canbus, fill in 0;
Parameter	Baud(k)	Canbus baud rate: 125 means 125k, in addition to the commonly used 1000k, 500k, 250k and so on;
	Blocktime	<ul><li>if that instruction is bloc,</li><li>1 : Blocking time(ms); waiting time for instruction execution</li><li>0 : non-blocking;</li></ul>
	Output	0: canbus is opened normally; -1: failure;

## 14.11.10 CanbusRecv Receiving Data

CanbusRecv	(Receiv	e data	by Canbus)
1.Connect Name			
2.Save data to	#Str	•	1
3.BlockTime	Oms		
4.Output	#Var	•	1

Examples of instructions	CanbusRecv	name="imf" dest=#Str1 block=0 =>#Var1;
Parameter	Connect Name	canbus identifier, created by CanbusOpen;
Description	Save data to	The received data frame will be converted into a string and stored in the form of"frame id, frame payload, standard



	frame/extended frame, data frame/remote frame, data;", for
	example:
	000000FF,08,std,d,09,0A,0B,0C,0D,0E,0F,10;000000FE,8,ext,r
	,09,0A,0B,0C,0D,0E,0F,10, multiple frames of data received
	at one time, with ";"(a) Division;
	if that instruction is bloc,
Block time	1: Blocking time (ms); waiting time for instruction execution
	0: non-blocking;
	output values,
output	>=0: the number of received can frames;
	-1 : failure;

### 14.11.11 CanbusSend Sending Data

CanbusSend	l (Send	data b	y Canbus)
1.Connect Name			
2.Send data from	#Str	▼	1
3.BlockTime	Oms		
4.Output	#Var	•	1

Examples of	CaphusSand	$n_{2} = m_{1} = m_{1} = m_{2} = m_{1} = m_{2} = m_{1} = m_{2} = m_{1} = m_{1$
instructions	Campussenu	$\operatorname{Ham} = \operatorname{Hm} \operatorname{SIC} = \# \operatorname{SIL} \operatorname{DIOCK} = \operatorname{O} = 2 \# \operatorname{Val} I,$
	Connect	canbus identifier, created by CanbusOpen:
	Name	
	Send data	The string stored in the sent data frame, the format is the
	from	same as CanbusRecv
Parameter		if that instruction is block,
Description	Block time	1: Blocking time (ms); waiting time for instruction execution
		0: non-blocking;
		output values,
	Output	>=0: the number of received can frames;
		-1: failure;



## 14.11.12 CanbusClose Closing a TCP/IP Connection

		CanbusClose (Close Canbus)
		1.Connect Name
Examples of	CanhusClos	ename-"imf".
instructions	Cambuscios	
Parameter	Connect	Close the caphus identifier greated by CaphusOpen
Description	Name	Close the campus identifier, created by CampusOpen;

## **15 Error Messages**

Error Code	Error message	Solution
0001	Hardware slave configuration fails, path is invalid, error code %1 (1: null; 2: length<3; 3: length>4096	Internal error, please upgrade or restore the program
0002	Hardware initialization fails, error code %1	Check that the hardware is powered on
0003	Hardware not ready, error code %1 ( -1: ethercat disconnected; -2: slave number change; -13: hardware not register; -23: NIC driver abnormal; -33: cable disconnected)	Check whether the EtherCAT network communication is normal. Check if the number of slaves has changed. Check for registration.
0004	Axis %1 is not ready for interpolation, error code %2	Check whether the EtherCAT communication is normal, power off and restart
0005	Hardware slave %1 error, driver error code %2, ref to driver manual	Slave station error, refer to the handling method of specific slave station brand
0006	Read encoder (0 -based) %1 fails, error code %2	Check whether the EtherCAT communication is normal and the network cable is disconnected
0007	Axis %1 servo on fails, error code %2 ( -1: ethercat not ready; -4: no power supply; -5:	Check whether the EtherCAT communication is normal, whether



	slave error)	the network cable is disconnected
		and whether it is powered on
		Check whether the EtherCAT
		communication is normal and
0008	Axis %1 servo off fails, error code %2	whether the network cable is
		disconnected and whether it is
		powered on
		Check whether the EtherCAT
0000	Avia 0/1 alaan aman faila annan aa da 0/2	communication is normal, whether
0009	AXIS %1 Clear error fails, error code %2	the network cable is disconnected
		and whether it is powered on
		Check whether the EtherCAT
0000	Axis %1 get slave error code fails, error code	communication is normal, whether
000A	%2	the network cable is disconnected
		and whether it is powered on
		Check whether the EtherCAT
0000	Avia $\frac{1}{2}$ and along state fails array and $\frac{1}{2}$	communication is normal, whether
0008	Axis %1 get slave state fails, erfor code %2	the network cable is disconnected
		and whether it is powered on
		Check whether the EtherCAT
	Read profiler (0 -based) %1 fails, error code %2	communication is normal and
000C		whether the network cable is
		disconnected and whether it is
		powered on
000D	IO is not ready, error code %1	Check IO
		Check the software setting
1001	Software configuration is invalid	parameters to see which parameter
		setting failed error message
	Cofficient initialization fails	
1002		check software setup parameters
1003	Axis reference calibration is invalid	Re-calibrate zero
1004	Axis %1 positive limit error, current %2 out of	Warning clears automatically after



	[%3, %4]	jog back to range of motion
1005	Axis %1 negative limit error, current %2 out	Warning clears automatically after
1005	of [%3, %4]	jog back to range of motion
1006	Cartesion (XYZABC) %1 positive limit error,	Warning clears automatically after
1000	current %2 out of [%3, %4]	jog back to range of motion
1007	Cartesion (XYZABC) %1 negative limit error,	Warning clears automatically after
1007	current %2 out of [%3, %4]	jog back to range of motion
1008	Axis %1 overspeed, current %2, beyond limit	Manually Clear Errors
1000	%3	
1009	%1 linear velocity overspeed, current %2,	Manually Clear Errors
1005	beyond limit %3	
100A	%1 angular velocity overspeed, current %2,	Manually Clear Errors
	beyond limit %3	
	Motion time out fatal error, current(ns) %1,	Please contact technical support or
100B	beyond motion cycle(ns) %2	modify the planning cycle and
		EtherCAT cycle parameters
	Motion time out warning, current(ns) %1,	Please contact technical support or
100C	beyond 80% of motion cycle(ns) %2	modify the planning cycle and
		EtherCAT cycle parameters
100D	Cannot open premotion log file	No treatment required
	Inverse kinematic fatal error, target point	
100E	(KCS without tool, UUID=%1) is X: %2, Y: %3,	Check teaching point
	Z: %4, A: %5, B: %6, C%7, pose idx: %8, error	
	code %9	
	Target point is not reachable, target point	
1005	(KCS without tool, UUID=%1) is: X: %2, Y: %3,	
1005	Z: %4, A: %5, B: %6, C%7, pose idx: %8, error	Check teaching point
	code %9	
	Movc points are co-linear, command UUID is	
1010	%1	Check teaching point
1011	External cannot follow robot, as robot	
1011	trajectory is too small, UUID = %1	Releach robot trajectory



1012	Start point pose index %1! = End point pose index %2, UUID = %3	Check teach point posture
1013	Start point pose index %1! = Aux point pose index %2, UUID = %3	Check teach point posture
2001	Invalid parameter: profile ts %1, out of [0.0005, 0.016]	Check setup parameters
2002	Invalid parameter: profile size %1, out of [32, 512]	Check setup parameters
2003	Invalid parameter: smooth size %1, out of [0, 128]	Check setup parameters
2004	Invalid parameter: %1 encoder actual resolution %2	Check setup parameters
2005	Invalid parameter: %1 encoder feedback resolution %2	Check setup parameters
2006	Invalid parameter: %1 encoder sign %2	Check setup parameters
2007	Invalid parameter: %1 motor max speed %2	Check setup parameters
2008	Invalid parameter: %1 motor max current %2	Check setup parameters
2009	Invalid parameter: %1 motor max torque %2	Check setup parameters
200A	Invalid parameter: %1 axis positive limit %2, negative limit %3	Check setup parameters
200B	Invalid parameter: %1 axis max velocity %2, max jog velocity %3	Check setup parameters
200C	Invalid parameter: %1 axis, gear ratio in axis side %1 > gear ratio in motor side %2	Check setup parameters
200D	Invalid parameter: %1 axis sign %2	Check setup parameters
200E	Invalid parameter: Cartesion %1 positive limit %2, negative limit %3	Check setup parameters



200F	Invalid parameter: Cartesian %1 max velocity %2, max jog velocity %3	Check setup parameters
2010	Invalid parameter: Cartesian %1 sign %2	Check setup parameters
	Invalid parameter: Cartesian end linear max	
2011	velocity %1, max acceleration %2, max	Check setup parameters
	deacceleration %3	
	Invalid parameter: Cartesian end angular	
2012	max velocity %1, max acceleration %2, max	Check setup parameters
	deacceleration %3	
	Invalid parameter: Axis space end max	
2013	velocity %1, max acceleration %2, max	Check setup parameters
	deacceleration %3	
	Invalid parameter: External group %1, axis	
2014	space end max velocity %2, max acceleration	Check setup parameters
	%3, max deacceleration %4	
2015	Invalid parameter: %1	Check setup parameters
	coordinate, index %2	
2016	Invalid parameter: Axis %1 reference zero	Check setup parameters
	pulse, based on reference current axis is %2	
3001	%1: Only works in %2 state	Check Controller Status
3002	%1: Not works in %2 state	Check Controller Status
3003	%1: Only works in Teach Mode	Check Controller Status
3004	%1: Hardware is not ready	Check the hardware
3005	%1: Command buffer is not ready (full or	Internal error
	finished)	Contact Technical Support
3006	%1: Parameter %2 = %3 is invalid	Check setup parameters
3007	%1: Parameter %2 = %3 is invalid, valid value	Check setup parameters
	is between [%4,%5]	
3008	%1: Parameter struct is invalid	Check setup parameters
2000	InitMotionController: Controller has been	Internal error
3003	initialized	No treatment required



	StartMotionController: Controller has not	
3004	heen initialized call	Internal error
3004		No treatment required
	Imf::InitiviotionController first	
300B	StartMotionController: Controller has been	Internal error
	started	No treatment required
3000	%1. Controller has not been started	Internal error
5000		No treatment required
3000	StartMotionController: Robot model dll path	Internal error
3000	is invalid	Upgrade or restore your system
2005	StartMotionController: Robot model dll dose	Internal error
JUOL	not contain specific robot type %1	Upgrade or restore your system
2005	StartMotionController: Cannot open %1	Internal error
3001	controller dll, system error info %2	Upgrade or restore your system
	StartMotionController: Creating controller	Internal error
3010	with specific type (real/virtual/simulated)	
	fails, system error info %1	Opgrade or restore your system
	StartMotionController: Creating %1 posix	Internal error
3011	thread fails, system error info %2	Contact Technical Support
2012	LogMotionDataOn: Motion log path %1 is	Internal error
3012	invalid	Upgrade or restore your system
2012	Jog: Only works in Teach Mode and Servo On	Charle Controllon Status
3013	state	Check Controller Status
2014	Jog: Jog coordinate is different from current	Check the coordinate system
3014	working coordinate	parameters sent by Jog
	%1: Immediate motion command only works	
3015	in Teach Mode, in Standby State and no	Check the conditions for immediate
	immediate motion command is executing	command sending
2016	%1: Immediate command only works in	Check the conditions for immediate
3016	Teach Mode	command sending
2017	%1: Immediate command only works in	Check the conditions for immediate
5017	Teach Mode,	command sending
3018	%1: Velocity %2 is out of range (%3, %4] with	Check command parameters



	unit %5	
	%1: Blend radius %2 is out of range [%3. %4]	
3019	with unit %5	Check command parameters
301A	%1: Target point is not reachable, UUID = %2	Check command target point
	%1: The first coordinate is system reserved,	Manual Clear
301B	not allowing modification	No treatment required
		Internal error
301C	%1: Unly suitable for Real Controller Mode	No treatment required
2010	%1: Open dll %2 fails %2	Internal error
3010		Upgrade or restore your system
301F	%1·%2 dll is not loaded	Internal error
JUIL		Upgrade or restore your system
301F	%1: %2 function is not registered, cannot find	Internal error
5011	specified function	Upgrade or restore your system
50000	Emergency stop button is pressed	Release the emergency stop
50100	system IO [%1] is triggered	
50101	system IO [%1] is triggered	
50102	system IO [%1] is triggered	
		Internal error, cannot be resolved
20000	undefined data type %1	after restart, contact technical
		support
20001	no project has been loaded	Please open a project first
		Database Internal error, cannot be
21000	mysql exec error %1	resolved after restart, contact
		technical support
	mysql data format error, missing col %1 or	Database Internal error, cannot be
21001	data type not compatible	resolved after restart, contact
		technical support
		Database Internal error, cannot be
21002	get failed, id %1 not exist in %2	resolved after restart, contact
		technical support
21003	set key %1 of table %2 failed, must in	Database Internal error, cannot be



	range([%3, %4])	resolved after restart, contact
		technical support
	est key 0/1 of table 0/2 failed address out of	Database Internal error, cannot be
21004	set key %1 of table %2 falled, address out of	resolved after restart, contact
	bounds: offset + size = %3, size of target = %4	technical support
		Database Internal error, cannot be
21005	set key %1 of table %2 failed, key not exist	resolved after restart, contact
		technical support
		Database Internal error, cannot be
21006	error loading project %1, not exist	resolved after restart, contact
		technical support
		Database Internal error, cannot be
21007	error loading project %1, missing main	resolved after restart, contact
		technical support
		Database Internal error, cannot be
21008	user data table %1 not found	resolved after restart, contact
		technical support
		Communication error, cannot be
22000	modbus error %1	resolved after restart, contact
		technical support
30000	system init	No treatment required
30001	system init timeout, over %1 s	No treatment required
		Configuration file error, cannot be
30002	unknown motion mode %1, real will be used.	resolved after restart, contact
		technical support
		Configuration file error, cannot be
30003	no ecat config file, init abort	resolved after restart, contact
		technical support
		Failed to call API. Unable to solve
31000	api calling error %1	after restarting. Contact technical
		support
31001	motion Internal error %1	Unable to resolve after restart,



		contact technical support
32000	command %1 missing keyword %2	Instruction format error, check
52000		program
32001	command %1, unexpected value of keyword	Instruction format error, check
52001	%2	program
22002	command %1 invalid value of kowword %2	Instruction format error, check
32002		program
32003	unknown robot command: %1	Instruction format error, check
32003		program
40000	%1: error parsing (Q variable/ $%$ 2)	Instruction format error, check
40000		program
40001	%1: orror parsing String(%2)	Instruction format error, check
40001		program
40002	%1 or or parsing operator ( $%2$ )	Instruction format error, check
40002		program
40003	%1: error parsing number(%2)	Instruction format error, check
40003		program
40004	%1: error parsing integer(%2)	Instruction format error, check
40004		program
40005	%1: error parsing system variable(%2)	Instruction format error, check
40005		program
10006	%1: unbalanced multi-line comment	Instruction format error, check
40000		program
41000	%1: invalid symbol(%2) in expression	Instruction format error, check
41000		program
41001	%1: unknown built-in func %2	Instruction format error, check
41001		program
41002	%1: expression terminated unexpectedly	Instruction format error, check
41002		program
41003	%1: unbalanced narenthesis in expression	Instruction format error, check
41003		program
41004	%1: invalid ++/ in expression	Instruction format error, check



		program
41005	%1: undeclared cymbol %2	Instruction format error, check
41005		program
41100	9/1, involid statement declaration with 9/2	Instruction format error, check
41100	%1: Invalid statement declaration with %2	program
41101	0(1, 0(2)) statement missing symplet $0(2)$	Instruction format error, check
41101	%1: %2 statement missing symbol %3	program
41102	%1. %2 statement missing knyword %2	Instruction format error, check
41102	MI. MZ Statement missing Reyword MS	program
	%1: break/continue only works with in	Instruction format error, check
41180	for/while	program
11101	%1: for statement loop variable not left	Instruction format error, check
41101	-value	program
11197	%1: assignment left term not left avalue	Instruction format error, check
41102	MI. assignment left term not left -value	program
	%1: %2 all robot cmd admits only one output	Instruction format error, check
41200	term	program
41201	%1: %2 output term must be placed in the	Instruction format error, check
41201	%1: %2 output term must be placed in the end for all robot cmd	Instruction format error, check program
41201	%1: %2 output term must be placed in the end for all robot cmd	Instruction format error, check program Instruction format error, check
41201 41202	<ul><li>%1: %2 output term must be placed in the</li><li>end for all robot cmd</li><li>%1: %2 missing symbol %3</li></ul>	Instruction format error, check program Instruction format error, check program
41201 41202 41203	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> </ul>	Instruction format error, check program Instruction format error, check program Instruction format error, check
41201 41202 41203	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> </ul>	Instruction format error, check program Instruction format error, check program Instruction format error, check program
41201 41202 41203	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> </ul>	Instruction format error, check program Instruction format error, check program Instruction format error, check program Instruction format error, check
41201 41202 41203 41204	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> <li>%1: %2 incomplete key-value pair detected</li> </ul>	Instruction format error, check program Instruction format error, check program Instruction format error, check program Instruction format error, check program
41201 41202 41203 41204	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> <li>%1: %2 incomplete key-value pair detected</li> <li>%1: %2 key -value pair count check fail, %3</li> </ul>	Instruction format error, checkprogramInstruction format error, check
41201 41202 41203 41204 41205	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> <li>%1: %2 incomplete key-value pair detected</li> <li>%1: %2 key -value pair count check fail, %3 required</li> </ul>	Instruction format error, check program Instruction format error, check program Instruction format error, check program Instruction format error, check program Instruction format error, check program
<ul> <li>41201</li> <li>41202</li> <li>41203</li> <li>41204</li> <li>41205</li> <li>41200</li> </ul>	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> <li>%1: %2 incomplete key-value pair detected</li> <li>%1: %2 key -value pair count check fail, %3 required</li> <li>%1: program doclaration missing keyword %2</li> </ul>	Instruction format error, checkprogramInstruction format error, check
<ul> <li>41201</li> <li>41202</li> <li>41203</li> <li>41204</li> <li>41205</li> <li>41300</li> </ul>	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> <li>%1: %2 incomplete key-value pair detected</li> <li>%1: %2 key -value pair count check fail, %3 required</li> <li>%1: program declaration missing keyword %2</li> </ul>	Instruction format error, checkprogramInstruction format error, checkprogram
41201 41202 41203 41204 41205 41300 41301	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> <li>%1: %2 incomplete key-value pair detected</li> <li>%1: %2 key -value pair count check fail, %3 required</li> <li>%1: program declaration missing keyword %2</li> </ul>	Instruction format error, checkprogramInstruction format error, check
<ul> <li>41201</li> <li>41202</li> <li>41203</li> <li>41204</li> <li>41205</li> <li>41300</li> <li>41301</li> </ul>	<ul> <li>%1: %2 output term must be placed in the end for all robot cmd</li> <li>%1: %2 missing symbol %3</li> <li>%1: %2 missing keyword %3</li> <li>%1: %2 incomplete key-value pair detected</li> <li>%1: %2 key -value pair count check fail, %3 required</li> <li>%1: program declaration missing keyword %2</li> <li>%1: program declaration missing symbol %2</li> </ul>	Instruction format error, checkprogramInstruction format error, checkprogram



		program
41303	%1: function name (%2) differs from file	Instruction format error, check
	name (%3)	program
41304	%1: function declaration, missing return type	Instruction format error, check
		program
41305	%1: function declaration, invalid return type	Instruction format error, check
	%2	program
41306	%1: function declaration, duplicate argument	Instruction format error, check
	%2	program
41307	%1: function declaration, invalid argument	Instruction format error, check
	name %2	program
41209	%1: function declaration, invalid argument	Instruction format error, check
41308	type %2	program
41200	%1: wrong argument number: provided = %2,	Instruction format error, check
41309	expected = %3	program
11301	%1: function argument type check failure	Instruction format error, check
41304		program
42000	%1: operands type check fail %2	Instruction format error, check
		program
42001	%1: division by 0, %2	Instruction format error, check
		program
42002	%1: invalid operand value %2	Instruction format error, check
		program
42003	%1: symbol %2 not exist	Instruction format error, check
42003		program
42004	%1: index (%2) exceeds array bounds %3	Instruction format error, check
		program
42005	%1: field (%2) not exist in struct	Instruction format error, check
		program
42100	%1: function %2 arg count check failure, %3	Instruction format error, check
	provided, %4 needed	program
42101	%1: function %2 with the %3 -th input null	Instruction format error, check



		program
42102	%1: function %2 division by 0	Instruction format error, check
		program
42103	%1: function %2 arg type check faliure (%3)	Instruction format error, check
		program
42104	%1: function %2 arg range check faliure %3	Instruction format error, check
		program
42200	%1: %2 passing array as parameter is	Instruction format error, check
	forbidden, key = %3	program
42201	%1: %2 group and index of DIO must be	Instruction format error, check
	integers %3	program
42202	%1: %2 index of AIO must be integers %3	Instruction format error, check
42202		program
42202	%1: %2, key %3 must be %4 type	Instruction format error, check
42203		program
12300	%1: unknown struct field %2	Instruction format error, check
42300		program
42301	%1: manipulation of struct field %2 is	Instruction format error, check
42301	forbidden	program
42302	%1: IO variable %2 out of bounds	Instruction format error, check
42302		program
42303	%1: undefined coord type %2	Instruction format error, check
		program
43000	file %1 not exist	Program does not exist, check if
		program exists
43001	duplicate command name %1, last found in	Instruction format error, check
	%2	program
43002	duplicate command type %1, last found in %2	Instruction format error, check
		program
43003	execute %1 isnforbidden, type = FUNCTION	Instruction format error, check
		program
43004	program %1, start line %2 exceeds limit	Startup line number out of limit



60000	invalid registration file	Error in registration file, which cannot be solved after restarting. Contact technical support
60001	invalid registration code	Error in registration file, which cannot be solved after restarting. Contact technical support
61000	app id = %1 is registered, but cannot be loaded	The program file is missing and cannot be solved after restarting. Contact technical support
61001	apps %1 and %2 have duplicate id = %3	Process plug-in error, cannot be resolved after restart, contact technical support
61002	apps %1 and %2 accepts common command %3	Process plug-in error, cannot be resolved after restart, contact technical support